Tenda

Ouick Installation Guide

For product or function details, please go to www.tendacn.com to download user guide.

AC1200 MU-MIMO Dual Band Gigabit WiFi Router Model: AC10/AC10U

Packing List

WiFi Router * 1 Power Adapter * 1 Ethernet Cable * 1 Quick Installation Guide * 1



If any item is missing, or damaged, please keep the original package and contact the local reseller or distributor immediately

If you want to replace your original router connected to the internet with a PPPoE user name and password, start from Step 1. Otherwise, start from Step 2.

Step 1: Migrate your PPPoE user name and password from your original router

• Power on your original and new routers.

Power

New router

LAN

- 2 Connect the WAN port of the original router to port 1, 2 or 3 of the new router using an Ethernet cable.
- 3 When the LAN and WAN indicators of the new router get solid on for 3 seconds after fast blinking, your PPPoE user name and password are migrated successfully.

Ethernet cable

 \square


Power

0 VVVV

Original router

4 Remove the original router.





Step 3: Set up the router

• Start a web browser on the device connected to the router. Enter tendawifi.com or 192.168.0.1 in the address bar, and press Enter.

Click Start.

- Tenda Tenda Router Quick Setup Wizard **Tip**: If the page above does not appear, refer to **Q1** in **FAQ**.
- If you imported ISP user name and password, click Next. If you did not, choose your connection type, set the related parameters, and click Next.

Then click Next.






4 Set your WiFi name (SSID), WiFi password, and login password.

Connected. Use the WiFi name and the WiFi password you set to connect your wireless devices to the router. Now, you can access the internet through your wireless and wired devices.

| WiFi Settings | | | | | |
|---|--|--|--|--|--|
| 🔶 WiFi Name | | | | | |
| ♀ WiFi password of 8-32 characters □ Not Required | | | | | |
| Set the WiFi password as the login password of the admin account. | | | | | |
| Login password of 5-32 characters | | | | | |
| Next | | | | | |
| The WiFi password is used to connect to the WiFi rk, and the login password is used to log in to the web ne router. | | | | | |



LED indicators

| LED Indicator | Status | Description | | | |
|---------------|-------------------------------------|---|--|--|--|
| | Solid on | The router is starting.The system is faulty after startup. | | | |
| | Slow blinking | The system is working properly. | | | |
| SYS | Fast blinking twice (AC10U only) | A portable USB device is connected to the USB port. | | | |
| | Fast blinking (AC10U only) | Data is transmitting over the USB port. | | | |
| | Solid on | The WAN port is connected properly. | | | |
| WAN | Fast blinking | Data is transmitting over the WAN port. | | | |
| | Off | The WAN port is disconnected or connected improperly. | | | |
| | Solid on | Port 1, 2 or 3 is connected properly. | | | |
| LAN | Blinking twice | A new device is connected to port 1, 2 or 3. | | | |
| | Off | None of ports 1, 2 and 3 is connected or connected properly. | | | |
| | Solid on | At least the 2.4 GHz or 5 GHz WiFi network is enabled. | | | |
| WiFi | Fast blinking | Data is transmitting wirelessly. | | | |
| | Slow Blinking | The router is performing WPS negotiation. | | | |
| | Off | The wireless function is disabled. | | | |

Ports and buttons

| Port / Button | Description |
|---------------------|---|
| WIFI | Used to enable/disable the WiFi of the router. |
| RST/WPS | Used to start the WPS negotiation process of the router, or to reset the router. WPS: Press the button of the router, and enable the WPS function of another device within 2 minutes to establish a WPS connection. Reset: Hold the button down for about 8 seconds. Reset succeeds when all LED indicators blink once. |
| 3 | By default, it is a LAN port the same as port 1/2. But after the IPTV function of the router is enabled, it functions only as an IPTV port used to connect with a set-top box. |
| 1/2 | They are LAN ports used to connect to devices such as computers or switches |
| WAN | Used to connect this router to the internet. |
| POWER | Used to connect with the power adapter included in the package. |
| USB (AC10U only) | Used to connect with a portable USB device. |

FAO

Q1: If I cannot log in to the web UI of the router, what should I do?

A1: Try the following solutions and log in again:

- If entering the IP address 192.168.0.1 does not work, you can try tendawifi.com
- Ensure that your device is connected to the router's WiFi network or port 1, 2 or 3 properly. For detailed connection instructions, refer to Step 2.
- use a Google Chrome, Firefox, or Internet Explorer 8 (or later) browser.
- Replace your computer or wireless device.

blink once. Then you can try logging again.

- A2: Try the following solutions:
- internet
- correct.

| Connection type | Information pro |
|--------------------|---------------------------------|
| PPPoE | ISP user name and |
| Dynamic IP address | None |
| Static IP address | IP Address, subne parameters |

- password is changed, connect to the WiFi network using the new name or password.
- port 1, 2 or 3 properly.
- If the problem still persists, consult your ISP.

Q3: Why cannot my phone find the 5 GHz signal?

A3: Only devices supporting 5 GHz signal can find and connect to the 5 GHz network.

FC

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This device is restricted to be used in the indoor.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.


Operating Temperature: 0 °C - 40 °C Operating Humidity: (10 - 90)% RH, non-condensing



RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys new electrical or electronic equipment.

| г | п | Γ. |
|---|---|----|
| F | н | L |
| L | | L |



Clear the cache of your web browser or replace the web browser. You are recommended to

Hold down the RST/WPS button for about 8 seconds. Reset succeeds when all LED indicators

Q2: If I cannot access the internet after the configuration, what should I do?

• Ensure that the Ethernet cable connected to the WAN port of the router has connected to the

• Refer to the following table to check whether your connection type and login parameters are

ovided by your ISP

nd ISP password

et mask, gateway, DNS server and other

 If your wireless devices cannot access the internet, ensure that you connect to the router's SSID. You can also change your WiFi name and password on the web UI of the router. If WiFi name or • If your wired device cannot access the internet, ensure that the wired device is connected to

CE

CE Mark Warning

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

Operations in the 5.15-5.25 GHz band are restricted to indoor use only.

This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

The mains plug is used as disconnect device, the disconnect device shall remain readily operable. NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.


Declaration of Conformity

Hereby, SHENZHEN TENDA TECHNOLOGY CO., LTD. declares that the radio equipment type AC10 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: http://www.tendacn.com/en/service/download-cata-101.html Hereby, SHENZHEN TENDA TECHNOLOGY CO., LTD. declares that the radio equipment type AC10U is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: http://www.tendacn.com/en/service/download-cata-101.html Operate Frequency: 2.4 GHz: EU/2400-2483.5 MHz (CH1-CH13) 5 GHz: EU/5150-5250 MHz (CH36-CH48) EIRP Power (Max.): 2.4 GHz: 19.95 dBm 5 GHz: 22.9 dBm Software Version: V15.03.06



Adapter Model: BN036-A12012E Manufacture: SHENZHEN HEWEISHUN NETWORK TECHNOLOGY Co., LTD Input: 100 - 240 V AC 50/60 Hz 0.4 A Output: 12 V === 1 A ----: DC Voltage



Adapter Model: BN037-A18012E Manufacture: SHENZHEN HEWEISHUN NETWORK TECHNOLOGY Co., LTD Input: 100 - 240 V AC 50/60 Hz 0.6 A Output: 12 V === 1.5 A ----: DC Voltage

| IE | EL | ES | FR | HR | IT | СҮ | LV |
|----|----|----|----|----|----|----|----|
| PL | PT | RO | SI | SK | FI | SE | UK |

Copyright © 2017 Shenzhen Tenda Technology Co., Ltd. All rights reserved. Tenda is a registered trademark legally held by Shenzhen Tenda Technology Co., Ltd. Other brand and product names mentioned herein are trademarks or registered trademarks of their respective holders. Specifications are subject to change without notice.

Technical Support

Shenzhen Tenda Technology Co., Ltd. 6-8 Floor, Tower E3, NO.1001, Zhongshanyuan Road, Nanshan District, Shenzhen, China. 518052 USA hotline: 1-800-570-5892 Toll Free: Daily 9am to 6pm EST Canada hotline: 1-888-998-8966 Toll Free: Mon - Fri 9 am - 6 pm PST Website: http://www.tendaus.com Email: support.usa@tenda.com.cn Hong Kong Hotline: 00852-81931998 Website: http://www.tendacn.com E-mail: support@tenda.com.cn