



Service Manual

GREE ELECTRIC APPLIANCES, INC. OF ZHUHAI



Table of Contents


Part I : Technical Information	1
1. Summary.....	1
2. Specifications	6
2.1 Specification Sheet.....	6
2.2 Capacity Variation Ratio According to Temperature.....	38
2.3 Cooling and Heating Data Sheet in Rated Frequency.....	40
3. Outline Dimension Diagram.....	41
3.1 Indoor Unit.....	41
3.2 Outdoor Unit.....	42
4. Refrigerant System Diagram	44
5. Electrical Part	45
5.1 Wiring Diagram	45
5.2 PCB Printed Diagram.....	50
6. Function and Control	57
6.1 Remote Controller Introduction	57
6.2 GREE+ App Operation Manual	62
6.3 Ewpe Smart App Operation Manual.....	63
6.4 Brief Description of Models and Functions	64
Part II : Installation and Maintenance	66
7. Notes for Installation and Maintenance	66
8. Installation	73
8.1 Installation Dimension Diagram.....	73
8.2 Installation Parts-checking	75
8.3 Selection of Installation Location.....	75
8.4 Electric Connection Requirement.....	75

8.5 Installation of Indoor Unit.....	76
8.6 Installation of Outdoor Unit.....	78
8.7 Vacuum Pumping and Leak Detection.....	79
8.8 Check after Installation and Test Operation	80
9. Maintenance	81
9.1 Error Code List.....	81
9.2 Procedure of Troubleshooting	86
9.3 Troubleshooting for Normal Malfunction	98
10. Exploded View and Parts List.....	100
10.1 Indoor Unit.....	100
10.2 Outdoor Unit.....	104
11. Removal Procedure	109
11.1 Removal Procedure of Indoor Unit.....	109
11.2 Removal Procedure of Outdoor Unit.....	119
Appendix	144
Appendix 1: Reference Sheet of Celsius and Fahrenheit.....	144
Appendix 2: Configuration of Connection Pipe	144
Appendix 3: Pipe Expanding Method.....	145
Appendix 4: List of Resistance for Temperature Sensor.....	146

1. Summary

Indoor Unit:

A1 panel(Blue)



A1 panel(Silver)



A1 panel(Black)




A2 panel(White)



A2 panel(Silver)




A1 panel(White)



A1 panel(Champagne)




A2 panel(Black)




Outdoor Unit:


GWH09AUCXB-K6DNA1A/O
GWH12AUCXB-K6DNA1A/O




GWH18AUDXD-K6DNA1A/O




GWH12AUDXD-K6DNA1C/O



GWH18AUDXE-K6DNA1A/O
GWH18AUDXE-K6DNA1B/O
GWH18AUDXE-K6DNA2C/O



GWH24AUDXF-K6DNA1A/O
GWH24AUDXF-K6DNA1B/O



Remote Controller:



YBE1F/YBE1F1/YBE1FB2

Model list

No.	Model	Product code	Indoor model	Indoor product code	Outdoor model	Outdoor product code	Remote Controller
1	GWH09AUCXB-K6DNA2A	CB597000400	GWH09AUCXB-K6DNA2A/I	CB597N00400			YBE1F
2		CB597000403		CB597N00403			YBE1FB2
3		CB597000404		CB597N00404			YBE1F
4		CB597000406		CB597N00406			
5		CB597000407		CB597N00407			
6		CB597000408		CB597N00408			CB575W00300
7		CB575000300		CB575N00300	GWH09AUCXB-K6DNA1A/O		YBE1F1
8		CB575000302		CB575N00302			YBE1F
9		CB575000303		CB575N00303			YBE1F
10		CB575000304		CB575N00304			YBE1F
11		CB575000307		CB575N00306			YBE1FB2
12		CB575000311		CB575N00311			YBE1F1
13		CB575000314		CB575N00314			YBE1F
14	GWH09AUCXB-K6DNA1A	CB575000313	GWH09AUCXB-K6DNA1A/I	CB575N00313			YBE1FB2
15		CB575000301		CB575N00300		CB575W00301	YBE1F1
16		CB575000305		CB575N00302			YBE1F
17		CB575000306		CB575N00306			YBE1FB2
18		CB575000308		CB575N00308			YBE1F
19		CB575000309		CB575N00309			
20		CB575000310		CB575N00310			
21		CB575000312		CB575N00311			YBE1F1
22		CB597000401		CB597N00400			YBE1F
23	GWH09AUCXB-K6DNA2A	CB597000402	GWH09AUCXB-K6DNA2A/I	CB597N00402			YBE1FB2
24		CB597000405		CB597N00405			YBE1F
25	GWH12AUCXB-K6DNA2A	CB597000100	GWH12AUCXB-K6DNA2A/I	CB597N00100		CB575W00200	YBE1F
26		CB597000102		CB597N00102			YBE1F
27		CB597000103		CB597N00103			YBE1FB2
28		CB597000104		CB597N00104			YBE1F
29		CB575000200		CB575N00200	GWH12AUCXB-K6DNA1A/O		YBE1F1
30		CB575000202		CB575N00202			YBE1F
31		CB575000203		CB575N00203			YBE1F
32		CB575000204		CB575N00204			YBE1F
33		CB575000207		CB575N00206			YBE1FB2
34		CB575000201		CB575N00200			YBE1F1
35	GWH12AUCXB-K6DNA1A	CB575000205	GWH12AUCXB-K6DNA1A/I	CB575N00202		CB575W00201	YBE1F
36		CB575000206		CB575N00206			YBE1FB2
37		CB575000208		CB575N00203			YBE1F
38		CB575000209		CB575N00204			YBE1F
39		CB575000210		CB575N00210			YBE1FB2
40		CB597000101		CB597N00100			YBE1F
41	GWH12AUCXD-K6DNA2C	CB597000600	GWH12AUCXD-K6DNA2C/I	CB597N00600			
42		CB597000602		CB597N00602			
43		CB575000700		CB575N00700	GWH12AUCXD-K6DNA1C/O	CB575W00700	YBE1F1
44		CB575000705		CB575N00705			YBE1F
45		CB575000704		CB575N00704			YBE1FB2
46		CB575000701		CB575N00700		CB575W00701	YBE1F1
47		CB575000702		CB575N00702			YBE1F
48		CB575000703		CB575N00703			YBE1F1
49	GWH12AUCXD-K6DNA1C	CB575000757	GWH12AUCXD-K6DNA1C/I	CB575N00705			YBE1F
50		CB575000708		CB575N00704			YBE1FB2
51		CB597000601		CB597N00600			YBE1F
52	GWH12AUCXD-K6DNA2C	CB597000603	GWH12AUCXD-K6DNA2C/I	CB597N00603			

Model list:

No.	Model	Product code	Indoor model	Indoor product code	Outdoor model	Outdoor product code	Refrigerant Controller
53	GWH18AUDXD-K6DNA2A	CB597000200	GWH18AUDXD-K6DNA2A/I	CB597N00200	GWH18AUDXD-K6DNA1A/O	CB575W00100	YBE1F
54		CB597000204		CB597N00204			YBE1FB2
55		CB597000203		CB597N00203			YBE1F
56		CB597000205		CB597N00205			YBE1F1
57		CB575000100		CB575N00100			YBE1F
58	GWH18AUDXD-K6DNA1A	CB575000102	GWH18AUDXD-K6DNA1A/I	CB575N00102	GWH18AUDXD-K6DNA1A/O	CB575W00101	YBE1FB2
59		CB575000103		CB575N00103			YBE1F1
60		CB575000104		CB575N00104			YBE1F
61		CB575000107		CB575N00105			YBE1FB2
62		CB575000101		CB575N00100			YBE1F1
63	GWH18AUDXD-K6DNA2A	CB575000105	GWH18AUDXD-K6DNA2A/I	CB575N00102	GWH18AUDXD-K6DNA1A/O	CB575W00101	YBE1F
64		CB575000106		CB575N00105			YBE1FB2
65		CB575000108		CB575N00104			YBE1F
66		CB575000109		CB575N00103			YBE1FB2
67		CB575000110		CB575N00110			YBE1F
68	GWH18AUDXD-K6DNA2A	CB597000202	GWH18AUDXD-K6DNA2A/I	CB597N00200	GWH18AUDXD-K6DNA1A/O	CB575W00900	YBE1F
69		CB575000900		CB575N00900			YBE1F1
70		CB575000905		CB575N00905			YBE1FB2
71		CB575000906		CB575N00906			YBE1F
72		CB597000700	GWH18AUDXD-K6DNA2A/I	CB597N00700	GWH18AUDXD-K6DNA1A/O	CB575W00901	YBE1F1
73	GWH18AUDXE-K6DNA2A	CB597000702		CB597N00702			YBE1F
74		CB575000901		CB575N00900			YBE1F1
75		CB575000902		CB575N00902			YBE1F
76		CB575000903		CB575N00903			YBE1F1
77	GWH18AUDXE-K6DNA1A	CB575000909	GWH18AUDXE-K6DNA1A/I	CB575N00905	GWH18AUDXE-K6DNA1A/O	CB575W00901	YBE1FB2
78		CB575000910		CB575N00906			YBE1F
79		CB597000701		CB597N00700			YBE1F
80		CB597000703		CB597N00703			YBE1F1
81		CB575001100		CB575N01100			YBE1FB2
82	GWH18AUDXE-K6DNA1B	CB575001101	GWH18AUDXE-K6DNA1B/I	CB575N01101	GWH18AUDXE-K6DNA1B/O	CB575W01100	YBE1F
83		CB575001102		CB575N01102			YBE1F1
84		CB597000800		CB597N00800			YBE1FB2
85		CB597000300		CB597N00300			YBE1F
86		CB597000303		CB597N00302			YBE1FB2
87	GWH24AUDXF-K6DNA2A	CB597000304	GWH24AUDXF-K6DNA2A/I	CB597N00304	GWH24AUDXF-K6DNA1A/O	CB437W04700	YBE1F
88		CB597000305		CB597N00305			YBE1F1
89		CB597000306		CB597N00306			YBE1F
90		CB597000307		CB597N00307			YBE1FB2
91		CB437004700		CB437N04700			YBE1F1
92	GWH24AUDXF-K6DNA1A	CB437004702	GWH24AUDXF-K6DNA1A/I	CB437N04702	GWH24AUDXF-K6DNA1A/O	CB437W04701	YBE1F
93		CB437004703		CB437N04703			YBE1FB2
94		CB437004704		CB437N04704			YBE1F1
95		CB437004707		CB437N04706			YBE1F
96		CB437004712		CB437N04711			YBE1FB2
97	GWH24AUDXF-K6DNA2A	CB437004713	GWH24AUDXF-K6DNA2A/I	CB437N04713	GWH24AUDXF-K6DNA1A/O	CB437W04701	YBE1F1
98		CB437004714		CB437N04714			YBE1F
99		CB437004701		CB437N04700			YBE1FB2
100		CB437004705		CB437N04702			YBE1F1
101		CB437004706		CB437N04706			YBE1F
102	GWH24AUDXF-K6DNA1A	CB437004708	GWH24AUDXF-K6DNA1A/I	CB437N04704	GWH24AUDXF-K6DNA1A/O	CB437W04701	YBE1FB2
103		CB437004709		CB437N04703			YBE1F1
104		CB437004710		CB437N04710			YBE1F
105		CB437004711		CB437N04711			YBE1FB2
106		CB597000301		CB597N00300			YBE1F1
107	GWH24AUDXF-K6DNA2A	CB597000302	GWH24AUDXF-K6DNA2A/I	CB597N00302			YBE1F

Model list

No.	Model	Product code	Indoor model	Indoor product code	Outdoor model	Outdoor product code	Remote Controller
108	GWH24AUDXF-K6DNA1B	CB603001000	GWH24AUDXF-K6DNA1B/I	CB603N01000	GWH24AUDXF-K6DNA1B/O	CB603W01000	YBE1F
109		CB603001001		CB603N01000		CB603W01001	YBE1FB2
110		CB603001002		CB603N01002			YBE1F1
111		CB603001003		CB603N01003			

2. Specifications

2.1 Specification Sheet

Model		1.GWH09AUCXB-K6DNA1A 2.GWH09AUCXB-K6DNA2A
Product Code		1.CB575000300/CB575000302/CB575000303/CB575000304/CB575000307/ CB575000311/CB575000313/CB575000314 2.CB597000400/CB597000403/CB597000404/CB597000406
Power Supply	Rated Voltage	V~ 220-240
	Rated Frequency	Hz 50
	Phases	1
Power Supply Mode		Outdoor
Cooling Capacity		W 2700
Heating Capacity		W 3000
Cooling Power Input		W 670
Heating Power Input		W 680
Cooling Current Input		A 3.1
Heating Current Input		A 3.2
Rated Input		W 1400
Rated Cooling Current		A 6.0
Rated Heating Current		A 6.2
Air Flow Volume		m ³ /h 610/570/540/470/440/420/390/180
Dehumidifying Volume		L/h 0.80
EER		W/W 4.03
COP		W/W 4.41
SEER		8.5
SCOP(Average/Warmer/Colder)		4.6/5.7/3.5
Application Area		m ² 12-18
Indoor Unit	Model	1.GWH09AUCXB-K6DNA1A/I 2.GWH09AUCXB-K6DNA2A/I
	Product Code	1.CB575N00300/CB575N00302/CB575N00303/CB575N00304/ CB575N00306/CB575N00311/CB575N00313/CB575N00314 2.CB597N00400/CB597N00402/CB597N00404/CB597N00406
	Fan Type	Cross-flow
	Fan Diameter Length(DXL)	mm Φ98×633.5
	Cooling Speed	r/min 1200/1100/1050/950/800/700/650/500
	Heating Speed	r/min 1200/1100/1040/950/900/880/850
	Fan Motor Power Output	W 15
	Fan Motor RLA	A 0.22
	Fan Motor Capacitor	μF /
	Evaporator Form	Aluminum Fin-copper Tube
	Evaporator Pipe Diameter	mm Φ5
	Evaporator Row-fin Gap	mm 2-1.4
	Evaporator Coil Length (LXD×W)	mm 635×22.8×306.3
	Swing Motor Model	MP24HF/MP24AK/MP24BA
	Swing Motor Power Output	W 1.5/1.5/1.5
	Fuse Current	A 3.15
	Sound Pressure Level	dB (A) Cooling:38/37/34/31/26/23/22/19 Heating:39/37/34/31/30/29/28
	Sound Power Level	dB (A) Cooling:58/51/48/45/40/37/36/33 Heating:58/51/48/45/44/43/42
	Dimension (W×H×D)	mm 837×293×200
	Dimension of Carton Box (L×W×H)	mm 891×357×261
	Dimension of Package (L×W×H)	mm 896×373×272
	Net Weight	kg 9.5
	Gross Weight	kg 11.5

Outdoor Unit	Outdoor Unit Model		GWH09AUCXB-K6DNA1A/O(LCLH)
	Outdoor Unit Product Code		CB575W00300
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO.,LTD
	Compressor Model		QXF-A082zC170
	Compressor Oil		ZE-G/E8 RB68GX or equivalent
	Compressor Type		Rotary
	Compressor LRA	A	15.00
	Compressor RLA	A	2.56
	Compressor Power Input	W	756.6
	Compressor Overload Protector		/
	Throttling Method		Capillary
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-25~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7
	Condenser Rows-fin Gap	mm	1~1.2
	Condenser Coil Length (LXD×W)	mm	666×19.05×527
	Fan Motor Speed	rpm	850
	Fan Motor Power Output	W	30
	Fan Motor RLA	A	0.40
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	1950
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ400
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	50
	Sound Power Level	dB (A)	61
	Dimension(WXHXD)	mm	732×555×330
	Dimension of Carton Box (LXWXH)	mm	791×373×590
	Dimension of Package(LXWXH)	mm	794×376×615
	Net Weight	kg	25
	Gross Weight	kg	27.5
	Refrigerant		R32
	Refrigerant Charge	kg	0.53
Connection Pipe	Connection Pipe Length	m	5
	Connection Pipe Gas Additional Charge	g/m	16
	Outer Diameter Liquid Pipe	inch	1/4
	Outer Diameter Gas Pipe	inch	3/8
	Max Distance Height	m	10
	Max Distance Length	m	15
Note: The connection pipe applies metric diameter.			

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			1.GWH09AUCXB-K6DNA1A 2.GWH09AUCXB-K6DNA2A
Product Code			1.CB575000301/CB575000305/CB575000306/CB575000308/CB575000309/ CB575000310/CB575000312 2.CB597000401/CB597000402/CB597000405
Power Supply	Rated Voltage	V~	220-240
	Rated Frequency	Hz	50
	Phases		1
Power Supply Mode			Outdoor
Cooling Capacity		W	2700
Heating Capacity		W	3000
Cooling Power Input		W	870
Heating Power Input		W	680
Cooling Current Input		A	3.1
Heating Current Input		A	3.2
Rated Input		W	1400
Rated Cooling Current		A	8.0
Rated Heating Current		A	6.2
Air Flow Volume		m³/h	610/570/540/470/440/420/390/180
Dehumidifying Volume		L/h	0.80
EER		W/W	4.03
COP		W/W	4.41
SEER			8.5
SCOP(Average/Warmer/Colder)			4.6/5.7/3.5
Application Area		m²	12-18
Indoor Unit	Model		1.GWH09AUCXB-K6DNA1A/I 2.GWH09AUCXB-K6DNA2A/I
	Product Code		1.CB575N00300/CB575N00302/CB575N00306/CB575N00308/ CB575N00309/CB575N00310/CB575N00311 2.CB597N00400/CB597N00402
	Fan Type		Cross-flow
	Fan Diameter Length(DXL)	mm	Φ88×633.5
	Cooling Speed	r/min	1200/1100/1050/950/800/700/650/500
	Heating Speed	r/min	1200/1100/1040/950/900/880/850
	Fan Motor Power Output	W	15
	Fan Motor RLA	A	0.22
	Fan Motor Capacitor	μF	/
	Evaporator Form		Aluminum Fin-copper Tube
	Evaporator Pipe Diameter	mm	Φ5
	Evaporator Row-fin Gap	mm	2-1.4
	Evaporator Coil Length (LXD×W)	mm	635×22.8×306.3
	Swing Motor Model		MP24HF/MP24AK/MP24BA
	Swing Motor Power Output	W	1.5/1.5/1.5
	Fuse Current	A	3.15
	Sound Pressure Level	dB (A)	Cooling:38/37/34/31/26/23/22/19 Heating:39/37/34/31/30/29/28
	Sound Power Level	dB (A)	Cooling:58/51/48/45/40/37/36/33 Heating:58/51/48/45/44/43/42
	Dimension (W×H×D)	mm	837×293×200
	Dimension of Carton Box (L×W×H)	mm	891×357×261
	Dimension of Package (L×W×H)	mm	896×373×272
	Net Weight	kg	9.5
	Gross Weight	kg	11.5

Outdoor Unit	Outdoor Unit Model		GWH09AUCXB-K6DNA1A/O(LC)
	Outdoor Unit Product Code		CB575W00301
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO.,LTD
	Compressor Model		QXF-A082zC170
	Compressor Oil		ZE-G/E8 RB68GX or equivalent
	Compressor Type		Rotary
	Compressor LRA	A	15.00
	Compressor RLA	A	2.56
	Compressor Power Input	W	756.6
	Compressor Overload Protector		/
	Throttling Method		Capillary
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-15~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7
	Condenser Rows-fin Gap	mm	1~1.2
	Condenser Coil Length (LXD×W)	mm	666×19.05×527
	Fan Motor Speed	rpm	850
	Fan Motor Power Output	W	30
	Fan Motor RLA	A	0.40
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	1950
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ400
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	50
	Sound Power Level	dB (A)	61
	Dimension(WXHXD)	mm	732×555×330
	Dimension of Carton Box (LXWXH)	mm	791×373×590
	Dimension of Package(LXWXH)	mm	794×376×615
	Net Weight	kg	25
	Gross Weight	kg	27.5
	Refrigerant		R32
	Refrigerant Charge	kg	0.53
Connection Pipe	Connection Pipe Length	m	5
	Connection Pipe Gas Additional Charge	g/m	16
	Outer Diameter Liquid Pipe	inch	1/4
	Outer Diameter Gas Pipe	inch	3/8
	Max Distance Height	m	10
	Max Distance Length	m	15
	Note: The connection pipe applies metric diameter.		

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			1.GWH12AUCXB-K6DNA1A 2.GWH12AUCXB-K6DNA2A
Product Code			1.CB575000200/CB575000202/CB575000203/CB575000204/CB575000207 2.CB597000100/CB597000102/CB597000103
Power Supply	Rated Voltage	V~	220-240
	Rated Frequency	Hz	50
	Phases		1
Power Supply Mode			Outdoor
Cooling Capacity		W	3510
Heating Capacity		W	3810
Cooling Power Input		W	989
Heating Power Input		W	977
Cooling Current Input		A	4.4
Heating Current Input		A	4.4
Rated Input		W	1650
Rated Cooling Current		A	6.2
Rated Heating Current		A	7.4
Air Flow Volume		m³/h	680/620/560/490/450/420/390/220
Dehumidifying Volume		L/h	1.40
EER		W/W	3.55
COP		W/W	3.90
SEER			7.2
SCOP(Average/Warmer/Colder)			4.1/5.2/3.1
Application Area		m²	16-24
Indoor Unit	Model		1.GWH12AUCXB-K6DNA1A/I 2.GWH12AUCXB-K6DNA2A/I
	Product Code		1.CB575N00200/CB575N00202/CB575N00203/CB575N00204/CB575N00206 2.CB597N00100/CB597N00102/CB597N00103
	Fan Type		Cross-flow
	Fan Diameter Length(DXL)	mm	Φ98×630
	Cooling Speed	r/min	1300/1200/1100/1000/900/800/750/500
	Heating Speed	r/min	1300/1200/1100/1000/900/850/800
	Fan Motor Power Output	W	15
	Fan Motor RLA	A	0.20
	Fan Motor Capacitor	μF	/
	Evaporator Form		Aluminum Fin-copper Tube
	Evaporator Pipe Diameter	mm	Φ6
	Evaporator Row-fin Gap	mm	2-1.4
	Evaporator Coil Length (LXD×W)	mm	634×22.8×304.8
	Swing Motor Model		MP24BA/MP24AK/MP24HF
	Swing Motor Power Output	W	1.5/1.5/1.5
	Fuse Current	A	3.15
	Sound Pressure Level	dB (A)	Cooling:41/38/36/33/30/27/25/19 Heating:41/38/36/33/29/27/26
	Sound Power Level	dB (A)	Cooling:60/52/50/47/44/41/39/33 Heating:55/52/50/47/43/41/40
	Dimension (W×H×D)	mm	637×293×200
	Dimension of Carton Box (L×W×H)	mm	891×357×261
	Dimension of Package (L×W×H)	mm	896×373×272
	Net Weight	kg	9.5
	Gross Weight	kg	11.5

Outdoor Unit	Outdoor Unit Model		GWH12AUCXB-K6DNA1A/O(LCLH)
	Outdoor Unit Product Code		CB575W00200
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO., LTD
	Compressor Model		FT2-AN108ACBD
	Compressor Oil		FW68DA or equivalent
	Compressor Type		Rotary
	Compressor LRA	A	/
	Compressor RLA	A	4.40
	Compressor Power Input	W	/
	Compressor Overload Protector		/
	Throttling Method		Electron expansion valve
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-25~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7.94
	Condenser Rows-fin Gap	mm	1-1.2
	Condenser Coil Length (LXD×W)	mm	666×19.05×527
	Fan Motor Speed	rpm	900
	Fan Motor Power Output	W	30
	Fan Motor RLA	A	0.40
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	1950
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ400
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	52
	Sound Power Level	dB (A)	63
	Dimension(WXHXD)	mm	732×555×330
	Dimension of Carton Box (LXWXH)	mm	791×373×590
	Dimension of Package(LXWXH)	mm	794×376×615
	Net Weight	kg	25.5
	Gross Weight	kg	28
	Refrigerant		R32
	Refrigerant Charge	kg	0.57
Connection Pipe	Connection Pipe Length	m	5
	Connection Pipe Gas Additional Charge	g/m	16
	Outer Diameter Liquid Pipe	inch	1/4
	Outer Diameter Gas Pipe	inch	3/8
	Max Distance Height	m	10
	Max Distance Length	m	15
Note: The connection pipe applies metric diameter.			

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			1.GWH12AUCXB-K6DNA1A 2.GWH12AUCXB-K6DNA2A
Product Code			1.CB575000201/CB575000205/CB575000206/CB575000208/ CB575000209/CB575000210 2.CB597000101
Power Supply	Rated Voltage	V~	220-240
	Rated Frequency	Hz	50
	Phases		1
Power Supply Mode			Outdoor
Cooling Capacity		W	3510
Heating Capacity		W	3810
Cooling Power Input		W	989
Heating Power Input		W	977
Cooling Current Input		A	4.4
Heating Current Input		A	4.4
Rated Input		W	1650
Rated Cooling Current		A	6.2
Rated Heating Current		A	7.4
Air Flow Volume		m³/h	680/620/560/490/450/420/390/220
Dehumidifying Volume		L/h	1.40
EER		W/W	3.55
COP		W/W	3.90
SEER			7.2
SCOP(Average/Warmer/Colder)			4.1/5.2/3.1
Application Area		m²	16-24
Indoor Unit	Model		1.GWH12AUCXB-K6DNA1A/I 2.GWH12AUCXB-K6DNA2A/I
	Product Code		1.CB575N00200/CB575N00202/CB575N00206/CB575N00203/ CB575N00204/CB575N00210 2.CB597N00100
	Fan Type		Cross-flow
	Fan Diameter Length(DXL)	mm	Φ98×630
	Cooling Speed	r/min	1300/1200/1100/1000/900/800/750/500
	Heating Speed	r/min	1300/1200/1100/1000/900/850/800
	Fan Motor Power Output	W	15
	Fan Motor RLA	A	0.20
	Fan Motor Capacitor	μF	/
	Evaporator Form		Aluminum Fin-copper Tube
	Evaporator Pipe Diameter	mm	Φ5
	Evaporator Row-fin Gap	mm	2-1.4
	Evaporator Coil Length (LXD×W)	mm	834×22.8×304.8
	Swing Motor Model		MP24BA/MP24AK/MP24HF
	Swing Motor Power Output	W	1.5/1.5/1.5
	Fuse Current	A	3,15
	Sound Pressure Level	dB (A)	Cooling:41/38/36/33/30/27/25/19 Heating:41/38/36/33/29/27/26
	Sound Power Level	dB (A)	Cooling:60/52/50/47/44/41/39/33 Heating:55/52/50/47/43/41/40
	Dimension (WXHXD)	mm	837×293×200
	Dimension of Carton Box (LXWXH)	mm	891×357×261
	Dimension of Package (LXWXH)	mm	896×373×272
	Net Weight	kg	9.5
	Gross Weight	kg	11.5

Outdoor Unit	Outdoor Unit Model		GWH12AUCXB-K6DNA1A/O(LC)
	Outdoor Unit Product Code		CB575W00201
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO., LTD
	Compressor Model		FT2-AN108ACBD
	Compressor Oil		FW68DA or equivalent
	Compressor Type		Rotary
	Compressor LRA	A	/
	Compressor RLA	A	4.40
	Compressor Power Input	W	/
	Compressor Overload Protector		/
	Throttling Method		Electron expansion valve
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-15~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7.94
	Condenser Rows-fin Gap	mm	1-1.2
	Condenser Coil Length (LXD×W)	mm	666×19.05×527
	Fan Motor Speed	rpm	900
	Fan Motor Power Output	W	30
	Fan Motor RLA	A	0.40
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	1950
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ400
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	52
	Sound Power Level	dB (A)	63
	Dimension(WXHXD)	mm	732×555×330
	Dimension of Carton Box (LXWXH)	mm	791×373×590
	Dimension of Package(LXWXH)	mm	794×376×615
	Net Weight	kg	25.5
	Gross Weight	kg	28
	Refrigerant		R32
	Refrigerant Charge	kg	0.57
Connection Pipe	Connection Pipe Length	m	5
	Connection Pipe Gas Additional Charge	g/m	16
	Outer Diameter Liquid Pipe	inch	1/4
	Outer Diameter Gas Pipe	inch	3/8
	Max Distance Height	m	10
	Max Distance Length	m	15
Note: The connection pipe applies metric diameter.			

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			1.GWH12AUCXD-K6DNA1C 2.GWH12AUCXD-K6DNA2C
Product Code			1.CB575000700/CB575000705/CB575000704 2.CB597000602
Power Supply	Rated Voltage	V~	220-240
	Rated Frequency	Hz	50
	Phases		1
Power Supply Mode			Outdoor
Cooling Capacity		W	3510
Heating Capacity		W	3810
Cooling Power Input		W	877
Heating Power Input		W	952
Cooling Current Input		A	4.1
Heating Current Input		A	4.5
Rated Input		W	1800
Rated Cooling Current		A	6.5
Rated Heating Current		A	8.0
Air Flow Volume		m³/h	720/600/570/530/500/460/430
Dehumidifying Volume		L/h	1.40
EER		W/W	4.00
COP		W/W	4.00
SEER			8.5
SCOP(Average/Warmer/Colder)			4.6/5.6/3.6
Application Area		m²	16-24
Indoor Unit	Model		1.GWH12AUCXD-K6DNA1C/I 2.GWH12AUCXD-K6DNA2C/I
	Product Code		1.CB575N00700/CB575N00705/CB575N00704 2.CB597N00602
	Fan Type		Cross-flow
	Fan Diameter/Length(DXL)	mm	Φ98×630
	Cooling Speed	r/min	1400/1200/1120/1050/980/920/750/500
	Heating Speed	r/min	1400/1200/1140/1080/1020/960/900
	Fan Motor Power Output	W	15
	Fan Motor RLA	A	0.2
	Fan Motor Capacitor	μF	/
	Evaporator Form		Aluminum Fin-copper Tube
	Evaporator Pipe Diameter	mm	Φ6
	Evaporator Row-fin Gap	mm	2-1.4
	Evaporator Coil Length (LXD×WH)	mm	634×22.8×304.8
	Swing Motor Model		MP24BA/MP24AK/MP24HF
	Swing Motor Power Output	W	1.5/1.5/1.5
	Fuse Current	A	3.15
	Sound Pressure Level	dB (A)	Cooling:43/39/37/35/32/30/24/19 Heating:44/39/37/35/33/31/29
	Sound Power Level	dB (A)	Cooling:60/53/51/49/46/44/38/33 Heating:60/53/51/49/47/45/43
	Dimension (W×H×D)	mm	837×293×200
	Dimension of Carton Box (L×W×H)	mm	891×357×261
	Dimension of Package (L×W×H)	mm	896×373×272
	Net Weight	kg	9.5
	Gross Weight	kg	11.5

Outdoor Unit	Outdoor Unit Model		GWH12AUCXD-K6DNA1C/O(LCLH)
	Outdoor Unit Product Code		CB575W00700
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO., LTD
	Compressor Model		QXF-A098zE170
	Compressor Oil		ZE-GLES R68GX or equivalent
	Compressor Type		Rotary
	Compressor LRA	A	/
	Compressor RLA	A	3.9
	Compressor Power Input	W	/
	Compressor Overload Protector		/
	Throttling Method		Electron expansion valve
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-25~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7
	Condenser Rows-fin Gap	mm	2~1.4
	Condenser Coil Length (L×D×W)	mm	761.5×36.1×528
	Fan Motor Speed	rpm	850
	Fan Motor Power Output	W	30
	Fan Motor RLA	A	0.4
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	2200
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ420
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	53
	Sound Power Level	dB (A)	64
	Dimension(W×H×D)	mm	802×555×350
	Dimension of Carton Box (L×W×H)	mm	869×395×594
	Dimension of Package(L×W×H)	mm	872×398×620
	Net Weight	kg	30
	Gross Weight	kg	32.5
	Refrigerant		R32
	Refrigerant Charge	kg	0.8
Connection Pipe	Connection Pipe Length	m	5
	Connection Pipe Gas Additional Charge	g/m	16
	Outer Diameter Liquid Pipe	inch	1/4
	Outer Diameter Gas Pipe	inch	3/8
	Max Distance Height	m	10
	Max Distance Length	m	20
Note: The connection pipe applies metric diameter.			

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			1.GWH12AUCXD-K6DNA1C 2.GWH12AUCXD-K6DNA2C
Product Code			1.CB575000701/CB575000702/CB575000703 2.CB597000601/CB597000603
Power Supply	Rated Voltage	V~	220-240
	Rated Frequency	Hz	50
	Phases		1
Power Supply Mode			Outdoor
Cooling Capacity		W	3510
Heating Capacity		W	3810
Cooling Power Input		W	877
Heating Power Input		W	952
Cooling Current Input		A	4.1
Heating Current Input		A	4.5
Rated Input		W	1800
Rated Cooling Current		A	6.5
Rated Heating Current		A	8.0
Air Flow Volume		m³/h	720/800/570/530/500/460/430/320
Dehumidifying Volume		L/h	1.40
EER		W/W	4.00
COP		W/W	4.00
SEER			8.5
SCOP(Average/Warmer/Colder)			4.6/5.6/3.6
Application Area		m²	16-24
Indoor Unit	Model		1.GWH12AUCXD-K6DNA1C/I 2.GWH12AUCXD-K6DNA2C/I
	Product Code		1.CB575N00700/CB575N00702/CB575N00703 2.CB597N00600/CB597N00603
	Fan Type		Cross-flow
	Fan Diameter/Length(DXL)	mm	Φ98×630
	Cooling Speed	r/min	1400/1200/1120/1050/980/920/750/500
	Heating Speed	r/min	1400/1200/1140/1080/1020/960/900
	Fan Motor Power Output	W	15
	Fan Motor RLA	A	0.2
	Fan Motor Capacitor	μF	/
	Evaporator Form		Aluminum Fin-copper Tube
	Evaporator Pipe Diameter	mm	Φ6
	Evaporator Row-fin Gap	mm	2-1.4
	Evaporator Coil Length (LXD×WH)	mm	634×22.8×304.8
	Swing Motor Model		MP24BA/MP24AK/MP24HF
	Swing Motor Power Output	W	1.5/1.5/1.5
	Fuse Current	A	3.15
	Sound Pressure Level	dB (A)	Cooling:43/39/37/35/32/30/24/19 Heating:44/39/37/35/33/31/29
	Sound Power Level	dB (A)	Cooling:60/53/51/49/46/44/38/33 Heating:60/53/51/49/47/45/43
	Dimension (W×H×D)	mm	837×293×200
	Dimension of Carton Box (L×W×H)	mm	891×357×261
	Dimension of Package (L×W×H)	mm	896×373×272
	Net Weight	kg	9.5
	Gross Weight	kg	11.5

Outdoor Unit	Outdoor Unit Model		GWH12AUCXD-K6DNA1C/O(LC)
	Outdoor Unit Product Code		CB575W00701
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO., LTD
	Compressor Model		QXF-A098zE170
	Compressor Oil		ZE-GLES R68GX or equivalent
	Compressor Type		Rotary
	Compressor LRA	A	/
	Compressor RLA	A	3.9
	Compressor Power Input	W	/
	Compressor Overload Protector		/
	Throttling Method		Electron expansion valve
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-15~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7
	Condenser Rows-fin Gap	mm	2~1.4
	Condenser Coil Length (LXD×W)	mm	761.5×36.1×528
	Fan Motor Speed	rpm	850
	Fan Motor Power Output	W	30
	Fan Motor RLA	A	0.4
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	2200
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ420
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	53
	Sound Power Level	dB (A)	64
	Dimension(WXHXD)	mm	802×555×350
	Dimension of Carton Box (LXWXH)	mm	889×395×594
	Dimension of Package(LXWXH)	mm	872×398×620
	Net Weight	kg	30
	Gross Weight	kg	32.5
	Refrigerant		R32
	Refrigerant Charge	kg	0.8
Connection Pipe	Connection Pipe Length	m	5
	Connection Pipe Gas Additional Charge	g/m	16
	Outer Diameter Liquid Pipe	inch	1/4
	Outer Diameter Gas Pipe	inch	3/8
	Max Distance Height	m	10
	Max Distance Length	m	20
	Note: The connection pipe applies metric diameter.		

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			1.GWH18AUDXD-K6DNA1A 2.GWH18AUDXD-K6DNA2A
Product Code			1.CB575000100/CB575000102/CB575000103/CB575000104/CB575000107 2.CB597000200/CB597000204/CB597000203
Power Supply	Rated Voltage	V~	220-240
	Rated Frequency	Hz	50
	Phases		1
Power Supply Mode			Outdoor
Cooling Capacity		W	5300
Heating Capacity		W	5350
Cooling Power Input		W	1582
Heating Power Input		W	1393
Cooling Current Input		A	7.2
Heating Current Input		A	6.3
Rated Input		W	2350
Rated Cooling Current		A	10
Rated Heating Current		A	10.5
Air Flow Volume		m³/h	1000/850/760/650/580/520/450
Dehumidifying Volume		L/h	1.90
EER		W/W	3.35
COP		W/W	3.84
SEER			7.3
SCOP(Average/Warmer/Colder)			4.2/5.7/3.5
Application Area		m²	23-34
Indoor Unit	Model		1.GWH18AUDXD-K6DNA1A/I 2.GWH18AUDXD-K6DNA2A/I
	Product Code		1.CB575N00100/CB575N00102/CB575N00103/CB575N00104/CB575N00105 2.CB597N00200/CB597N00204/CB597N00203
	Fan Type		Cross-flow
	Fan Diameter Length(DXL)	mm	Φ106×739
	Cooling Speed	r/min	1250/1150/1030/960/800/700/650/500
	Heating Speed	r/min	1300/1150/1040/950/900/880/800
	Fan Motor Power Output	W	45
	Fan Motor RLA	A	0.25
	Fan Motor Capacitor	μF	1
	Evaporator Form		Aluminum Fin-copper Tube
	Evaporator Pipe Diameter	mm	Φ5
	Evaporator Row-fin Gap	mm	2-1.3
	Evaporator Coil Length (LXD×W)	mm	745×22.8×342.9
	Swing Motor Model		MP24AK/MP24BA/MP24HF
	Swing Motor Power Output	W	1.5/1.5 /1.5
	Fuse Current	A	3.15
	Sound Pressure Level	dB (A)	Cooling:45/42/40/37/34/29/26/23 Heating:48/44/42/37/36/35/32
	Sound Power Level	dB (A)	Cooling:60/55/53/50/47/42/39/36 Heating:60/57/55/50/49/48/45
	Dimension (W×H×D)	mm	993×311×222
	Dimension of Carton Box (L×W×H)	mm	1050×377×288
	Dimension of Package (L×W×H)	mm	1055×385×298
	Net Weight	kg	12.5
	Gross Weight	kg	15

Outdoor Unit	Outdoor Unit Model		GWH18AUDXD-K6DNA1A/O(LCLH)
	Outdoor Unit Product Code		CB575W00100
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO.,LTD
	Compressor Model		QXF-A120ZH170A
	Compressor Oil		FW68DA or equivalent
	Compressor Type		Rotary
	Compressor LRA	A	18.00
	Compressor RLA	A	5.00
	Compressor Power Input	W	1096
	Compressor Overload Protector		HPC115/95U1/KSD115°C
	Throttling Method		Electron expansion valve
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-25~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7
	Condenser Rows-fin Gap	mm	2-1.4
	Condenser Coil Length (LXD×W)	mm	895×28.1×528
	Fan Motor Speed	rpm	880
	Fan Motor Power Output	W	30
	Fan Motor RLA	A	0.40
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	2200
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ420
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	56
	Sound Power Level	dB (A)	65
	Dimension(W×H×D)	mm	802×555×350
	Dimension of Carton Box (L×W×H)	mm	869×395×594
	Dimension of Package(L×W×H)	mm	872×398×620
	Net Weight	kg	31.5
	Gross Weight	kg	34
	Refrigerant		R32
	Refrigerant Charge	kg	0.85
Connection Pipe	Connection Pipe Length	m	5
	Connection Pipe Gas Additional Charge	g/m	18
	Outer Diameter Liquid Pipe	inch	1/4
	Outer Diameter Gas Pipe	inch	1/2
	Max Distance Height	m	10
	Max Distance Length	m	25
Note: The connection pipe applies metric diameter.			

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			1.GWH18AUDXD-K6DNA1A 2.GWH18AUDXD-K6DNA2A
Product Code			1.CB575000101/CB575000105/CB575000106/CB575000108/ CB575000109/CB575000110 2.CB597000202
Power Supply	Rated Voltage	V~	220-240
	Rated Frequency	Hz	50
	Phases		1
Power Supply Mode			Outdoor
Cooling Capacity	W		5300
Heating Capacity	W		5350
Cooling Power Input	W		1682
Heating Power Input	W		1393
Cooling Current Input	A		7.2
Heating Current Input	A		6.3
Rated Input	W		2350
Rated Cooling Current	A		10
Rated Heating Current	A		10.5
Air Flow Volume	m³/h		1000/850/760/650/580/520/450
Dehumidifying Volume	L/h		1.90
EER	W/W		3.35
COP	W/W		3.84
SEER			7.3
SCOP(Average/Warmer/Colder)			4.2/5.7/3.5
Application Area	m²		23-34
Indoor Unit	Model		1.GWH18AUDXD-K6DNA1A/I 2.GWH18AUDXD-K6DNA2A/I
	Product Code		1.CB575N00100/CB575N00102/CB575N00105/CB575N00104/ CB575N00103/CB575N00110 2.CB597N00200
	Fan Type		Cross-flow
	Fan Diameter Length(DXL)	mm	Φ106×739
	Cooling Speed	r/min	1250/1150/1030/980/800/700/650/500
	Heating Speed	r/min	1300/1150/1040/950/900/880/800
	Fan Motor Power Output	W	45
	Fan Motor RLA	A	0.25
	Fan Motor Capacitor	μF	/
	Evaporator Form		Aluminum Fin-copper Tube
	Evaporator Pipe Diameter	mm	Φ5
	Evaporator Row-fin Gap	mm	2-1.3
	Evaporator Coil Length (LXD×W)	mm	745×22.8×342.9
	Swing Motor Model		MP24AK/MP24BA/MP24HF
	Swing Motor Power Output	W	1.5/1.5 /1.5
	Fuse Current	A	3.15
	Sound Pressure Level	dB (A)	Cooling:45/42/40/37/34/29/26/23 Heating:48/44/42/37/36/35/32
	Sound Power Level	dB (A)	Cooling:60/55/53/50/47/42/39/36 Heating:60/57/55/50/49/48/45
	Dimension (W×H×D)	mm	993×311×222
	Dimension of Carton Box (L×W×H)	mm	1050×377×288
	Dimension of Package (L×W×H)	mm	1055×385×298
	Net Weight	kg	12.5
	Gross Weight	kg	15

Outdoor Unit	Outdoor Unit Model		GWH18AUDXD-K6DNA1A/O(LC)
	Outdoor Unit Product Code		C8575W00101
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO.,LTD
	Compressor Model		QXF-A120ZH170A
	Compressor Oil		FW68DA or equivalent
	Compressor Type		Rotary
	Compressor LRA	A	18.00
	Compressor RLA	A	5.00
	Compressor Power Input	W	1096
	Compressor Overload Protector		HPC115/95U1/KSD115°C
	Throttling Method		Electron expansion valve
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-15~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7
	Condenser Rows-fin Gap	mm	2-1.4
	Condenser Coil Length (L×D×W)	mm	895×38.1×528
	Fan Motor Speed	rpm	880
	Fan Motor Power Output	W	30
	Fan Motor RLA	A	0.40
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	2200
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ420
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	56
	Sound Power Level	dB (A)	65
	Dimension(W×H×D)	mm	802×555×350
	Dimension of Carton Box (L×W×H)	mm	869×395×594
	Dimension of Package(L×W×H)	mm	872×398×620
	Net Weight	kg	31.5
	Gross Weight	kg	34
	Refrigerant		R32
	Refrigerant Charge	kg	0.85
Connection Pipe	Connection Pipe Length	m	5
	Connection Pipe Gas Additional Charge	g/m	18
	Outer Diameter Liquid Pipe	inch	1/4
	Outer Diameter Gas Pipe	inch	1/2
	Max Distance Height	m	10
	Max Distance Length	m	25
Note: The connection pipe applies metric diameter.			

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			1.GWH18AUDXE-K6DNA1A 2.GWH18AUDXE-K6DNA2A
Product Code			1.CB575000900/CB575000905/CB575000906 2.CB597000702
Power Supply	Rated Voltage	V~	220-240
	Rated Frequency	Hz	50
	Phases		1
Power Supply Mode			Outdoor
Cooling Capacity		W	5300
Heating Capacity		W	5600
Cooling Power Input		W	1472
Heating Power Input		W	1365
Cooling Current Input		A	6.6
Heating Current Input		A	6.2
Rated Input		W	2300
Rated Cooling Current		A	11.5
Rated Heating Current		A	11.5
Air Flow Volume		m ³ /h	1000/880/760/650/620/600/550
Dehumidifying Volume		L/h	1.8
EER		W/W	3.6
COP		W/W	4.1
SEER			8
SCOP(Average/Warmer/Colder)			4.6/5.8/3.6
Application Area		m ²	23-34
Indoor Unit	Model		1.GWH18AUDXE-K6DNA1A/I 2.GWH18AUDXE-K6DNA2A/I
	Product Code		1.CB575N00900/CB575N00905/CB575N00906 2.CB597N00702
	Fan Type		Cross-flow
	Fan Diameter Length(DXL)	mm	Φ106×739
	Cooling Speed	r/min	1250/1150/1030/960/800/700/650/500
	Heating Speed	r/min	1300/1150/1040/950/900/880/800
	Fan Motor Power Output	W	45
	Fan Motor RLA	A	0.25
	Fan Motor Capacitor	μF	/
	Evaporator Form		Aluminum Fin-copper Tube
	Evaporator Pipe Diameter	mm	Φ5
	Evaporator Row-fin Gap	mm	2-1.3
	Evaporator Coil Length (LXD×W)	mm	745×22.8×342.9
	Swing Motor Model		MP24AK/MP24BA/MP24HF
	Swing Motor Power Output	W	1.5/1.5 /1.5
	Fuse Current	A	3.15
	Sound Pressure Level	dB (A)	Cooling:45/42/40/37/34/29/26/23 Heating:48/44/42/38/36/35/32
	Sound Power Level	dB (A)	Cooling:60/57/55/52/49/44/41/38 Heating:60/56/54/50/48/47/44
	Dimension (W×H×D)	mm	993×311×222
	Dimension of Carton Box (L×W×H)	mm	1050×377×268
	Dimension of Package (L×W×H)	mm	1055×385×298
	Net Weight	kg	13
	Gross Weight	kg	15.5

Outdoor Unit	Outdoor Unit Model		GW/H18AUDXE-K6DNA1A/O(LCLH)
	Outdoor Unit Product Code		C8575W00900
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO.,LTD
	Compressor Model		QXF-M130zF170
	Compressor Oil		FW68DA or equivalent
	Compressor Type		Rotary
	Compressor LRA	A	/
	Compressor RLA	A	/
	Compressor Power Input	W	1196
	Compressor Overload Protector		/
	Throttling Method		Electron expansion valve
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-25~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7.94
	Condenser Rows-fin Gap	mm	2-1.4
	Condenser Coil Length (L×D×W)	mm	833×381×528
	Fan Motor Speed	rpm	970
	Fan Motor Power Output	W	40
	Fan Motor RLA	A	0.7
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	3000
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ445
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	59
	Sound Power Level	dB (A)	65
	Dimension(W×H×D)	mm	873×555×376
	Dimension of Carton Box (L×W×H)	mm	948×428×591
	Dimension of Package(L×W×H)	mm	951×431×620
	Net Weight	kg	37
	Gross Weight	kg	40
	Refrigerant		R32
	Refrigerant Charge	kg	0.95
Connection Pipe	Connection Pipe Length	m	5
	Connection Pipe Gas Additional Charge	g/m	18
	Outer Diameter Liquid Pipe	inch	1/4
	Outer Diameter Gas Pipe	inch	1/2
	Max Distance Height	m	10
	Max Distance Length	m	25
Note: The connection pipe applies metric diameter.			

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			1.GWH18AUDXE-K6DNA1A 2.GWH18AUDXE-K6DNA2A
Product Code			1.CB575000901/CB575000902/CB575000903 2.CB597000701/CB597000703
Power Supply	Rated Voltage	V~	220-240
	Rated Frequency	Hz	50
	Phases		1
Power Supply Mode			Outdoor
Cooling Capacity		W	5300
Heating Capacity		W	5600
Cooling Power Input		W	1472
Heating Power Input		W	1365
Cooling Current Input		A	6.6
Heating Current Input		A	6.2
Rated Input		W	2300
Rated Cooling Current		A	11.5
Rated Heating Current		A	11.5
Air Flow Volume		m ³ /h	1000/880/760/650/620/600/550
Dehumidifying Volume		L/h	1.8
EER		W/W	3.6
COP		W/W	4.1
SEER			8
SCOP(Average/Warmer/Colder)			4.6/5.8/3.6
Application Area		m ²	23-34
Indoor Unit	Model		1.GWH18AUDXE-K6DNA1A/I 2.GWH18AUDXE-K6DNA2A/I
	Product Code		1.CB575N00900/CB575N00902/CB575N00903 2.CB597N00700/CB597N00703
	Fan Type		Cross-flow
	Fan Diameter Length(DXL)	mm	Φ106×739
	Cooling Speed	r/min	1250/1150/1030/960/800/700/650/500
	Heating Speed	r/min	1300/1150/1040/950/900/880/800
	Fan Motor Power Output	W	45
	Fan Motor RLA	A	0.25
	Fan Motor Capacitor	μF	/
	Evaporator Form		Aluminum Fin-copper Tube
	Evaporator Pipe Diameter	mm	Φ5
	Evaporator Row-fin Gap	mm	2-1.3
	Evaporator Coil Length (LXD×W)	mm	745×22.8×342.9
	Swing Motor Model		MP24AK/MP24BA/MP24HF
	Swing Motor Power Output	W	1.5/1.5 /1.5
	Fuse Current	A	3.15
	Sound Pressure Level	dB (A)	Cooling:45/42/40/37/34/29/26/23 Heating:48/44/42/38/36/35/32
	Sound Power Level	dB (A)	Cooling:60/57/55/52/49/44/41/38 Heating:60/56/54/50/48/47/44
	Dimension (W×H×D)	mm	993×311×222
	Dimension of Carton Box (L×W×H)	mm	1050×377×268
	Dimension of Package (L×W×H)	mm	1055×385×298
	Net Weight	kg	13
	Gross Weight	kg	15.5

Outdoor Unit	Outdoor Unit Model		GWH18AUDXE-K6DNA1A/O(LC)
	Outdoor Unit Product Code		CB575W00901
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO.,LTD
	Compressor Model		QXF-M130ZF170
	Compressor Oil		FW68DA or equivalent
	Compressor Type		Rotary
	Compressor LRA	A	/
	Compressor RLA	A	/
	Compressor Power Input	W	1196
	Compressor Overload Protector		/
	Throttling Method		Electron expansion valve
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-15~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7.94
	Condenser Rows-fin Gap	mm	2-1.4
	Condenser Coil Length (LXDXW)	mm	833×38.1×528
	Fan Motor Speed	rpm	970
	Fan Motor Power Output	W	40
	Fan Motor RLA	A	0.7
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	3000
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ445
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	59
	Sound Power Level	dB (A)	65
	Dimension(WXHXD)	mm	873×555×376
	Dimension of Carton Box (LXWXH)	mm	948×428×591
	Dimension of Package(LXWXH)	mm	951×431×820
	Net Weight	kg	37
	Gross Weight	kg	40
	Refrigerant		R32
	Refrigerant Charge	kg	0.95
Connection Pipe	Connection Pipe Length	m	5
	Connection Pipe Gas Additional Charge	g/m	18
	Outer Diameter Liquid Pipe	inch	1/4
	Outer Diameter Gas Pipe	inch	1/2
	Max Distance Height	m	10
	Max Distance Length	m	25
Note: The connection pipe applies metric diameter.			

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			1.GWH18AUDXE-K6DNA1B
Product Code			1.CB575001100/CB575001101/CB575001102
Power Supply	Rated Voltage	V~	220-240
	Rated Frequency	Hz	50
	Phases		1
Power Supply Mode			Outdoor
Cooling Capacity		W	5100
Heating Capacity		W	5800
Cooling Power Input		W	1417
Heating Power Input		W	1365
Cooling Current Input		A	8.4
Heating Current Input		A	8.2
Rated Input		W	2300
Rated Cooling Current		A	11.5
Rated Heating Current		A	11.5
Air Flow Volume		m³/h	1000/880/760/650/620/600/550
Dehumidifying Volume		L/h	1.8
EER		W/W	3.6
COP		W/W	4.1
SEER			8.5
SCOP(Average/Warmer/Colder)			4.8/5.8/3.6
Application Area		m²	23-34
Indoor Unit	Model		1.GWH18AUDXE-K6DNA1B/I
	Product Code		1.CB575N01100/CB575N01101/CB575N01102
	Fan Type		Cross-flow
	Fan Diameter Length(DXL)	mm	Φ106×739
	Cooling Speed	r/min	1250/1150/1030/960/800/700/650/500
	Heating Speed	r/min	1300/1150/1040/950/900/880/800
	Fan Motor Power Output	W	45
	Fan Motor RLA	A	0.25
	Fan Motor Capacitor	μF	/
	Evaporator Form		Aluminum Fin-copper Tube
	Evaporator Pipe Diameter	mm	Φ6
	Evaporator Row-fin Gap	mm	2-1.3
	Evaporator Coil Length (LXDXW)	mm	745×22.8×342.9
	Swing Motor Model		MP24AK/MP24BA/MP24HF
	Swing Motor Power Output	W	1.5/1.5 /1.5
	Fuse Current	A	3.15
	Sound Pressure Level	dB (A)	Cooling:45/42/40/37/34/29/26/23 Heating:48/44/42/38/36/35/32
	Sound Power Level	dB (A)	Cooling:60/57/55/52/49/44/41/38 Heating:60/56/54/50/48/47/44
	Dimension (W×H×D)	mm	993×311×222
	Dimension of Carton Box (L×W×H)	mm	1050×377×288
	Dimension of Package (L×W×H)	mm	1055×385×298
	Net Weight	kg	13
	Gross Weight	kg	15.5

Outdoor Unit	Outdoor Unit Model		GWH18AUDXE-K8DNA1B/O(LCLH)
	Outdoor Unit Product Code		CB575W01100
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO.,LTD
	Compressor Model		QXF-M130zF170
	Compressor Oil		FW68DA or equivalent
	Compressor Type		Rotary
	Compressor LRA	A	/
	Compressor RLA	A	/
	Compressor Power Input	W	1196
	Compressor Overload Protector		/
	Throttling Method		Electron expansion valve
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-25~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7.94
	Condenser Rows-fin Gap	mm	2-1.4
	Condenser Coil Length (LXD×W)	mm	833×38.1×528
	Fan Motor Speed	rpm	970
	Fan Motor Power Output	W	40
	Fan Motor RLA	A	0.7
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	3000
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ445
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	59
	Sound Power Level	dB (A)	65
	Dimension(W×H×D)	mm	873×555×376
	Dimension of Carton Box (L×W×H)	mm	948×428×591
	Dimension of Package(L×W×H)	mm	951×431×620
	Net Weight	kg	37
	Gross Weight	kg	40
	Refrigerant		R32
	Refrigerant Charge	kg	0.95
Connection Pipe	Connection Pipe Length	m	5
	Connection Pipe Gas Additional Charge	g/m	16
	Outer Diameter Liquid Pipe	Inch	1/4
	Outer Diameter Gas Pipe	Inch	1/2
	Max Distance Height	m	10
	Max Distance Length	m	25
Note: The connection pipe applies metric diameter.			

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			GWH18AUDXE-K6DNA2C
Product Code			CB597000800
Power Supply	Rated Voltage	V~	220-240
	Rated Frequency	Hz	50
	Phases		1
Power Supply Mode			Outdoor
Cooling Capacity		W	5300
Heating Capacity		W	5600
Cooling Power Input		W	1472
Heating Power Input		W	1365
Cooling Current Input		A	6.6
Heating Current Input		A	6.2
Rated Input		W	2300
Rated Cooling Current		A	11.5
Rated Heating Current		A	11.5
Air Flow Volume		m³/h	1000/880/760/650/620/600/550
Dehumidifying Volume		L/h	1.80
EER		W/W	3.6
COP		W/W	4.1
SEER			8.1
SCOP(Average/Warmer/Colder)			4.6/5.8/3.8
Application Area		m²	23-34
Indoor Unit	Model		GWH18AUDXE-K6DNA2C/I
	Product Code		CB597N00800
	Fan Type		Cross-flow
	Fan Diameter Length(DXL)	mm	Φ106×739
	Cooling Speed	r/min	1250/1150/1030/960/800/700/650/500
	Heating Speed	r/min	1300/1150/1040/950/900/880/800
	Fan Motor Power Output	W	45
	Fan Motor RLA	A	0.25
	Fan Motor Capacitor	μF	/
	Evaporator Form		Aluminum Fin-copper Tube
	Evaporator Pipe Diameter	mm	Φ5
	Evaporator Row-fin Gap	mm	2-1.3
	Evaporator Coil Length (LXD×W)	mm	745×22.8×342.9
	Swing Motor Model		MP24AK/MP24BA/MP24HF
	Swing Motor Power Output	W	1.5/1.5 /1.5
	Fuse Current	A	3.15
	Sound Pressure Level	dB (A)	Cooling:45/42/40/37/34/29/26/23 Heating:48/44/42/38/36/35/32
	Sound Power Level	dB (A)	Cooling:60/57/45/52/49/44/41/38 Heating:60/56/54/50/48/47/44
	Dimension (WXHXD)	mm	993X311X222
	Dimension of Carton Box (LXWXH)	mm	1050X377X288
	Dimension of Package (LXWXH)	mm	1055X385X298
	Net Weight	kg	13
	Gross Weight	kg	15.5

Outdoor Unit	Outdoor Unit Model		GWH18AUDXE-K6DNA2C/O
	Outdoor Unit Product Code		C8597W00800
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO., LTD.
	Compressor Model		QXF-M130zF170
	Compressor Oil		FW68DA or equivalent
	Compressor Type		Rotary
	Compressor LRA	A	/
	Compressor RLA	A	/
	Compressor Power Input	W	1196
	Compressor Overload Protector		/
	Throttling Method		Electron expansion valve
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-25~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7.94
	Condenser Rows-fin Gap	mm	2~1.4
	Condenser Coil Length (LXDXW)	mm	833×38.1×528
	Fan Motor Speed	rpm	970
	Fan Motor Power Output	W	40
	Fan Motor RLA	A	0.7
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	3000
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ445
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	59
	Sound Power Level	dB (A)	65
	Dimension(WXHXD)	mm	873X561X376
	Dimension of Carton Box (LXWXH)	mm	948X428X591
	Dimension of Package(LXWXH)	mm	951X431X620
	Net Weight	kg	37
	Gross Weight	kg	40
	Refrigerant		R32
	Refrigerant Charge	kg	0.95
Connection Pipe	Connection Pipe Length	m	5
	Connection Pipe Gas Additional Charge	g/m	16
	Outer Diameter Liquid Pipe	inch	1/4
	Outer Diameter Gas Pipe	inch	1/2
	Max Distance Height	m	10
	Max Distance Length	m	25
Note: The connection pipe applies metric diameter.			

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			1.GWH24AUDXF-K6DNA1A 2.GWH24AUDXF-K6DNA2A
Product Code			1.CB437004700/CB437004702/CB437004703/CB437004704/CB437004707/ CB437004712/CB437004713/CB437004714 2.CB597000300/CB597000303/CB597000304/CB597000306
Power Supply	Rated Voltage	V~	220-240
	Rated Frequency	Hz	50
	Phases		1
Power Supply Mode			Outdoor
Cooling Capacity		W	7100
Heating Capacity		W	7300
Cooling Power Input		W	2030
Heating Power Input		W	1870
Cooling Current Input		A	9
Heating Current Input		A	9.3
Rated Input		W	3500
Rated Cooling Current		A	13
Rated Heating Current		A	14
Air Flow Volume		m³/h	1000/850/760/580/520/450/400/280
Dehumidifying Volume		L/h	2.40
EER		W/W	3.51
COP		W/W	3.90
SEER			7
SCOP(Average/Warmer/Colder)			4.30/5.50/3.40
Application Area		m²	27-42
Indoor Unit	Model		1.GWH24AUDXF-K6DNA1A/I 2.GWH24AUDXF-K6DNA2A/I
	Product Code		1.CB437N04700/CB437N04702/CB437N04703/CB437N04704/CB437N04706/ CB437N04711/CB437N04713/CB437N04714 2.CB597N00300/CB597N00302/CB597N00304/CB597N00306
	Fan Type		Cross-flow
	Fan Diameter Length(DXL)	mm	Φ106×739
	Cooling Speed	r/min	1400/1200/1120/1050/980/860/750/550
	Heating Speed	r/min	1400/1200/1120/1050/950/850/750
	Fan Motor Power Output	W	45
	Fan Motor RLA	A	0.25
	Fan Motor Capacitor	μF	/
	Evaporator Form		Aluminum Fin-copper Tube
	Evaporator Pipe Diameter	mm	Φ7
	Evaporator Row-fin Gap	mm	2-1.4
	Evaporator Coil Length (LXD×W)	mm	745×22.8×342.9
	Swing Motor Model		MP24AK/MP24HF/MP24BA
	Swing Motor Power Output	W	1.5/1.5/1.5
	Fuse Current	A	3.15
	Sound Pressure Level	dB (A)	Cooling:48/44/41/40/38/36/33/27 Heating:50/47/43/41/40/38/35
	Sound Power Level	dB (A)	Cooling:65/59/56/55/53/51/48/42 Heating:64/62/58/56/55/51/50
	Dimension (WXHXD)	mm	993×311×222
	Dimension of Carton Box (LXWXH)	mm	1050×377×266
	Dimension of Package (LXWXH)	mm	1055×385×298
	Net Weight	kg	13
	Gross Weight	kg	15.5

Outdoor Unit	Outdoor Unit Model		GWH24AUDXF-K6DNA1A/O(LCLH)
	Outdoor Unit Product Code		GB437W04700
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO.,LTD
	Compressor Model		QXFS-M180zX170
	Compressor Oil		/
	Compressor Type		Rotary
	Compressor LRA	A	24.00
	Compressor RLA	A	3.50
	Compressor Power Input	W	1350
	Compressor Overload Protector		HPC 115/95U1 KSD115°C
	Throttling Method		Electron expansion valve
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-25~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7.94
	Condenser Rows-fin Gap	mm	2-1.4
	Condenser Coil Length (LXD×W)	mm	934×38.1×616
	Fan Motor Speed	rpm	600
	Fan Motor Power Output	W	60
	Fan Motor RLA	A	0.65
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	3600
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ520
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	59
	Sound Power Level	dB (A)	70
	Dimension(WXHXD)	mm	958×660×402
	Dimension of Carton Box (LXWXH)	mm	1029×453×715
	Dimension of Package(LXWXH)	mm	1032×456×737
	Net Weight	kg	45
	Gross Weight	kg	49.5
	Refrigerant		R32
	Refrigerant Charge	kg	1.4
Connection Pipe	Connection Pipe Length	m	6
	Connection Pipe Gas Additional Charge	g/m	40
	Outer Diameter Liquid Pipe	inch	1/4
	Outer Diameter Gas Pipe	inch	5/8
	Max Distance Height	m	10
	Max Distance Length	m	25
	Note: The connection pipe applies metric diameter.		

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			1.GWH24AUDXF-K6DNA1A 2.GWH24AUDXF-K6DNA2A
Product Code			1.CB437004701/CB437004705/CB437004706/CB437004708/ CB437004709/CB437004710/CB437004711 2.CB597000301/CB597000302/CB597000305
Power Supply	Rated Voltage	V~	220-240
	Rated Frequency	Hz	50
	Phases		1
Power Supply Mode			Outdoor
Cooling Capacity		W	7100
Heating Capacity		W	7300
Cooling Power Input		W	2030
Heating Power Input		W	1870
Cooling Current Input		A	8
Heating Current Input		A	9.3
Rated Input		W	3500
Rated Cooling Current		A	13
Rated Heating Current		A	14
Air Flow Volume		m³/h	1000/850/760/580/520/450/400/280
Dehumidifying Volume		L/h	2.40
EER		W/W	3.51
COP		W/W	3.90
SEER			7
SCOP(Average/Warmer/Colder)			4.30/5.50/3.40
Application Area		m²	27-42
Indoor Unit	Model		1.GWH24AUDXF-K6DNA1A/I 2.GWH24AUDXF-K6DNA2A/I
	Product Code		1.CB437N04700/CB437N04702/CB437N04706/CB437N04704/ CB437N04703/CB437N04710/CB437N04711 2.CB597N00300/CB597N00302/CB597N00305
	Fan Type		Cross-flow
	Fan Diameter Length(DXL)	mm	Φ106×729
	Cooling Speed	r/min	1400/1200/1120/1050/980/860/750/550
	Heating Speed	r/min	1400/1200/1120/1050/950/850/750
	Fan Motor Power Output	W	45
	Fan Motor RLA	A	0.25
	Fan Motor Capacitor	μF	/
	Evaporator Form		Aluminum Fin-copper Tube
	Evaporator Pipe Diameter	mm	Φ7
	Evaporator Row-fin Gap	mm	2-1.4
	Evaporator Coil Length (LXD×W)	mm	745×22.8×342.9
	Swing Motor Model		MP24AK/MP24HF/MP24BA
	Swing Motor Power Output	W	1.5/1.5/1.5
	Fuse Current	A	3.15
	Sound Pressure Level	dB (A)	Cooling:48/44/41/40/38/36/33/27 Heating:50/47/43/41/40/36/35
	Sound Power Level	dB (A)	Cooling:85/59/56/55/53/51/48/42 Heating:64/62/58/56/55/51/50
	Dimension (WXHXD)	mm	993×311×222
	Dimension of Carton Box (LXWXH)	mm	1050×377×288
	Dimension of Package (LXWXH)	mm	1055×385×298
	Net Weight	kg	13
	Gross Weight	kg	15.5

Outdoor Unit	Outdoor Unit Model		GWH24AUDXF-K6DNA1A/O(LC)
	Outdoor Unit Product Code		GB437W04701
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO.,LTD
	Compressor Model		QXFS-M180zX170
	Compressor Oil		/
	Compressor Type		Rotary
	Compressor LRA	A	24.00
	Compressor RLA	A	3.50
	Compressor Power Input	W	1350
	Compressor Overload Protector		HPC 115/95U1 KSD115°C
	Throttling Method		Electron expansion valve
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-15~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7.94
	Condenser Rows-fin Gap	mm	2~1.4
	Condenser Coil Length (LXD×W)	mm	934×38.1×616
	Fan Motor Speed	rpm	600
	Fan Motor Power Output	W	60
	Fan Motor RLA	A	0.65
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	3600
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ520
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	59
	Sound Power Level	dB (A)	70
	Dimension(WXHXD)	mm	958×660×402
	Dimension of Carton Box (LXWXH)	mm	1029×453×715
	Dimension of Package(LXWXH)	mm	1032×456×737
	Net Weight	kg	45
	Gross Weight	kg	49.5
	Refrigerant		R32
	Refrigerant Charge	kg	1.4
Connection Pipe	Connection Pipe Length	m	6
	Connection Pipe Gas Additional Charge	g/m	40
	Outer Diameter Liquid Pipe	inch	1/4
	Outer Diameter Gas Pipe	inch	5/8
	Max Distance Height	m	10
	Max Distance Length	m	25
	Note: The connection pipe applies metric diameter.		

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			GWH24AUDXF-K6DNA1B
Product Code			CB803001000
Power Supply	Rated Voltage	V~	220-240
	Rated Frequency	Hz	50
	Phases		1
Power Supply Mode			Outdoor
Cooling Capacity		W	6500
Heating Capacity		W	7034
Cooling Power Input		W	1700
Heating Power Input		W	1980
Cooling Current Input		A	7.5
Heating Current Input		A	9.5
Rated Input		W	4000
Rated Cooling Current		A	13
Rated Heating Current		A	17.5
Air Flow Volume		m³/h	1000/850/750/580/520/450/400/280
Dehumidifying Volume		L/h	2.4
EER		W/W	3.82
COP		W/W	3.55
SEER			8.5
SCOP(Average/Warmer/Colder)			4.4/6.0/3.5
Application Area		m²	27-42
Indoor Unit	Model		GWH24AUDXF-K6DNA1B/I
	Product Code		CB803N01000
	Fan Type		Cross-flow
	Fan Diameter Length(DXL)	mm	Φ106×739
	Cooling Speed	r/min	1400/1200/1120/1050/980/860/750/550
	Heating Speed	r/min	1400/1200/1120/1050/950/850/750
	Fan Motor Power Output	W	45
	Fan Motor RLA	A	0.25
	Fan Motor Capacitor	μF	1
	Evaporator Form		Aluminum Fin-copper Tube
	Evaporator Pipe Diameter	mm	Φ7
	Evaporator Row-fin Gap	mm	2-1.4
	Evaporator Coil Length (L×D×W)	mm	745×22.8×342.9
	Swing Motor Model		MP24AK/MP24HF/MP24BA
	Swing Motor Power Output	W	1.5/1.5/1.5
	Fuse Current	A	3.15
	Sound Pressure Level	dB (A)	Cooling:48/43/41/39/37/33/29/23 Heating:50/44/42/40/36/33/30
	Sound Power Level	dB (A)	Cooling:64/57/55/53/51/47/43/37 Heating:64/58/56/54/50/47/44
	Dimension (W×H×D)	mm	993×311×222
	Dimension of Carton Box (L×W×H)	mm	1050×377×288
	Dimension of Package (L×W×H)	mm	1055×385×298
	Net Weight	kg	13.5
	Gross Weight	kg	16

Outdoor Unit	Outdoor Unit Model		GWH24AUDXF-K6DNA1B/O(LC)
	Outdoor Unit Product Code		GB603W01000
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO.,LTD
	Compressor Model		QXFS-A150zX170S
	Compressor Oil		FW68DA or equivalent
	Compressor Type		Rotary
	Compressor LRA	A	35
	Compressor RLA	A	11.35
	Compressor Power Input	W	1330
	Compressor Overload Protector		/
	Throttling Method		Electron expansion valve
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-15~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7.94
	Condenser Rows-fin Gap	mm	2~1.4
	Condenser Coil Length (LXD×W)	mm	934×38.1×616
	Fan Motor Speed	rpm	600
	Fan Motor Power Output	W	60
	Fan Motor RLA	A	1.5
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	3600
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ520
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	58
	Sound Power Level	dB (A)	70
	Dimension(WXHXD)	mm	958×660×402
	Dimension of Carton Box (LXWXH)	mm	1029×453×715
	Dimension of Package(LXWXH)	mm	1032×456×737
	Net Weight	kg	42.5
	Gross Weight	kg	47
	Refrigerant		R32
	Refrigerant Charge	kg	1.3
Connection Pipe	Connection Pipe Length	m	6
	Connection Pipe Gas Additional Charge	g/m	40
	Outer Diameter Liquid Pipe	inch	1/4
	Outer Diameter Gas Pipe	inch	5/8
	Max Distance Height	m	10
	Max Distance Length	m	25
Note: The connection pipe applies metric diameter.			

The above data is subject to change without notice. Please refer to the nameplate of the unit.







Model		GWH24AUDXF-K6DNA1B	
Product Code		CB603001001/CB603001002/CB603001003	
Power Supply	Rated Voltage	V~	220-240
	Rated Frequency	Hz	50
	Phases		1
Power Supply Mode		Outdoor	
Cooling Capacity		W	6500
Heating Capacity		W	7034
Cooling Power Input		W	1700
Heating Power Input		W	1980
Cooling Current Input		A	7.5
Heating Current Input		A	9.5
Rated Input		W	4000
Rated Cooling Current		A	13
Rated Heating Current		A	17.5
Air Flow Volume		m³/h	1000/850/760/580/520/450/400/280
Dehumidifying Volume		L/h	2.4
EER		W/W	3.82
COP		W/W	3.55
SEER			8.5
SCOP(Average/Warmer/Colder)			4.4/6.0/3.5
Application Area		m²	27-42
Indoor Unit	Model	GWH24AUDXF-K6DNA1B/I	
	Product Code	CB603N01000/CB603N01002/CB603N01003	
	Fan Type	Cross-flow	
	Fan Diameter Length(DXL)	mm	Φ106×739
	Cooling Speed	r/min	1400/1200/1120/1050/980/860/750/550
	Heating Speed	r/min	1400/1200/1120/1050/950/850/750
	Fan Motor Power Output	W	45
	Fan Motor RLA	A	0.25
	Fan Motor Capacitor	μF	1
	Evaporator Form	Aluminum Fin-copper Tube	
	Evaporator Pipe Diameter	mm	Φ7
	Evaporator Row-fin Gap	mm	2-1.4
	Evaporator Coil Length (LXDXW)	mm	745×22.8×342.9
	Swing Motor Model	MP24AK/MP24HF/MP24BA	
	Swing Motor Power Output	W	1.5/1.5/1.5
	Fuse Current	A	3.15
	Sound Pressure Level	dB (A)	Cooling:48/43/41/39/37/33/29/23 Heating:50/44/42/40/36/33/30
	Sound Power Level	dB (A)	Cooling:64/57/55/53/51/47/43/37 Heating:64/58/56/54/50/47/44
	Dimension (WXHXD)	mm	993×311×222
	Dimension of Carton Box (LXWXH)	mm	1050×377×286
	Dimension of Package (LXWXH)	mm	1055×385×298
	Net Weight	kg	13.5
	Gross Weight	kg	16

Outdoor Unit	Outdoor Unit Model		GWH24AUDXF-K6DNA1B/O(LCLH)
	Outdoor Unit Product Code		GB603W01001
	Compressor Manufacturer		ZHUHAI LANDA COMPRESSOR CO.,LTD
	Compressor Model		QXFS-A150zX170S
	Compressor Oil		FW68DA or equivalent
	Compressor Type		Rotary
	Compressor LRA	A	35
	Compressor RLA	A	11.35
	Compressor Power Input	W	1330
	Compressor Overload Protector		/
	Throttling Method		Electron expansion valve
	Set Temperature Range	°C	16~30
	Cooling Operation Ambient Temperature Range	°C	-15~50
	Heating Operation Ambient Temperature Range	°C	-25~30
	Condenser Form		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	mm	Φ7.94
	Condenser Rows-fin Gap	mm	2~1.4
	Condenser Coil Length (LXD×W)	mm	934×38.1×616
	Fan Motor Speed	rpm	600
	Fan Motor Power Output	W	60
	Fan Motor RLA	A	1.5
	Fan Motor Capacitor	μF	/
	Outdoor Unit Air Flow Volume	m³/h	3600
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ520
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level	dB (A)	58
	Sound Power Level	dB (A)	70
	Dimension(WXHXD)	mm	958×660×402
	Dimension of Carton Box (LXWXH)	mm	1029×453×715
	Dimension of Package(LXWXH)	mm	1032×456×737
	Net Weight	kg	42.5
	Gross Weight	kg	47
	Refrigerant		R32
	Refrigerant Charge	kg	1.3
Connection Pipe	Connection Pipe Length	m	6
	Connection Pipe Gas Additional Charge	g/m	40
	Outer Diameter Liquid Pipe	inch	1/4
	Outer Diameter Gas Pipe	inch	5/8
	Max Distance Height	m	10
	Max Distance Length	m	25
	Note: The connection pipe applies metric diameter.		

The above data is subject to change without notice. Please refer to the nameplate of the unit.


2.2 Capacity Variation Ratio According to Temperature

Heating operation ambient temperature range is -25°C~30°C




Heating operation ambient temperature range is -15°C~30°C


Cooling




Heating




Cooling




Heating



Cooling




Heating




3. Outline Dimension Diagram


3.1 Indoor Unit



AUC



AUD





Unit: mm

Model	W	H	D	W1	W2	W3
AUC	837	293	200	119	542	176
AUD	993	311	222	128	707.5	157.5

3.2 Outdoor Unit




GWH09AUCXB-K6DNA1A/O GWH12AUCXB-K6DNA1A/O



Unit:mm


GWH18AUDXD-K6DNA1A/O GWH12AUCXD-K6DNA1C/O

(The front grill appearance is for reference only)




Unit:mm

GWH18AUDXE-K6DNA1A/O GWH18AUDXE-K6DNA1B/O GWH18AUDXE-K6DNA2C/O




GWH24AUDXF-K6DNA1A/O GWH24AUDXF-K6DNA1B/O




4. Refrigerant System Diagram

09K



Connection pipe specification:
Liquid pipe: 1/4"
Gas pipe: 3/8"

12/18/24K



Connection pipe specification:
Liquid pipe: 1/4"
Gas pipe: 3/8" (09/12K(XB))
Gas pipe: 1/2" (12K(XD)/18K)
Gas pipe: 5/8" (24K)

5. Electrical Part

5.1 Wiring Diagram

• Instruction


Symbol	Symbol Color	Symbol	Symbol Color	Symbol	Name
WH	White	GN	Green	CAP	Jumper cap
YE	Yellow	BN	Brown	COMP	Compressor
RD	Red	BU	Blue		Grounding wire
YEGN	Yellow/Green	BK	Black	/	/
VT	Violet	OG	Orange	/	/

Note: Jumper cap is used to determine fan speed and the swing angle of horizontal louver for this model.

• Indoor Unit


D9K(except:CB575N00311/CB597N00404/CB597N00498/CB575N00313/CB575N00314)

12K(XB)




18K(XD)

24K(except:CB437N04711/CB597N00304/CB603N01000/CB603N01002/CB603N01003/CB437N04713/CB437N04714)




D9K(CB575N00311/CB597N00404/CB597N00408/CB575N00313/CB575N00314)

12K(XD)



18K(XE)

24K(CB437N04711/CB597N00304/CB603N01000/CB603N01002/CB603N01003/CB437N04713/CB437N04714)




• Outdoor Unit


GWH09AUCXB-K6DNA1A/O


GWH12AUCXB-K6DNA1A/O

GWH12AUCXD-K6DNA1C/O



GWH18AUDXE-K6DNA2C/O





These wiring diagrams are subject to change without notice; please refer to the one supplied with the unit.

5.2 PCB Printed Diagram


Indoor Unit

09K(except:CB575N00314/CB575N00313/CB597N00408)

12K(XB)/18K(XD)

GWH24AUDXF-K6DNA1A/I(CB437N04700/CB437N04702/CB437N04703/CB437N04704/CB437N04706/CB437N04700/CB437N04702/CB437N04706/CB437N04704/CB437N04703/CB437N04710)

GWH24AUDXF-K8DNA2A/I(CB597N00300/CB597N00302/CB597N00300/CB597N00302/CB597N00306/CB597N00305/CB597N00307)



No.	Name
1	Earthing wire
2	Live wire
3	Communication interface
4	Neutral wire
5	DC fan
6	Cold plasma
7	Ultraviolet clean
8	Up&down swing 2

No.	Name
9	Up&down swing 1
10	Left&right swing
11	Interface of display board
12	Interface of WiFi
13	Temperature sensor
14	Door control
15	Wired controller


No.	Name	No.	Name
1	Neutral Wire Insertion	11	Stepping Motor Needle Stand 2
2	Fuse	12	Stepping Motor Needle Stand 4
3	Live Wire Insertion	13	Left & Right Swing Needle Stand
4	Earthing Wire Insertion	14	Display Board Needle Stand
5	Communication Wire Insertion	15	Fresh air Function Needle Stand
6	Brushless DC Motor Needle Stand	16	Temperature Sensor Needle Stand
7	Ultraviolet cleaning Needle Stand	17	Door Control Needle Stand
8	Health Function Needle Stand	18	Wired Controller Needle Stand
9	Up & Down Swing Needle Stand 1	19	Jumper Needle Stand
10	Up & Down Swing Needle Stand 3		

Outdoor Unit


GWH09AUCXB-K6DNA1A/O

GWH12AUCXB-K6DNA1A/O

GWH12AUCXD-K6DNA1C/O




No.	Name
1	Earthing wire
2	Neutral wire, live wire and communication cable
3	4-way valve
4	Electric heating belt of chassis
5	Outdoor fan
6	Electronic expansion valve
7	Temperature sensor
8	Three-phase terminal of compressor




No.	Name
1	Earthing wire
2	Live wire
3	Neutral wire
4	communication cable
5	4-way valve
6	Electric heating belt of chassis
7	DRED-DC(preliminary)

No.	Name
8	Outdoor fan
9	DRED(preliminary)
10	Electronic expansion valve
11	Overload
12	Temperature sensor
13	EE flash drive
14	Three-phase terminal of compressor




No.	Name
1	Earthing Wire Insertion
2	Live Wire Insertion
3	Communication Wire Insertion
4	Neutral Wire Insertion
5	Four-way Valve Needle Stand
6	Chassis Electric Heating Belt Needle Stand
7	Electronic Expansion Valve Needle Stand

No.	Name
8	Outdoor Fan Needle Stand
9	Temperature Sensor Needle Stand
10	Compressor Overload Needle Stand
11	DRED Power Supply Needle Stand
12	Compressor Needle Stand
13	EEP Flash Drive Needle Stand
14	DRED Communication Needle Stand



No.	Name
1	Earthing wire
2	Live wire
3	Neutral wire
4	communication cable
5	4-way valve
6	Electric heating belt of chassis

No.	Name
7	Outdoor fan
8	Temperature sensor
9	Overload
10	Three-phase terminal of compressor
11	Electronic expansion valve



No.	Name
1	Earthing Wire Insertion
2	Live Wire Insertion
3	Neutral Wire Insertion
4	Communication Wire Insertion
5	Four-way Valve Needle Stand
6	Chassis Electric Heating Belt Needle Stand

No.	Name
7	Outdoor Fan Needle Stand
8	Temperature Sensor Needle Stand
9	Compressor Overload Needle Stand
10	Compressor Needle Stand
11	Electronic Expansion Valve Needle Stand
12	EEP Flash Drive Needle Stand

6. Function and Control

6.1 Remote Controller Introduction

Introduction for icons on display screen



Introduction for icons on display screen

	Quiet
	Set fan speed
	Turbo mode
	Send signal
	Auto mode
	Cool mode
	Dry mode
	Fan mode
	Heat mode
	X-FAN function
	Humidity control
	Power limiting operation
	Set temperature
	Indoor ambient temp.
	Indoor ambient humidity
	TIMER ON / TIMER OFF
	Set time
	Left & right swing
	Up & down swing
	Chill icon
	Fast cool
	Health and UV functions
	WiFi function
	LED
	Auto LED
	I feel
	Sleep mode

Introduction for buttons on remote controller

NOTE:

- This is a general use remote controller. It could be used for the air conditioner with multifunction. For the functions which the model doesn't have, if press the corresponding button on the remote controller, the unit will keep the original running status.
- After putting through the power, the air conditioner will give out a sound. Power Indicator "ON" is ON. After that, you can operate the air conditioner by using remote controller.
- Under on status, pressing the button on the remote controller, the signal icon "S" on the display of remote controller will blink once and the air conditioner will give out a "di" sound, which means the signal has been sent to the air conditioner.

ON/OFF button

Press this button to turn on the unit. Press this button again to turn off the unit.

Mode button

Press this button to select your required operation mode.



- When selecting auto mode, air conditioner will operate automatically according to the sensed temperature. Press "Fan" button can adjust fan speed. Press " " / " " button can adjust fan blowing angle.
- After selecting cool mode, air conditioner will operate under cool mode. Press " + " or " - " button to adjust set temperature. Press "Fan" button to adjust fan speed. Press " " / " " button to adjust fan blowing angle.
- When selecting dry mode, the air conditioner operates at low speed under dry mode. Under dry mode, fan speed can't be adjusted. Press " " / " " button to adjust fan blowing angle.
- When selecting fan mode, the air conditioner will only blow fan, no cooling and no heating. Press "Fan" button to adjust fan speed. Press " " / " " button to adjust fan blowing angle.
- When selecting heat mode, the air conditioner operates under heat mode. Press " + " or " - " button to adjust set temperature. Press "Fan" button to adjust fan speed. Press " " / " " button to adjust fan blowing angle.

NOTE:

- For preventing cold air, after starting up heat mode, indoor unit will delay 1-5 minutes to blow air (Actual delay time depends on indoor ambient temperature).
- Set temperature range from remote controller: 16-30°C (61-86°F).
- This mode indicator is not available for some models.
- Cooling only unit won't receive heat mode signal. If setting heat mode with remote controller, press " ON/OFF " button can't start up the unit.



• When humidity control with dehumidification mode is set, the remote controller will display "88%", "%" and humidity value "88"; you can press "+" and "-" buttons to set the humidity value. Humidity setting range for the remote controller: 30%-70%. Temperature can't be adjusted under humidity control with dehumidification mode.

• When continuous dehumidification is set, the remote controller will display "Co"; the remote controller and indoor unit will display "Co".

Temperature can't be adjusted under continuous dehumidification mode.


• Under continuous dehumidification mode, the unit always works under dehumidification status; no need to set temperature and humidity.

NOTE:

- The air conditioner is mainly used for controlling the temperature, while the humidity control is the auxiliary function. The humidity will be affected by the factors such as indoor and outdoor environment, degree of indoor sealing and indoor flow.
- When the set humidity is higher than current atmospheric humidity, the set humidity can't be reached.
- If the humidity sensor is with malfunction, humidity setting under cooling mode or dehumidification mode will stop and the unit operates under general cooling mode or dehumidification mode.

⌂ LR-swing button

Press this button can select left & right swing angle. Fan blow angle can be selected circularly as below:



NOTE:

- Press this button continuously more than 2s, the main unit will swing back and forth from left to right, and then loosen the button, the unit will stop swinging and present position of guide louver will be kept immediately.
- Under swing left and right mode, when the status is switched from off to , if press this button again 2s later,  status will switch to off status directly; if press this button again within 2s, the change of swing status will also depend on the circulation sequence stated above.
- This function only applicable for some models.

⌚ Timer button

• At ON status, press this button once can set TIMER OFF. The character of HOUR and OFF will flash. Press "+" or "-" button within 5s can adjust the time of TIMER OFF. After each pressing of "+" or "-" button, time will increase or decrease half an hour. When holding "+" or "-" button, 2s later, the time will change quickly until to reach to your required time. After that, press "Timer" button to confirm it. The character of HOUR and OFF won't flash again. Cancel TIMER OFF: Press "Timer" button again under TIMER

OFF status.

• At OFF status, press this button once can set TIMER ON. Please refer to TIMER off for detailed operation.

Cancel TIMER ON: Press "Timer" button again under TIMER ON status.

NOTE:

- Time setting range: 0.5-24 hours.
- Time interval between two operations can't exceed 5s. Otherwise, remote controller will exit the setting status automatically.

⌚ Sleep button

Press this button, can select Sleep 1 (), Sleep 2 (), Sleep 3 () and cancel the Sleep, circulate between these, after electrified, Sleep Cancel is defaulted.

- Sleep 1 is Sleep mode 1, in Cool modes: sleep status after run for one hour, the main unit setting temperature will increase 1, two hours, setting temperature increased 2, then the unit will run at this setting temperature; in Heat mode: sleep status after run for one hour, the setting temperature will decrease 1, two hours, setting temperature will decrease 2, then the unit will run at this setting temperature.
- Sleep 2 is sleep mode 2, that is air conditioner will run according to the presetting a group of sleep temperature curve.
- Sleep 3 the sleep curve setting under Sleep mode by DIY.

(1) Under Sleep 3 mode, press "Health" button for a long time, remote controller enters into user individuation sleep setting status, at this time, the time of remote controller will display "1 HOUR", the setting temperature "88" will display the corresponding temperature of last setting sleep curve and blink (The first entering will display according to the initial curve setting value of original factory).

(2) Adjust "+" and "-" button, could change the corresponding setting temperature, after adjusted, press "Health" button for confirmation.

(3) At this time, 1 hour will be automatically increased at the timer position on the remote control, (that are "2 HOUR" or "3 HOUR" or "8 HOUR"), the place of setting temperature "88" will display the corresponding temperature of last setting sleep curve and blink.

(4) Repeat the above step (2)-(3) operation, until 8 hours temperature setting finished, sleep curve setting finished, at this time, the remote controller will resume the original timer display; temperature display will resume to original setting temperature.

• Sleep 3 the sleep curve setting under Sleep mode by DIY could be inquired:

The user could accord to sleep curve setting method to inquire the presetting sleep curve, enter into user individuation sleep setting status, but do not change the temperature, press "Health" button directly for confirmation. Note: In the above presetting or enquiry procedure, if continuously within 10s, there is no button pressed, the sleep curve setting within 10s, there is no button pressed, the sleep curve setting status will be automatically quit and resume to display the original displaying. In the presetting or enquiry procedure, press "On/Off" button, "Mode" button, "Timer" button or "Sleep" button, the sleep curve setting or enquiry status will quit similarly.

💡 Light button

Press this button to control the LED status on the display, the circulation change is as follow:



When selecting "Auto LED" with remote controller, LED indicator on indoor unit will adjust the luminance automatically according to the ambient intensity of illumination.

Function introduction for combination buttons

Energy-saving function

Under cooling mode, press "Mode" and "Timer" buttons simultaneously to start up or turn off energy-saving function. When energy-saving function is started up, "SE" will be shown on remote controller, and air conditioner will adjust the set temperature automatically according to ex-factory setting to reach to the best energy-saving effect.

Press "Mode" and "Timer" buttons simultaneously again to exit energy-saving function.

NOTE:

- Under energy-saving function, fan speed is defaulted at auto speed and it can't be adjusted.
- Under energy-saving function, set temperature can't be adjusted.
- Sleep function and energy-saving function can't operate at the same time. If energy-saving function has been set under cool mode, press "Sleep" button will cancel energy-saving function. If sleep function has been set under cool mode, start up the energy-saving function will cancel sleep function.

Child lock function

Hold "On/Off" and "Child Lock" buttons simultaneously for 3s to turn on or turn off child lock function. When child lock function is on, "Child Lock" icon is displayed on remote controller. If you operate the remote controller, the "Child Lock" icon will blink three times without sending signal to the unit.

Temperature display switchover function

Under OFF status, hold "Mode" and "Temperature" buttons simultaneously for 3s to switch temperature display between °C and °F.

Power limiting function

Power limiting function is for limiting power of the whole unit. Press "Mode" and "Sleep" buttons simultaneously, the remote controller will circularly display as the following:



- Maximum power limited under the power limiting mode is lower than that of normal mode.
- If you want to cancel the power limiting function, press "Mode" and "Sleep" buttons simultaneously till the icon in remote controller is not displayed.

• When the remote controller is turned off, power limiting function is cancelled. If you want to activate the function, please repress "Mode" and "Sleep" buttons simultaneously.

• If the current power is lower than the maximum power of power limiting mode, then the power will not be limited after entering into such mode.

• For the model with one outdoor unit and two indoor units, if any one of indoor units enters into power limiting function, the outdoor unit will enter into the set limiting power mode of indoor unit; when two indoor units enter into power limiting mode, then the power of outdoor unit will be limited according to the lower power of the two indoor units.

NOTE:

- This button is only available for the model with such function.

Indoor ambient temperature or humidity display

By holding "On/Off" and "Indoor Temp/Humidity" buttons simultaneously, you can see indoor ambient temperature or indoor ambient humidity on indoor unit's display. The setting on remote controller is selected circularly as below:



- When selecting "Indoor Temp" with remote controller, temperature indicator on indoor unit displays indoor ambient temperature.
- When selecting "Indoor Humidity" with remote controller, temperature indicator on indoor unit displays indoor ambient humidity.

NOTE:

- The ambient humidity value is only for reference. Eg: If humidity value is "0%", there may be malfunction for the humidity detection board. Please contact local service provider.
- There may be some measuring deviation for humidity detection and photosensitivity detection.

Clean reminder function of filter

The reminder function is defaulted to be OFF. Hold "On/Off" and "Clean Reminder" buttons simultaneously for 5s to turn it on. The buzzer will give out sound for 0.5s and the dual-8 nixie tube on the display will be on for 3s; Once the reminder function is turned on, when the air conditioner has reached to the set time, the dual-8 nixie tube will flash about 30s when the unit is turned on each time to remind the user to clean the filter; you can turn off this cycle reminder by holding "On/Off" and "Clean Reminder" buttons simultaneously for 5s and then the air conditioner will count time again.

NOTE:

- Once the reminder function is turned on, only this cycle reminder can be cleared.
- This function is only available for some models.

Volume control of IDU Buzzer

Press "Mode" and "Volume" buttons simultaneously to reduce the sound level of the indoor unit buzzer.

NOTE:

- This function is only available for some models.

Fast cool function

Press "On/Off" and "+" buttons simultaneously under cooling mode can select 25°C(77°F) fast cooling mode, 16°C(61°F) fast cooling mode and normal cooling mode circularly. "+" icon will be displayed on the remote controller under fast cooling mode.

Once it enters into fast cooling mode, the fan speed is auto fan and the set temperature is 25°C(77°F) or 16°C(61°F). At this time, the set temperature flashes to display for 5s. In the flashing period, press "+" or "-" button to adjust the set temperature.

Press "Fan" button to adjust the fan speed. If the set temperature and the fan speed haven't been adjusted during that time, the remote controller and the indoor unit will operate under current set temperature and fan speed for 20 minutes. 20 minutes later, the set temperature and the fan speed for the remote controller and the indoor unit will turn to the status before quick cooling.

NOTE:

- If the set temperature and the fan speed have been adjusted during the operation under fast cooling mode, the unit will exit from the fast cooling mode. Then the indoor unit operates continuously under the adjusted status.
- Fast cooling function is only applicable for some models. If this function is unavailable for this indoor unit, 20 minutes later, the remote controller will turn back to the status before fast cooling. Indoor unit operates continuously according to current status. At this time, status of indoor unit and the display status on the remote controller may be different.
- This function is only available for some models.

Auto clean function

Under unit off status, hold "Mode" and "⌂" buttons simultaneously for 5s to turn on or turn off the auto clean function. When the auto clean function is turned on, indoor unit displays "CL". During the auto clean process of evaporator, the unit will perform fast cooling or fast heating. There may be some noise, which is the sound of flowing liquid or thermal expansion or cold shrinkage. The air conditioner may blow cool or warm air, which is a normal phenomenon. During cleaning process, please make sure the room is well ventilated to avoid affecting the comfort.

NOTE:

- The auto clean function can only work under normal ambient temperature. If the room is dusty, clean it once a month; if not, clean it once every three months. After the auto clean function is turned on, you can leave the room. When auto clean is finished, the air conditioner will enter standby status.
- This function is only available for some models.

Night mode

Under cooling or heating mode, when turning on sleep mode and turn to low speed or quiet notch, the outdoor unit would enter into night mode.

NOTE:


- When you feel that the cooling and heating effect is poor, please press "Fan" button to other fan speed or press "Sleep" button to exit the night mode.
- The night mode can only work under normal ambient temperature.
- This function is only available for some models.

I FEEL function

Press "Health" and "+" buttons simultaneously to start I FEEL function and "+" will be displayed on the remote controller. After this function is set, the remote controller will send the detected ambient temperature to the controller and the unit will automatically adjust the indoor temperature according to the detected temperature. Press "Health" and "+" buttons simultaneously again to turn off I FEEL function and "+" will disappear.

- Please put the remote controller near user when this function is set. Do not put the remote controller near the object of high temperature or low temperature in order to avoid detecting inaccurate ambient temperature. When I FEEL function is turned on, the remote controller should be put within the area where indoor unit can receive the signal sent by the remote controller.

Replacement of batteries in remote controller




1. Press the back side of remote controller marked with "⌂", as shown in the fig, and then push out the cover of battery box along the arrow direction.
2. Replace two 7# (AAA 1.5V) dry batteries, and make sure the position of "+" polar and "-" polar are correct.
3. Reinstall the cover of battery box.

NOTICE:

- During operation, point the remote control signal sender at the receiving window on indoor unit.
- The distance between signal sender and receiving window should be no more than 8m, and there should be no obstacles between them.
- Signal may be interfered easily in the room where there is fluorescent lamp or wireless telephone; remote controller should be close to indoor unit during operation.
- Replace new batteries of the same model when replacement is required.
- When you don't use remote controller for a long time, please take out the batteries.
- If the display on remote controller is fuzzy or there's no display, please replace batteries.

6.2 GREE+ App Operation Manual

Control Flow Chart



Operating Systems

Requirement for User's smart phone:



iOS system
Support iOS7.0 and
above version



Android system
Support Android 4.4 and
above version

Download and installation




GREE+ App Download Linkage

Scan the QR code or search "GREE+" in the application market to download and install it. When "GREE+" App is installed, register the account and add the device to achieve long-distance control and LAN control of Gree smart home appliances. For more information, please refer to "Help" in App.

6.3 Ewpe Smart App Operation Manual

Control Flow Chart



Operating Systems

Requirement for User's smart phone:



iOS system
Support iOS7.0 and
above version



Android system
Support Android 4.4 and
above version

Download and installation



App Download Linkage

Scan the QR code or search "Ewpe Smart" in the application market to download and install it. When "Ewpe Smart" App is installed, register the account and add the device to achieve long-distance control and LAN control of smart home appliances. For more information, please refer to "Help" in App.

After power recovery, compressor can only be started up after $180 + T_s$ at least.

(13) SE control mode

The unit operates at SE status.

(14) X-fan mode

When X-fan function is turned on, after turn off the unit, indoor fan will still operate at low speed for 2min and then the complete unit will be turned off. When x-fan function is turned off, after turn off the unit, the complete unit will be turned off directly.

(15) 8°C heating function

Under heating mode, you can set 8°C heating function by remote controller. The system will operate at 8°C set temperature.

(16) Turbo function

Turbo function can be set under cooling and heating modes. Press Fan Speed button to cancel turbo setting. Turbo function is not available under auto, drying and fan modes.

● Outdoor Unit

1. Cooling mode:

Working condition and process of cooling mode:

① When $T_{\text{indoor ambient temperature}} \geq T_{\text{preset}}$, unit enters into cooling mode. Indoor fan, outdoor fan and compressor start operation. Indoor fan operates according to set fan speed.

② When $T_{\text{indoor ambient temperature}} \leq T_{\text{preset}} - 2^\circ\text{C}$, compressor stops operation and outdoor fan will stop 30s later. Indoor fan operates according to set fan speed.

③ When $T_{\text{preset}} - 2^\circ\text{C} < T_{\text{indoor ambient temperature}} < T_{\text{preset}}$, unit operates according to the previous status.

Under cooling mode, 4-way valve is not energized. Temperature setting range is 16~30°C. If compressor stops because of malfunction in cooling mode, indoor fan and swing motor will work according to the original status.

2. Drying mode:

(1) Working condition and process of drying mode

① When $T_{\text{indoor ambient temperature}} > T_{\text{preset}}$, unit will be in drying mode. Outdoor fan and compressor start operation while indoor fan will operate at low fan speed.

② When $T_{\text{preset}} - 2^\circ\text{C} \leq T_{\text{indoor ambient temperature}} \leq T_{\text{preset}}$, unit operates according to the previous status.

③ When $T_{\text{indoor ambient temperature}} < T_{\text{preset}} - 2^\circ\text{C}$, compressor stops operation and outdoor fan will stop 30s later.

(2) Under drying mode, 4-way valve is not energized. Temperature setting range is 16~30°C.

(3) Protection function: same as in cooling mode.

3. Fan mode

(1) Under this mode, indoor fan can select different fan speed (except Turbo) or auto fan speed. Compressor, outdoor fan and 4-way valve all stop operation.

(2) In fan mode, temperature setting range is 16~30°C.

4. Heating mode

Working condition and process of heating mode:

① When $T_{\text{preset}} - (T_{\text{indoor ambient temperature}} - T_{\text{compensation}}) \geq 1^\circ\text{C}$, unit enters into heating mode. Compressor, outdoor fan and 4-way valve start operation.

② When $-2^\circ\text{C} < T_{\text{preset}} - (T_{\text{indoor ambient temperature}} - T_{\text{compensation}}) < 1^\circ\text{C}$, unit operates according to the previous status.

③ When $T_{\text{preset}} - (T_{\text{indoor ambient temperature}} - T_{\text{compensation}}) \leq -2^\circ\text{C}$, compressor

stops operation and outdoor fan will stop 30s later. Indoor fan will be in residual-heat blowing status.

④ When unit is turned off under heating mode or changed to other modes from heating mode, 4-way valve will be power-off 2min after compressor stops working (compressor is in operation status under heating mode).

⑤ When $T_{\text{indoor ambient temperature}} > 30^\circ\text{C}$, compressor stops operation immediately. Outdoor fan will stop 30s later.

⑥ Under the condition that compressor is turned on, when unit is changed to heating mode from cooling or drying mode, 4-way valve will be energized in 2~3mins delay.

Note: Tcompensation is determined by IDU and ODU. If IDU controls the compensation temperature, then Tcompensation is determined according to the value sent by IDU to ODU; If IDU does not control the compensation temperature, then Tcompensation will default to 3°C by the ODU.

5. Freon recovery mode

After the Freon recovery signal from IDU is received, cooling, at rated frequency will be forcibly turned on to recover Freon.

Indoor unit will display Fo. If any signal from remote controller is received, unit will exit from Freon recovery mode and indoor unit stops displaying Fo.

6. Compulsory defrosting

If unit is turned on under heating mode and set temperature is 16°C (by remote controller), press "+, -, +, -, +, -" within 5s, unit will enter into compulsory defrosting mode and send the signal to ODU. When the compulsory defrosting signal from ODU is received, IDU will exit from the compulsory defrosting mode and stop sending the signal to ODU.

After ODU receives the compulsory defrosting code, it will start compulsory defrosting. Defrosting frequency and opening angle will be the same as in normal defrosting mode. When compulsory defrosting is finished, the complete unit resumes original status.

7. Auto mode

Auto mode is determined by controller of IDU. See IDU logic for details.

8. 8°C heating

Set temperature is 8°C. Display board of IDU displays 8°C. Under this mode, "Cold air prevention" function is shielded.

If compressor is operating under this mode, fan speed will adjust according to auto fan speed; if compressor stops operation under this mode, indoor fan will be in residual-heat blowing status.

When power on, communication light will be blinking in a normal way (after receiving a group of correct signals, blinking stops for 0.2s~0.3s). If there is no communication, communication light will be always on. If other ODU has malfunction, communication light will be on for 1s and off for 1s in a circular way.

7. Notes for Installation and Maintenance

Safety Precautions: Important!

Please read the safety precautions carefully before installation and maintenance.

The following contents are very important for installation and maintenance.

Please follow the instructions below.

- The installation or maintenance must accord with the instructions.
- Comply with all national electrical codes and local electrical codes.
- Pay attention to the warnings and cautions in this manual.
- All installation and maintenance shall be performed by distributor or qualified person.
- All electric work must be performed by a licensed technician according to local regulations and the instructions given in this manual.
- Be caution during installation and maintenance. Prohibit incorrect operation to prevent electric shock, casualty and other accidents.

WARNINGS

Electrical Safety Precautions:

1. Cut off the power supply of air conditioner before checking and maintenance.
2. The air condition must apply specialized circuit and prohibit share the same circuit with other appliances.
3. The air conditioner should be installed in suitable location and ensure the power plug is touchable.
4. Make sure each wiring terminal is connected firmly during installation and maintenance.
5. Have the unit adequately grounded. The grounding wire can't be used for other purposes.
6. Must apply protective accessories such as protective boards, cable-cross loop and wire clip.
7. The live wire, neutral wire and grounding wire of power supply must be corresponding to the live wire, neutral wire and grounding wire of the air conditioner.
8. The power cord and power connection wires can't be pressed by hard objects.
9. If power cord or connection wire is broken, it must be replaced by a qualified person.
10. If the power cord or connection wire is not long enough, please get the specialized power cord or connection wire from the manufacture or distributor. Prohibit prolong the wire by yourself.
11. For the air conditioner without plug, an air switch must be installed in the circuit. The air switch should be all-pole parting and the contact parting distance should be more than 3mm.

12. Make sure all wires and pipes are connected properly and the valves are opened before energizing.

13. Check if there is electric leakage on the unit body. If yes, please eliminate the electric leakage.

14. Replace the fuse with a new one of the same specification if it is burnt down; don't replace it with a cooper wire or conducting wire.

15. If the unit is to be installed in a humid place, the circuit breaker must be installed.

Installation Safety Precautions:

1. Select the installation location according to the requirement of this manual. (See the requirements in installation part)
2. Handle unit transportation with care; the unit should not be carried by only one person if it is more than 20kg.
3. When installing the indoor unit and outdoor unit, a sufficient fixing bolt must be installed; make sure the installation support is firm.
4. Wear safety belt if the height of working is above 2m.
5. Use equipped components or appointed components during installation.
6. Make sure no foreign objects are left in the unit after finishing installation.

Refrigerant Safety Precautions:

1. When refrigerant leaks or requires discharge during installation, maintenance, or disassembly, it should be handled by certified professionals or otherwise in compliance with local laws and regulations.
2. Avoid contact between refrigerant and fire as it generates poisonous gas; Prohibit prolong the connection pipe by welding.
3. Apply specified refrigerant only. Never have it mixed with any other refrigerant. Never have air remain in the refrigerant line as it may lead to rupture or other hazards.
4. Make sure no refrigerant gas is leaking out when installation is completed.
5. If there is refrigerant leakage, please take sufficient measure to minimize the density of refrigerant.
6. Never touch the refrigerant piping or compressor without wearing glove to avoid scald or frostbite.

Improper installation may lead to fire hazard, explosion, electric shock or injury.

UV-C lamp function instruction

WARNINGS

This appliance contains a UV emitter. Do not stare at the light source.

- This appliance contains a UV-C lamp.
- Read the maintenance instructions before opening the appliance.
- Details for cleaning and other user maintenance of the appliance:

① Prior to cleaning or other maintenance, the appliance must be disconnected from the supply mains.

② Open the panel to take out the filter.

③ Use a soft cotton cloth to wipe the quartz glass until it's clean.

④ Reinstall the filter when it has been cleaned and then close the panel cover.

- The method, frequency of cleaning, and necessary precautions to be taken:

Cleaning method: wipe the quartz glass with soft cloth until the surface is clean.

Cleaning frequency: clean it every 6 months; the cleaning frequency can be properly adjusted according to the degree of air cleanliness.

Preventive measures:

① The unit must be turned off and the power must be cut off before cleaning. Otherwise, it may cause electric shock and damage by UV.

② Do not use volatile oil, alcohol, diluents or lacquer to clean the UV-C lamp. Otherwise, the UV-C lamp may be damaged.

③ Do not touch the fins of indoor unit to prevent scalding.

④ Do not scratch the surface of glass when wiping it.

• Unintended use of the appliance or damage to the housing may result in the escape of dangerous UV-C radiation. UV-C radiation may, even in small doses, cause harm to the eyes and skin.

- Appliances that are obviously damaged must not be operated.

• Before opening doors and access panels bearing the ultraviolet radiation hazard Symbol for the conducting user maintenance, it is recommended to disconnect the power.

• UV-C barriers bearing the ultraviolet radiation hazard symbol should not be removed.

- Do not operate UV-C lamps outside of the appliance.

WARNINGS

• Do not operate the UV-C emitter when it is removed from the appliance.

• To avoid any dangerous situations, the user shall not replace the UV-C lamp, which must be performed by the manufacturer or the professionals of the maintenance or similar department.

Safety Precautions for Installing and Relocating the Unit:

To ensure safety, please be mindful of the following precautions.



WARNINGS

1. When installing or relocating the unit, be sure to keep the refrigerant circuit free from air or substances other than the specified refrigerant.

Any presence of air or other foreign substance in the refrigerant circuit will cause system pressure rise or compressor rupture, resulting in injury.

2. When installing or moving this unit, do not charge the refrigerant which is not comply with that on the nameplate or unqualified refrigerant.

Otherwise, it may cause abnormal operation, wrong action, mechanical malfunction or even series safety accident.

3. When refrigerant needs to be recovered during relocating or repairing the unit, be sure that the unit is running in cooling mode. Then, fully close the valve at high pressure side (liquid valve). About 30-40 seconds later, fully close the valve at low pressure side (gas valve), immediately stop the unit and disconnect power. Please note that the time for refrigerant recovery should not exceed 1 minute.

If refrigerant recovery takes too much time, air may be sucked in and cause pressure rise or compressor rupture, resulting in injury.

4. During refrigerant recovery, make sure that liquid valve and gas valve are fully closed and power is disconnected before detaching the connection pipe.

If compressor starts running when stop valve is open and connection pipe is not yet connected, air will be sucked in and cause pressure rise or compressor rupture, resulting in injury.

5. When installing the unit, make sure that connection pipe is securely connected before the compressor starts running.

If compressor starts running when stop valve is open and connection pipe is not yet connected, air will be sucked in and cause pressure rise or compressor rupture, resulting in injury.

6. Prohibit installing the unit at the place where there may be leaked corrosive gas or flammable gas.

If there leaked gas around the unit, it may cause explosion and other accidents.

7. Do not use extension cords for electrical connections. If the electric wire is not long enough, please contact a local service center authorized and ask for a proper electric wire.

Poor connections may lead to electric shock or fire.

8. Use the specified types of wires for electrical connections between the indoor and outdoor units. Firmly clamp the wires so that their terminals receive no external stresses.

Electric wires with insufficient capacity, wrong wire connections and insecure wire terminals may cause electric shock or fire.

Safety Precautions for Refrigerant

- To realize the function of the air conditioner unit, a special refrigerant circulates in the system. The used refrigerant is the fluoride R32, which is specially cleaned. The refrigerant is flammable and inodorous. Furthermore, it can lead to explosion under certain conditions. But the flammability of the refrigerant is very low. It can be ignited only by fire.
- Compared to common refrigerants, R32 is a nonpolluting refrigerant with no harm to the ozoneosphere. The influence upon the greenhouse effect is also lower. R32 has got very good thermodynamic features which lead to a really high energy efficiency. The units there fore need a less filling.

WARNING:

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacture. Should repair be necessary, contact your nearest authorized Service Centre. Any repairs carried out by unqualified personnel may be dangerous. The appliance shall be stored in a room without continuously operating ignition sources. (for example: open flames, an operating gas appliance or an operating electric heater.) Do not pierce or burn.

Appliance shall be installed, operated and stored in a room with a floor area larger than Xm^2 . (Please refer to table "a" in section of " Safety operation of flammable refrigerant " for space X.)

Appliance filled with flammable gas R32.

For repairs, strictly follow manufacturer's instructions only. Be aware that refrigerants may not contain an odour. Read specialist's manual.



Safety Operation of Flammable Refrigerant

Qualification requirement for installation and maintenance man

- All the work men who are engaging in the refrigeration system should bear the valid certification awarded by the authoritative organization and the qualification for dealing with the refrigeration system recognized by this industry. If it needs other technician to maintain and repair the appliance, they should be supervised by the person who bears the qualification for using the flammable refrigerant.
- It can only be repaired by the method suggested by the equipment's manufacturer.

Installation notes

- The air conditioner must be installed in a room that is larger

than the minimum room area. The minimum room area is shown on the nameplate or following table a.

- It is not allowed to drill hole or burn the connection pipe.
- Leak test is a must after installation.

table a - Minimum room area (m^2)

Charge amount (kg)	Floor location	Window mounted	Wall mounted	Ceiling mounted
≤1.2	4	4	4	4
1.3	14.5	5.2	4	4
1.4	16.8	6.1	4	4
1.5	19.3	7	4	4
1.6	22	7.9	4	4
1.7	24.8	8.9	4	4
1.8	27.8	10	4	4
1.9	31	11.2	4	4
2.0	34.3	12.4	4	4
2.1	37.8	13.6	4.2	4
2.2	41.5	15	4.6	4
2.3	45.4	16.3	5	4
2.4	49.4	17.6	5.5	4
2.5	53.6	19.3	6	4

Maintenance notes

- Check whether the maintenance area or the room area meet the requirement of the nameplate.
- It's only allowed to be operated in the rooms that meet the requirement of the nameplate.
- Check whether the maintenance area is wellventilated.
- The continuous ventilation status should be kept during the operation process.
- Check whether there is fire source or potential fire source in the maintenance area.
- The naked flame is prohibited in the maintenance area; and the "no smoking" warning board should be hanged.
- Check whether the appliance mark is in good condition.
- Replace the vague or damaged warning mark.

Welding

- If you should cut or weld the refrigerant system pipes in the process of maintaining, please follow the steps as below:
 - a. Shut down the unit and cut power supply
 - b. Eliminate the refrigerant
 - c. Vacuuming
 - d. Clean it with N_2 gas
 - e. Cutting or welding
 - f. Carry back to the service spot for welding
- The refrigerant should be recycled into the specialized storage tank.
- Make sure that there isn't any naked flame near the outlet of the vacuum pump and it's wellventilated.

Filling the refrigerant

- Use the refrigerant filling appliances specialized for R32. Make sure that different kinds of refrigerant won't contaminate with each other.
- The refrigerant tank should be kept upright at the time of filling refrigerant.
- Stick the label on the system after filling is finished (or haven't finished).
- Don't overfilling.
- After filling is finished, please do the leakage detection before test running; another time of leak detection should be done when it's removed.

Safety instructions for transportation and storage

- Please use the flammable gas detector to check before unload and open the container.
- No fire source and smoking.
- According to the local rules and laws.

Specialist's Manual

- The following checks shall be applied to installations using flammable refrigerants:
 - the charge size is in accordance with the room size within which the refrigerant containing parts are installed;
 - the ventilation machinery and outlets are operating adequately and are not obstructed;
 - if an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant;
 - marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
 - refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.
- Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised.
- Initial safety checks shall include:
 - that capacitors are discharged; this shall be done in a safe manner to avoid possibility of sparking;
 - that no live electrical components and wiring are exposed while charging, recovering or purging the system;
 - that there is continuity of earth bonding.
- Checking for presence of refrigerant
The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.
- Presence of fire extinguisher
If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO2 fire extinguisher adjacent to the charging area.

• Ventilated area

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

• Checks to the refrigeration equipment

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.

• Checks to electrical devices

- that capacitors are discharged; this shall be done in a safe manner to avoid possibility of sparking;
- that no live electrical components and wiring are exposed while charging, recovering or purging the system.

• Repairs to sealed components

During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation. Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.

– Ensure that the apparatus is mounted securely.

– Ensure that seals or sealing materials have not degraded to the point that they no longer serve the purpose of preventing the ingress of flammable atmospheres. Replacement parts shall be in accordance with the manufacturer's specifications.

NOTE: The use of silicon sealant can inhibit the effectiveness of some types of leak detection equipment.

Intrinsically safe components do not have to be isolated prior to working on them.

• Repair to intrinsically safe components

Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.

Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.

Replace components only with parts specified by the manufacturer. Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

• Cabling

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

• Detection of flammable refrigerants

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

• Leak detection methods

Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.

• Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of reclaimed refrigerant. It is essential that electrical power is available before the task is commenced.

- a) Become familiar with the equipment and its operation.
- b) Isolate system electrically.
- c) Before attempting the procedure, ensure that:
 - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - all personal protective equipment is available and being used correctly;
 - the recovery process is supervised at all times by a competent person;
 - recovery equipment and cylinders conform to the appropriate standards;
- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with manufacturer's instructions.
- h) Do not overfill cylinders. (No more than 80% volume liquid charge).
- i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

• Labelling

Equipment shall be labelled stating that it has been decommissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing flammable refrigerants, ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

• Recovery

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge are available.

All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).

Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery machine,

check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.

The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.

If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

Main Tools for Installation and Maintenance



Level meter



Measuring tape



Screw driver



Impact drill



Drill head



Electric drill



Electroprobe



Universal meter



Torque wrench



Open-end wrench



Inner hexagon spanner



Electronic leakage detector



Vacuum pump



Pressure meter



Pipe pliers



Pipe pliers



Pipe cutter



Pipe expander



Pipe bender



Soldering appliance




Refrigerant container




Electronic scale

8. Installation

8.1 Installation Dimension Diagram



Installation Procedures



Note: this flow is only for reference; please find the more detailed installation steps in this section.

8.2 Installation Parts-checking

No.	Name
1	Indoor unit
2	Outdoor unit
3	Connection pipe
4	Drainage pipe
5	Wall-mounting frame
6	Connecting cable(power cord)
7	Wall pipe
8	Sealing gum
9	Wrapping tape
10	Support of outdoor unit
11	Fixing screw
12	Drainage plug(cooling and heating unit)
13	Owners manual, remote controller

Note:

1. Please contact the local agent for installation.
2. Don't use unqualified power cord.

8.3 Selection of Installation Location

1. Basic Requirement:

Installing the unit in the following places may cause malfunction. If it is unavoidable, please consult the local dealer.

- (1) The place with strong heat sources; vapors, flammable or explosive gas, or volatile objects spread in the air.
- (2) The place with high-frequency devices (such as welding machine, medical equipment).
- (3) The place near coast area.
- (4) The place with oil or fumes in the air.
- (5) The place with sulfured gas.
- (6) Other places with special circumstances.
- (7) The appliance shall not be installed in the laundry.
- (8) It's not allowed to be installed on the unstable or motive base structure(such as truck) or in the corrosive environment (such as chemical factory).

2. Indoor Unit:

- (1) There should be no obstruction near air inlet and air outlet.
- (2) Select a location where the condensation water can be dispersed easily and won't affect other people.
- (3) Select a location which is convenient to connect the outdoor unit and near the power socket.
- (4) Select a location which is out of reach for children.
- (5) The location should be able to withstand the weight of indoor unit and won't increase noise and vibration.
- (6) The appliance must be installed 2.5m above floor.
- (7) Don't install the indoor unit right above the electric appliance.
- (8) Please try your best to keep away from fluorescent lamp.

3. Outdoor Unit:

- (1) Select a location where the noise and outflow air emitted by the outdoor unit will not affect neighborhood.
- (2) The location should be well ventilated and dry, in which the outdoor unit won't be exposed directly to sunlight or strong wind.

(3) The location should be able to withstand the weight of outdoor unit.

(4) Make sure that the installation follows the requirement of installation dimension diagram.

(5) Select a location which is out of reach for children and far away from animals or plants. If it is unavoidable, please add fence for safety purpose.

8.4 Electric Connection Requirement

1. Safety Precaution

- (1) Must follow the electric safety regulations when installing the unit.
- (2) According to the local safety regulations, use qualified power supply circuit and air switch.
- (3) Make sure the power supply matches with the requirement of air conditioner. Unstable power supply or incorrect wiring may result in electric shock, fire hazard or malfunction. Please install proper power supply cables before using the air conditioner.
- (4) Properly connect the live wire, neutral wire and grounding wire of power socket.
- (5) Be sure to cut off the power supply before proceeding any work related to electricity and safety.
- (6) Do not put through the power before finishing installation.
- (7) If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- (8) The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.
- (9) The appliance shall be installed in accordance with national wiring regulations.
- (10) Appliance shall be installed, operated and stored in a room with a floor area larger than 3m² (Please refer to table "a" in section of "Safety Operation of Inflammable Refrigerant" for Space X.)



Please notice that the unit is filled with flammable gas R32. Inappropriate treatment of the unit involves the risk of severe damages of people and material. Details to this refrigerant are found in chapter "refrigerant".

2. Grounding Requirement:

- (1) The air conditioner is the first class electric appliance. It must be properly grounding with specialized grounding device by a professional. Please make sure it is always grounded effectively, otherwise it may cause electric shock.
- (2) The yellow-green wire in air conditioner is grounding wire, which can't be used for other purposes.
- (3) The grounding resistance should comply with national electric safety regulations.
- (4) The appliance must be positioned so that the plug is accessible.
- (5) An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.
- (6) Including an air switch with suitable capacity, please note the following table. Air switch should be included magnet buckle and heating buckle function. It can protect the circuit-short and overload. (Caution: please do not use the fuse only for protect the circuit)

Model	Air switch capacity	Power cord
09/12K	10A	3G1.0
18K	16A	3G1.5
24K	25A	3G2.5

8.5 Installation of Indoor Unit

1. Choosing Installation location

Recommend the installation location to the client and then confirm it with the client.

2. Install Wall-mounting Frame


(1) Hang the wall-mounting frame on the wall; adjust it in horizontal position with the level meter and then point out the screw fixing holes on the wall.

(2) Drill the screw fixing holes on the wall with impact drill (the specification of drill head should be the same as the plastic expansion particle) and then fill the plastic expansion particles in the holes.


(3) Fix the wall-mounting frame on the wall with tapping screws and then check if the frame is firmly installed by pulling the frame. If the plastic expansion particle is loose, please drill another fixing hole nearby.

3. Drill Piping Hole

(1) Choose the position of piping hole according to the direction of outlet pipe. The position of piping hole should be a little lower than the wall-mounted frame, shown as below. (As show in Fig.1)



(2) Drill a piping hole with the diameter of $\Phi 55\text{mm}$ or $\Phi 70\text{mm}$ on the selected outlet pipe position. In order to drain smoothly, slant the piping hole on the wall slightly downward to the outdoor side with the gradient of $5-10^\circ$ (As show in Fig.2)





Note:

Pay attention to dust prevention and take relevant safety measures when drilling the hole.

4. Outlet Pipe

(1) The pipe can be led out in the direction of right, rear right, left or rear left. (As show in Fig.3)

(2) When selecting leading out the pipe from left or right, please cut off the corresponding hole on the bottom case. (As show in Fig.4)






5. Connect the Pipe of Indoor Unit

(1) Aim the pipe joint at the corresponding bellmouth. (As show in Fig.5)

(2) Pretightening the union nut with hand.

(3) Adjust the torque force by referring to the following sheet. Place the open-end wrench on the pipe joint and place the torque wrench on the union nut. Tighten the union nut with torque wrench. (As show in Fig.6)

(4) Wrap the indoor pipe and joint of connection pipe with insulating pipe, and then wrap it with tape. (As show in Fig.7)



Refer to the following table for wrench moment of force:

Piping size	Tightening torque(N·m)
1/4"	15~20
3/8"	30~40
1/2"	45~55
5/8"	60~65
3/4"	70~75

6. Install Drain Hose

- (1) Connect the drain hose to the outlet pipe of indoor unit. (As show in Fig.8)
- (2) Bind the joint with tape. (As show in Fig.9)




Fig.8




Fig.9

⚠ Note:

- (1) Add insulating pipe in the indoor drain hose in order to prevent condensation.
- (2) The plastic expansion particles are not provided. (As show in Fig. 10)




Fig.10

7. Connect Wire of Indoor Unit

- (1) Open the panel, remove the screw on the wiring cover and then take down the cover. (As show in Fig.11)




Fig.11

- (2) Make the power connection wire go through the cable-cross hole at the back of indoor unit and then pull it out from the front side. (As show in Fig.12)




Fig.12

- (3) Remove the wire clip, connect the power connection wire/signal control wire (only for cooling and heating unit) to the wiring terminal according to the color; tighten the screw and then fix the power connection wire with wire clip. (As show in Fig.13)




Fig.13

Note: The wiring connect is for reference only, please refer to the actual one.

- (4) Put wiring cover back and then tighten the screw.
- (5) Close the panel.

⚠ Note:

- (1) All wires of indoor unit and outdoor unit should be connected by a professional.
- (2) If the length of power connection wire is insufficient, please contact the supplier for a new one. Avoid extending the wire by yourself.
- (3) For the air conditioner with plug, the plug should be reachable after finishing installation.
- (4) For the air conditioner without plug, an air switch must be installed in the line. The air switch should be all-pole parting and the contact parting distance should be more than 3mm.

8. Bind up Pipe

- (1) Bind up the connection pipe, power cord and drain hose with the band. (As show in Fig.14)
- (2) Reserve a certain length of drain hose and power cord for installation when binding them. When binding to a certain degree, separate the indoor power and then separate the drain hose. (As show in Fig.15)
- (3) Bind them evenly.
- (4) The liquid pipe and gas pipe should be bound separately at the end.




Fig.14






Fig.15

Note:

- (1) The power cord and control wire can't be crossed or winding.
- (2) The drain hose should be bound at the bottom.

9. Hang the Indoor Unit

- (1) Put the bound pipes in the wall pipe and then make them pass through the wall hole.
- (2) Hang the indoor unit on the wall-mounting frame.
- (3) Stuff the gap between pipes and wall hole with sealing gum.
- (4) Fix the wall pipe.(As show in Fig.16)
- (5) Check if the indoor unit is installed firmly and closed to the wall.(As show in Fig.17)



Note:

Do not bend the drain hose too excessively in order to prevent blocking.



8.6 Installation of Outdoor Unit

1. Fix the Support of Outdoor Unit(Select it according to the actual installation situation)

- (1) Select installation location according to the house structure.
- (2) Fix the support of outdoor unit on the selected location with expansion screws.

Note:

- (1) Take sufficient protective measures when installing the outdoor unit.
- (2) Make sure the support can withstand at least four times the unit weight.
- (3) The outdoor unit should be installed at least 3cm above the floor in order to install drain joint.(As show in Fig.18)
- (4) For the unit with cooling capacity of 2300W-5000W, 6 expansion screws are needed; for the unit with cooling capacity of 6000W-8000W, 8 expansion screws are needed; for the unit with cooling capacity of 10000W-16000W, 10 expansion screws are needed.





2. Install Drain Joint(Only for cooling and heating unit)

- (1) Connect the outdoor drain joint into the hole on the chassis.
 - (2) Connect the drain hose into the drain vent.
- (As show in Fig.19)


3. Fix Outdoor Unit

- (1) Place the outdoor unit on the support.
 - (2) Fix the foot holes of outdoor unit with bolts.
- (As show in Fig.20)



4. Connect Indoor and Outdoor Pipes

- (1) Remove the screw on the right handle of outdoor unit and then remove the handle.(As show in Fig.21)
- (2) Remove the screw cap of valve and aim the pipe joint at the bellmouth of pipe.(As show in Fig.22)




- (3) Pretightening the union nut with hand.
- (4) Tighten the union nut with torque wrench.

Refer to the following table for wrench moment of force:

Piping size	Tightening torque(N·m)
1/4"	15~20
3/8"	30~40
1/2"	45~55
5/8"	60~65
3/4"	70~75

5. Connect Outdoor Electric Wire

(1) Remove the wire clip, connect the power connection wire and signal control wire (only for cooling and heating unit) to the wiring terminal according to the color, fix them with screws. (As show in Fig.23)



Note: the wiring connect is for reference only, please refer to the actual one.



(2) Fix the power connection wire and signal control wire with wire clip (only for cooling and heating unit).

⚠ Note:

- (1) After tightening the screw, pull the power cord slightly to check if it is firm.
- (2) Never cut the power connection wire to prolong or shorten the distance.


6. Neaten the Pipes

- (1) The pipes should be placed along the wall, bent reasonably and hidden possibly. Min. semidiameter of bending the pipe is 10cm.
- (2) If the outdoor unit is higher than the wall hole, you must set a U-shaped curve in the pipe before pipe goes into the room, in order to prevent rain from getting into the room. (As show in Fig.24)



⚠ Note:


- (1) The through-wall height of drain hose shouldn't be higher than the outlet pipe hole of indoor unit. (As show in Fig.25)
- (2) Slant the drain hose slightly downwards. The drain hose can't be curved, raised and fluctuant, etc. (As show in Fig.26)
- (3) The water outlet can't be placed in water in order to drain smoothly. (As show in Fig.27)



8.7 Vacuum Pumping and Leak Detection

1. Use Vacuum Pump

- (1) Remove the valve caps on the liquid valve and gas valve and the nut of refrigerant charging vent.
- (2) Connect the charging hose of piezometer to the refrigerant charging vent of gas valve and then connect the other charging hose to the vacuum pump.
- (3) Open the piezometer completely and operate for 10-15min to check if the pressure of piezometer remains in -0.1MPa.
- (4) Close the vacuum pump and maintain this status for 1-2min to check if the pressure of piezometer remains in -0.1MPa. If the pressure decreases, there may be leakage.
- (5) Remove the piezometer, open the valve core of liquid valve and gas valve completely with inner hexagon spanner.
- (6) Tighten the screw caps of valves and refrigerant charging vent. (As show in Fig.28)
- (7) Reinstall the handle.



2. Leak Detection

- (1) With leakage detector:
Check if there is leakage with leakage detector.
- (2) With soap water:
If leakage detector is not available, please use soap water for leakage detection. Apply soap water at the suspected position and keep the soap water for more than 3min. If there are air bubbles coming out of this position, there's a leakage.

8.8 Check after Installation and Test Operation

1. Check after Installation

Check according to the following requirement after finishing installation.

NO.	Items to be checked	Possible malfunction
1	Has the unit been installed firmly?	The unit may drop, shake or emit noise.
2	Have you done the refrigerant leakage test?	It may cause insufficient cooling (heating) capacity.
3	Is heat insulation of pipeline sufficient?	It may cause condensation and water dripping.
4	Is water drained well?	It may cause condensation and water dripping.
5	Is the voltage of power supply according to the voltage marked on the nameplate?	It may cause malfunction or damage the parts.
6	Is electric wiring and pipeline installed correctly?	It may cause malfunction or damage the parts.
7	Is the unit grounded securely?	It may cause electric leakage.
8	Does the power cord follow the specification?	It may cause malfunction or damage the parts.
9	Is there any obstruction in air inlet and air outlet?	It may cause insufficient cooling (heating) capacity.
10	The dust and sundries caused during installation are removed?	It may cause malfunction or damaging the parts.
11	The gas valve and liquid valve of connection pipe are open completely?	It may cause insufficient cooling (heating) capacity.
12	Is the inlet and outlet of piping hole been covered?	It may cause insufficient cooling(heating) capacity or waste electricity.

2. Test Operation

(1) Preparation of test operation

- The client approves the air conditioner installation.
- Specify the important notes for air conditioner to the client.

(2) Method of test operation

- Put through the power, press ON/OFF button on the remote controller to start operation.
- Press MODE button to select AUTO, COOL, DRY, FAN and HEAT to check whether the operation is normal or not.
- If the ambient temperature is lower than 16°C, the air conditioner can't start cooling.

9. Maintenance

9.1 Error Code List

Error code	Malfunction name	AC status	Possible causes
C5	Malfunction of jumper cap	The complete unit stops operation	1. Jumper cap is not installed in control panel; 2. Poor contact of jumper cap; 3. Jumper cap is damaged; 4. The tested circuit of jumper cap on control panel is abnormal.
E6	Communication malfunction between indoor unit and outdoor unit	Cool: compressor stops operation, while indoor fan operates; Heat: all loads stops operation.	See "Communication malfunction"
H5	IPM protection	Cool/Dry: compressor stops operation, while indoor fan operates. Heat: all loads stops operation.	See "IPM protection, over-phase current of compressor"
L3 LA	Malfunction of outdoor fan/ malfunction of DC motor	Cool/Dry: all loads stops operation except indoor fan. Heat: all loads stops operation.	1. Outdoor condenser, air inlet and air outlet are blocked by filth or dirt; 2. Fan is blocked or loosened; 3. Motor or connection wire of motor is damaged; 4. Main board of outdoor unit is damaged; (As for dual-outdoor fan, L3 indicates fan 1; LA indicates fan 2)
H3	Overload protection of compressor	Cool/Dry: compressor stops operation, while indoor fan operates. Heat: all loads stops operation.	1. Overload wire of compressor is loose; 2. The overload protector is damaged. Under normal circumstances, the resistance between both ends of terminal is less than 1ohm. 3. See "Overload protection of compressor, High discharge temperature protection of compressor"
F0	Refrigerant insufficient protection, cut-off protection of refrigerant	Cool: compressor and outdoor fan stops operation, while indoor fan operates; Heat: Compressor, outdoor fan and indoor fan stops operation.	1. Is system cooling under high humidity environment, thus temperature difference of heat transfer is small; 2. Check whether the big valve and small valve of outdoor unit are opened completely; 3. Is the temperature sensor of evaporator of indoor unit loose? 4. Is the temperature sensor of condenser of outdoor unit loose? 5. Is the capillary or the electronic expansion valve blocked? 6. Is refrigerant leaking?
F1	Indoor ambient temperature sensor is open/short-circuited	Cool/Dry: indoor fan operates, while compressor and outdoor fan stops operation; Heat: all loads stops operation.	1. Temperature sensor is not well connected; 2. Temperature sensor is damaged 3. Main board of indoor unit is damaged.
F2	Indoor evaporator temperature sensor is open/short-circuited	Cool/Dry: indoor fan operates, while compressor and outdoor fan stops operation; Heat: all loads stops operation.	1. Temperature sensor is not well connected; 2. Temperature sensor is damaged 3. Main board of indoor unit is damaged.
H6	No feedback from indoor unit's motor	The complete unit stops operation	1. Is the fan blocked? 2. Is the motor terminal loose? 3. Is the connection wire of motor damaged? 4. Is the motor damaged? 5. Is the main board of indoor unit damaged?
LP	Indoor unit and outdoor unit can be matched with each other	Heat: compressor, outdoor unit and indoor fan stops operation.	Capacity of indoor unit and outdoor unit can't be matched.
C4	Malfunction of jumper cap of outdoor unit	Heat: all loads are stopped; other modes: outdoor unit stops operation.	Jumper cap of outdoor unit hasn't been installed.
b7	Gas valve temperature sensor is ON / short-circuited		1. Temperature sensor is not well connected or damaged; 2. The wire of temperature sensor is damaged, causing short circuit to copper pipe or outer casing; 3. Main board of outdoor unit is damaged.

Error code	Malfunction name	AC status	Possible causes
b5	Liquid valve temperature sensor is ON / short-circuited		1. Temperature sensor is not well connected or damaged; 2. The wire of temperature sensor is damaged, causing short circuit to copper pipe or outer casing; 3. Main board of outdoor unit is damaged.
E1	High pressure protection of system	Cool/Dry: all loads stops operation except indoor fan; Heat: all loads stops operation.	1. Heat exchange of outdoor unit is too dirty, or it blocked the air inlet/outlet; 2. Is power voltage normal; (three-phase unit) 3. Ambient temperature is too high; 4. Wiring of high pressure switch is loose or high pressure switch is damaged; 5. The internal system is blocked; (dirt blockage, ice blockage, oil blockage, angle valve is not completely opened) 6. Main board of outdoor unit is damaged; 7. Refrigerant is too much.
E3	Low pressure/low system pressure protection/ compressor low pressure protection	Cool: compressor, outdoor fan and indoor fan stop operation; Heat: compressor and outdoor fan stop operation at first. About 1min later, indoor fan stops operation; 2mins later, the 4-way valve stop operation.	1. Low pressure switch is damaged; 2. Refrigerant inside the system is insufficient.
E4	High discharge temperature protection of compressor	Cool/Dry: compressor and outdoor fan stops operation, while indoor fan operates; Heat: all loads stops operation.	See "Overload protection of compressor", High discharge temperature protection of compressor"
E5	AC overcurrent protection	Cool/Dry: compressor and outdoor fan stops operation, while indoor fan operates; Heat: all loads stops operation.	1. Power voltage is unstable; 2. Power voltage is too low; 3. System load is too high, which leads to high current; 4. Heat exchange of indoor unit is too dirty, or it blocked the air inlet/outlet; 5. Fan motor operation is abnormal; the fan speed is too low or not functioning; 6. Compressor is blocked; 7. The internal system is blocked; (dirt blockage, ice blockage, oil blockage, angle valve is not completely opened) 8. Main board of outdoor unit is damaged. See "AC overcurrent protection"
E7	Mode shock/system mode shock	Load of indoor unit stops operation (indoor fan, E-Heater, swing)	Malfunction of one-to-more system; there may be two indoor units which has set the shock mode, such as one is cooling and the other is heating.
E8	High temperature prevention protection	Cool: compressor stops operation while indoor fan operates; Heat: all loads stops operation.	See "High temperature prevention protection; high power, system is abnormal"
EE	Malfunction of EEPROM	Cool/Dry: compressor stops operation, while indoor fan operates; Heat: all loads stops operation.	Main board of outdoor unit is damaged.
F0	Refrigerant-recovery mode	Cool/Dry: compressor and outdoor fan stops operation, while indoor fan operates.	Refrigerant recovery. The maintenance personnel operate it when he is maintaining the unit.
F3	Outdoor ambient temperature is open/short-circuited	Cool/Dry: compressor and outdoor fan stop operation, while indoor fan operates; Heat: all loads stops operation.	1. Temperature sensor is not connected well or damaged; 2. Temperature sensor wire of outdoor unit is damaged; short circuit between the temperature sensor and copper pipe or outer case 3. Main board of outdoor unit is damaged;

Error code	Malfunction name	AC status	Possible causes
F4	Outdoor condenser temperature sensor is open/short-circuited	Cool/Dry: compressor and outdoor fan stop operation, while indoor fan operates; Heat: after operating for 3mins, all loads stops operation.	1. Temperature sensor is not connected well or damaged; 2. Temperature sensor wire of outdoor unit is damaged; short circuit between the temperature sensor and copper pipe or outer case; 3. Main board of outdoor unit is damaged.
F5	Outdoor air discharge temperature is open/short-circuited	Complete unit stops operation; motor of sliding door is out of power.	1. The exhaust temperature sensor is not connected well or damaged. 2. Temperature sensor wire of outdoor unit is damaged; short circuit between the temperature sensor and copper pipe or outer case 3. Main board of outdoor unit is damaged.
FC	Malfunction of micro switch	Cool/Dry: compressor stops operation, while indoor fan operates; Heat: all loads stops operation.	1. The sliding door is blocked; 2. Malfunction of the photoelectric inspection panel of sliding door;
H4	System is abnormal	Cool/Dry: all loads stops operation except indoor fan; Heat: all loads stops operation.	See "High temperature prevention protection; high power; system is abnormal"
H7	Desynchronizing of compressor	Cool/Dry: compressor stops operation, while indoor fan operates; Heat: all loads stops operation.	See "Desynchronization diagnosis for compressor"
HC	PFC protection	Cool/Dry: compressor stops operation, while indoor fan operates; Heat: all loads stops operation.	1. The power grid quality is bad; AC input voltage fluctuates sharply; 2. Power plug of air conditioner or wiring board or reactor is not connected reliably; 3. Indoor and outdoor heat exchanger is too dirty, or air inlet/outlet is blocked; 4. Main board of outdoor unit is damaged.
HE	Demagnetization protection of compressor	Cool: compressor and outdoor fan stop operation; Heat: compressor and outdoor fan stop operation at first; about 1min later, indoor fan stops operation.	1. The main board of outdoor unit is damaged; 2. Compressor is damaged;
JF	Communication malfunction between indoor unit and inspection board	Normal operation	1. Poor connection between the indoor unit and the inspection board. 2. The main board of indoor unit is damaged; 3. The inspection board is damaged;
L1	Malfunction of humidity sensor	Compressor, outdoor fan and indoor fan stop operation;	The inspection board is damaged.
L9	High power protection	Cool: compressor and outdoor fan stops operation, while indoor fan operates.	See "High temperature prevention protection; high power; system is abnormal"
Lc	Start-up failed	Cool/Dry: compressor stops, while indoor fan operates; Heat: all loads stops operation.	See "Malfunction diagnosis for failure startup"
Ld	Lost phase	Cool: compressor and outdoor fan stop operation; Heat: compressor and outdoor fan stop operation at first; about 1min later, indoor fan stops operation.	1. The main board of outdoor unit is damaged; 2. The compressor is damaged; 3. The connection wire of compressor is not connected well.
PS	Over-phase current protection of compressor	Cool/Dry: compressor stops operation, while indoor fan operates; Heat: all loads stops operation.	See "Overload protection of compressor", High discharge temperature protection of compressor"

Error code	Malfunction name	AC status	Possible causes
OE	Undefined outdoor unit error	Cool: compressor and outdoor fan stops operation, while indoor fan operates; Heat: compressor, outdoor fan and indoor fan stop operation.	1. Outdoor ambient temperature exceeds the operation range of unit (eg: less than -20°C or more than 60°C for cooling; more than 30°C for heating); 2. Are wires of compressor not connected tightly? 3. Failure startup of compressor? 4. Is compressor damaged? 5. Is main board damaged?
PE	Communication malfunction between the drive board and the main board	Cool: compressor and outdoor fan stops operation; Heat: compressor and outdoor fan stop at first; about 1min later, indoor fan stops operation;	1. The drive board is damaged; 2. The main board of outdoor unit is damaged; 3. The drive board and the main board is not connected well.
PF	Circuit malfunction of module temperature sensor	Cool/Dry: compressor stops operation, while indoor fan operates; Heat: all loads stops operation.	Replace outdoor control board
PH	Module overheating protection	Cool: compressor stops operation, while indoor fan operates; Heat: all loads stops operation.	1. Air inlet / air outlet of outdoor unit are blocked by filth or dirt; 2. Condenser of outdoor unit is blocked by filth or dirt; 3. IPM screw of main board is not tightened; 4. Main board of outdoor unit is damaged;
PI	Malfunction of ambient temperature sensor of drive board	Cool: compressor, outdoor fan and indoor fan stop operation; Heat: compressor and outdoor fan stop operation at first; about 1min later, indoor fan stops operation.	1. The ambient temperature sensor of the drive board is not connected well; 2. Malfunction of the ambient temperature sensor of drive board.
PH	DC bus voltage is too high	Cool/Dry: compressor stops operation, while indoor fan operates; Heat: all loads stops operation.	1. Measure the voltage between position L and position N on the wiring board (XT). If it's higher than 265 VAC, please turn on the unit until the power voltage is decreased to the normal range; 2. If the AC input is normal, please replace the outdoor control board.
PL	DC bus voltage is too low	Cool/Dry: compressor stops operation, while indoor fan operates; Heat: all loads stops operation.	1. Measure the voltage between position L and position N on the wiring board (XT). If it's lower than 150 VAC, please turn on the unit until the power voltage is increased to the normal range; 2. If the AC input is normal, please replace the outdoor control board.
PU	Charging malfunction of capacitor	Cool/Dry: compressor stops operation, while indoor fan operates; Heat: all loads stops operation.	See "Charging malfunction of capacitor"
RF	Malfunction of RF module	Cool: compressor and outdoor fan stop operation; Heat: compressor and outdoor fan stop operation at first; about 1min later, indoor fan stops operation.	1. The connection wire of RF module is not connected well. 2. Malfunction of RF module;
UI	Phase current detection circuit malfunction of	Cool: compressor and outdoor fan stops operation, while indoor fan operates; Heat: compressor, outdoor fan and indoor fan stops operation.	The control board is damaged
U2	Lost phase protection of compressor	Cool: compressor and outdoor fan stop operation; Heat: compressor and outdoor fan stop operation at first; about 1min later, indoor fan stops operation.	1. The main board of outdoor unit is damaged; 2. The compressor is damaged; 3. The connection wire of compressor is not connected well.

Error code	Malfunction name	AC status	Possible causes
U3	DC bus voltage drop malfunction	Cool/Dry: compressor stops operation, while indoor fan operates; Heat: all loads stops operation.	The power voltage is unstable.
U5	Current detection malfunction of unit	Cool: compressor and outdoor fan stops operation, while indoor fan operates; Heat: compressor, outdoor fan and indoor fan stops operation.	1. Is the complete unit lacking of refrigerant? 2. There's malfunction for the circuit of control board of outdoor unit. Replace the control board of outdoor unit.
U7	4-way valve is abnormal	This malfunction occurs when the unit is heating. All loads stops operation.	1. Power voltage is lower than AC175V; 2. Wiring terminal of 4-way valve is loose or broken; 3. 4-way valve is damaged. Replace the 4-way valve.
U8	Malfunction of zero-crossing signal of indoor unit	Compressor, outdoor fan and indoor fan stop operation.	1. The power is abnormal; 2. Main board of indoor unit is damaged.
U9	Zero-crossing malfunction of outdoor unit	Cool: compressor stops operation, while indoor fan operates; Heat: all loads stops operation.	Replace the control board of outdoor unit.
E2	Evaporator anti-freezing protection		Not error code, it is the status code in cooling process
E9	Anti cold air protection		Not error code, it is the status code in cooling process
	Defrosting	Heat indicator Flash once/10s	Not error code, it is the status code in cooling process

Analysis or processing of some of the malfunction display:

1. Compressor discharge protection

Possible causes: shortage of refrigerant; blockage of air filter; poor ventilation or air flow short pass for condenser; the system has noncondensing gas (such as air, water etc.); blockage of capillary assy (including filter); leakage inside four-way valve causes incorrect operation; malfunction of compressor; malfunction of protection relay; malfunction of discharge sensor; outdoor temperature too high.

Processing method: refer to the malfunction analysis in the above section.

2. Low voltage overcurrent protection

Possible cause: Sudden drop of supply voltage.

3. Communication malfunction

Processing method: Check if communication signal cable is connected reliably.

4. Sensor open or short circuit

Processing method: Check whether sensor is normal, connected with the corresponding position on the controller and if damage of lead wire is found.

5. Compressor over load protection

Possible causes: insufficient or too much refrigerant; blockage of capillary and increase of suction temp.; improper running of compressor, burning in or stuck of bearing, damage of discharge valve; malfunction of protector.

Processing method: adjust refrigerant amount; replace the capillary; replace the compressor; use universal meter to check if the contactor of compressor is fine when it is not overheated, if not replace the protector.

6. System malfunction

i.e. overload protection. When tube temperature (Check the temperature of outdoor heat exchanger when cooling and check the temperature of indoor heat exchanger when heating) is too high, protection will be activated.

Possible causes: Outdoor temperature is too high when cooling; Insufficient outdoor air circulation; refrigerant flow malfunction.

please refer to the malfunction analysis in the previous section for handling method.

7. IPM module protection


Processing method: Once the module malfunction happens, if it persists for a long time and can not be self-canceled, cut off the power and turn off the unit, and then re-energize the unit again after about 10 min. After repeating the procedure for several times, if the malfunction still exists, replace the module.

9.2 Procedure of Troubleshooting

1. Troubleshooting for jumper cap C5

Main check points:


(1) jumper cap (2) control board of indoor unit



2. Communication malfunction §6

Main check points:

- (1) Connection wire between indoor unit and outdoor unit
- (2) Wiring inside the unit
- (3) Communication circuit of control board of indoor unit
- (4) Communication circuit of control board of outdoor unit




3. IPM protection H5, over-phase current of compressor P5

Main check points:

- (1) compressor COMP terminal (2) power supply voltage (3) compressor
- (4) charging amount of refrigerant (5) air inlet and air outlet of indoor/outdoor unit

NOTE: The control board as below means the control board of outdoor unit.




4. Overload protection of compressor H3, high discharge temperature, protection of compressor E4

Main check points:

(1) electronic expansion valve (2) expansion valve terminal

(3) charging amount of refrigerant (4) overload protector


NOTE: The control board as below means the control board of outdoor unit.



5. Troubleshooting for temperature sensor F1, F2, F3, F4, F5

Main check points:

(1) connection terminal (2) temperature sensor (3) main board




6.High temperature prevention protection E8; high power L9; system is abnormal H4

Main check points:

(1) outdoor temperature (2) fan (3)air inlet and air outlet of indoor/outdoor unit

NOTE: The control board as below means the control board of outdoor unit.




7.Desynchronization diagnosis for compressor H7

Main check point:

(1) system pressure (2) power supply voltage

NOTE:The control board as below means the control board of outdoor unit.




8. Malfunction diagnosis for failure startup L_c

Main check points:

(1) compressor wire (2) compressor (3) charging amount of refrigerant

NOTE: The control board as below means the control board of outdoor unit.




9. Charging malfunction of capacitor PU

Main check points:

(1) wiring board XT (2) reactor

NOTE: The control board as below means the control board of outdoor unit.





10. Troubleshooting-motor(indoor fan) doesn't operate H5


Main check points:

(1) connection terminal (2) motor (3) control board AP1 of indoor unit (4) blade


10.1 DC motor



10.2 PG motor



11. AC overcurrent protection ES



9.3 Troubleshooting for Normal Malfunction

1. Air Conditioner can't be Started Up

Possible Causes	Discriminating Method (Air conditioner Status)	Troubleshooting
No power supply, or poor connection for power plug	After energization, operation indicator isn't bright and the buzzer can't give out sound	Confirm whether it's due to power failure. If yes, wait for power recovery. If not, check power supply circuit and make sure the power plug is connected well.
Wrong wire connection between indoor unit and outdoor unit, or poor connection for wiring terminals	Under normal power supply circumstances, operation indicator isn't bright after energization	Check the circuit according to circuit diagram and connect wires correctly. Make sure all wiring terminals are connected firmly
Electric leakage for air conditioner	After energization, room circuit breaker trips off at once	Make sure the air conditioner is grounded reliably. Make sure wires of air conditioner is connected correctly. Check the wiring inside air conditioner. Check whether the insulation layer of power cord is damaged; if yes, place the power cord.
Model selection for air switch is improper	After energization, air switch trips off	Select proper air switch
Malfunction of remote controller	After energization, operation indicator is bright, while no display on remote controller or buttons have no action.	Replace batteries for remote controller. Repair or replace remote controller.

2. Poor Cooling (Heating) for Air Conditioner

Possible Causes	Discriminating Method (Air conditioner Status)	Troubleshooting
Set temperature is improper	Observe the set temperature on remote controller	Adjust the set temperature
Rotation speed of the IDU fan motor is set too low	Small wind blow	Set the fan speed at high or medium
Filter of indoor unit is blocked	Check the filter to see its blocked	Clean the filter
Installation position for indoor unit and outdoor unit is improper	Check whether the installation position is proper according to installation requirement for air conditioner	Adjust the installation position, and install the rainproof and sunproof for outdoor unit
Refrigerant is leaking	Discharged air temperature during cooling is higher than normal discharged wind temperature; Discharged air temperature during heating is lower than normal discharged wind temperature; Units pressure is much lower than regulated range	Find out the leakage causes and deal with it. Add refrigerant.
Malfunction of 4-way valve	Blow cold wind during heating	Replace the 4-way valve
Malfunction of capillary	Discharged air temperature during cooling is higher than normal discharged wind temperature; Discharged air temperature during heating is lower than normal discharged wind temperature; Unit pressure is much lower than regulated range. If refrigerant isn't leaking, part of capillary is blocked	Replace the capillary
Flow volume of valve is insufficient	The pressure of valves is much lower than that stated in the specification	Open the valve completely
Malfunction of horizontal louver	Horizontal louver can't swing	Refer to point 3 of maintenance method for details
Malfunction of the IDU fan motor	The IDU fan motor can't operate	Refer to troubleshooting for H5 for maintenance method in details
Malfunction of the ODU fan motor	The ODU fan motor can't operate	Refer to point 4 of maintenance method for details
Malfunction of compressor	Compressor can't operate	Refer to point 5 of maintenance method for details

3. Horizontal Louver can't Swing

Possible Causes	Discriminating Method (Air conditioner Status)	Troubleshooting
Wrong wire connection, or poor connection	Check the wiring status according to circuit diagram	Connect wires according to wiring diagram to make sure all wiring terminals are connected firmly
Stepping motor is damaged	Stepping motor can't operate	Repair or replace stepping motor
Main board is damaged	Others are all normal, while horizontal louver can't operate	Replace the main board with the same model

4. ODU Fan Motor can't Operate

Possible causes	Discriminating method (air conditioner status)	Troubleshooting
Wrong wire connection, or poor connection	Check the wiring status according to circuit diagram	Connect wires according to wiring diagram to make sure all wiring terminals are connected firmly
Capacity of the ODU fan motor is damaged	Measure the capacity of fan capacitor with an universal meter and find that the capacity is out of the deviation range indicated on the nameplate of fan capacitor.	Replace the capacity of fan
Power voltage is a little low or high	Use universal meter to measure the power supply voltage. The voltage is a little high or low	Suggest to equip with voltage regulator
Motor of outdoor unit is damaged	When unit is on, cooling/heating performance is bad and ODU compressor generates a lot of noise and heat	Change compressor oil and refrigerant. If no better, replace the compressor with a new one

5. Compressor can't Operate

Possible causes	Discriminating method (air conditioner status)	Troubleshooting
Wrong wire connection, or poor connection	Check the wiring status according to circuit diagram	Connect wires according to wiring diagram to make sure all wiring terminals are connected firmly
Capacity of compressor is damaged	Measure the capacity of fan capacitor with an universal meter and find that the capacity is out of the deviation range indicated on the nameplate of fan capacitor.	Replace the compressor capacitor
Power voltage is a little low or high	Use universal meter to measure the power supply voltage. The voltage is a little high or low	Suggest to equip with voltage regulator
Coil of compressor is burnt out	Use universal meter to measure the resistance between compressor terminals and it's 0	Repair or replace compressor
Cylinder of compressor is blocked	Compressor can't operate.	Repair or replace compressor

6. Air Conditioner is Leaking

Possible causes	Discriminating method (air conditioner status)	Troubleshooting
Drain pipe is blocked	Water leaking from indoor unit	Eliminate the foreign objects inside the drain pipe
Drain pipe is broken	Water leaking from drain pipe	Replace drain pipe
Wrapping is not tight	Water leaking from the pipe connection place of indoor unit	Wrap it again and bundle it tightly


7. Abnormal Sound and Vibration

Possible causes	Discriminating method (air conditioner status)	Troubleshooting
When turn on or turn off the unit, the panel and other parts will expand and theres abnormal sound	Theres the sound of "PAPA"	Normal phenomenon. Abnormal sound will disappear after a few minutes.
When turn on or turn off the unit, theres abnormal sound due to flow of refrigerant inside air conditioner	Water-running sound can be heard	Normal phenomenon. Abnormal sound will disappear after a few minutes.
Foreign objects inside the indoor unit or therere parts touching together inside the indoor unit	Theres abnormal sound fro indoor unit	Remove foreign objects. Adjust all parts position of indoor unit, tighten screws and stick damping plaster between connected parts
Foreign objects inside the outdoor unit or therere parts touching together inside the outdoor unit	Theres abnormal sound fro outdoor unit	Remove foreign objects. Adjust all parts position of outdoor unit, tighten screws and stick damping plaster between connected parts
Short circuit inside the magnetic coil	During heating, the way valve has abnormal electromagnetic sound	Replace magnetic coil
Abnormal shake of compressor	Outdoor unit gives out abnormal sound	Adjust the support foot mat of compressor, tighten the bolts
Abnormal sound inside the compressor	Abnormal sound inside the compressor	If add too much refrigerant during maintenance, please reduce refrigerant properly. Replace compressor for other circumstances.

10. Exploded View and Parts List

10.1 Indoor Unit

AUC




The component picture is only for reference; please refer to the actual product.

NO.	Description
1	Front Panel
2	Filter Sub-Assy
3	Screw Cover
4	Front Case
5	Guide Louver (upper)
6	Guide Louver (lower)
7	Plug Pin
8	Swing Lever
9	Air Louver (left)
10	Helicoid Tongue
11	Left Axle Bush
12	Rear Case
13	Drainage Hose
14	Ring of Bearing
15	O-Gasket sub-assy of Bearing
16	Evaporator Support
17	Wall Mounting Frame
18	Wall Mounting Frame
19	Cross Flow Fan
20	Motor Press Plate
21	Brushless DC Motor
22	Connecting pipe clamp

NO.	Description
23	Rubber Plug (Water Tray)
24	Stepping Motor
25	Crank
26	Stepping Motor
27	Plasmacluster Ion
28	Air Louver
29	Stepping Motor
30	Air Louver(right)
31	Electric Box
32	Main Board
33	Jumper
34	Supporter
35	Terminal Board
36	Cable Clamp 2
37	Electric Box Assy
38	Electric Box Cover
39	Display Board
40	Front Panel Assy
41	Remote Controller
42	Temperature Sensor
43	Connecting Cable
44	UV sterilizing lamp

Some models may not contain some parts, please refer to the actual product.

AUD:



The component picture is only for reference; please refer to the actual product.


NO.	Description
1	Front Panel
2	Front Case Assy
3	Guide Louver Sub-assy 1
4	Guide Louver Sub-assy 2
5	Plug Pin
6	Left Axle Bush
7	Rear Case
8	Cross Flow Fan
9	Ring of Bearing
10	O-Gasket sub-assy of Bearing
11	Evaporator Support
12	Evaporator Assy
13	Fan Motor
14	Motor Press Plate
15	Wall Mounting Frame Sub-assy
16	Electric Box Assy
17	Connecting pipe clamp
18	Rubber Plug (Water Tray)
19	Supporter
20	Electric Box
21	Main Board

NO.	Description
22	Jumper
23	Stepping Motor
24	Stepping Motor
25	Crank
26	Drainage Hose
27	Filter Sub-Assy
28	Screw Cover
29	Electric Box Cover
30	Remote Controller
31	Connecting Cable
32	Connecting Cable
33	Power Cord
34	Temperature Sensor
35	Plasmacluster Ion
36	Stepping Motor
37	Terminal Board
38	Display Board
39	Right Decorative Board
40	Left Decorative Board
41	UV sterilizing lamp

Some models may not contain some parts, please refer to the actual product.

10.2 Outdoor Unit

GWH09AUCXB-K6DNA1A/O




The component is only for reference; please refer to the actual product

NO.	Description
1	Coping
2	4-Way Valve
3	4-Way Valve Assy
4	Sponge(Condenser)
5	Temperature Sensor Support
6	Condenser Assy
7	Capillary Sub-assy
8	Sensor Insert
9	Right Side Plate
10	Earthing Plate Sub-Assy
11	Wire Clamp
12	Valve Cover
13	Silencer
14	Cut-off valve
15	Cut-off valve
16	Valve Support
17	Compressor and Fittings

NO.	Description
18	Chassis Sub-assy
19	Motor Support
20	Fan Motor
21	Axial Flow Fan
22	Cabinet
23	Front Grill
24	Drainage Joint(ODU)
25	Left Side Plate
26	Clapboard
27	Electric Box Assy
28	Electric Box
29	Main Board
30	Electric Box Cover
31	Terminal Board
32	Temperature Sensor
33	Radiator
34	Handle (Right)

Some models may not contain some parts, please refer to the actual product.




The component is only for reference, please refer to the actual product

NO.	Description
1	Coping
2	Supporting Board(Condenser)
3	4-Way Valve
4	Temperature Sensor Support
5	Condenser Assy
6	Temp Sensor Slewing
7	Sensor Insert
8	Handle
9	Right Side Plate
10	Earthing Plate Sub-assy
11	Wire Clamp
12	Electronic Expansion Valve
13	Electric Expand Valve Fitting
14	Valve Cover
15	Silencer
16	Cut off Valve Sub-Assy
17	Strainer
18	Cut off Valve Assy
19	Valve Support

NO.	Description
20	4-Way Valve Assy
21	Compressor and Fittings
22	Chassis Sub-assy
23	Motor Support
24	Brushless DC Motor
25	Axial Flow Fan
26	Cabinet
27	Front Grill
28	Drainage Joint(ODU)
29	Left Side Plate
30	Clapboard
31	Electric Box Assy
32	Electric Box
33	Main Board
34	Electric Box Cover
35	Terminal Board
36	Temperature Sensor
37	Radiator

Some models may not contain some parts, please refer to the actual product.

GWH18AUDXD-K6DNA1A/O GWH12AUCXD-K6DNA1C/O
(The front grill appearance is for reference only)




The component is only for reference; please refer to the actual product.

NO.	Description
1	Top Cover Assy
2	Condenser Assy
3	4-Way Valve
4	Temperature Sensor clamp
5	4-Way Valve Assy
6	Electric Expand Valve Fitting
7	Electric Expansion Valve Sub-Asy
8	Wire Clamp
9	Right Side Plate
10	Earthing Plate Sub-assy

NO.	Description
11	Handle
12	Valve Cover
13	Cut-off valve
14	Cut-off valve
15	Valve Support
16	Compressor and Fittings
17	Chassis Sub-assy
18	Cabinet
19	Front Grill
20	Axial Flow Fan
21	Brushless DC Motor

NO.	Description
22	Motor Support
23	Left Side Plate
24	Clapboard Assy
25	Electric Box Assy
26	Electric Box
27	Main Board
28	Electric Box Cover
29	Terminal Board
30	Temperature Sensor
31	Radiator


Some models may not contain some parts, please refer to the actual product.



The component picture is only for reference; please refer to the actual product.

NO.	Description	NO.	Description	NO.	Description
1	Front Panel Assy	13	Electronic Expansion Valve assy	25	Motor Support Sub
2	Front grill	14	Right Side Plate Assy	26	Top Cover Sub- Assy
3	Front Panel	15	Valve Support	27	Left Side Plate
4	Axial Flow Fan	16	Cut-off valve	28	Terminal Board
5	Drainage hole Cap	17	Cut-off valve	29	Electric Box Cover
6	Chassis Sub-assy	18	Valve Support Block	30	Main Board
7	Drainage Joint	19	Valve Cover	31	Radiator
8	Compressor and Fittings	20	Electronic Expand Valve Fitting	32	Electric Box Assy
9	Compressor Gasket	21	Sensor Insert	33	Electric Box
10	4-way valve	22	Temp Sensor Sleeving	34	Brushless DC Motor
11	4-way valve Sub-assy	23	Condenser Assy	35	Handle
12	Electronic Expansion Valve	24	Clapboard Sub- Assy		

Some models may not contain some parts, please refer to the actual product.



The component is only for reference; please refer to the actual product.

NO.	Description
1	Front Grill
2	Front Panel
3	Axial Flow Fan
4	Chassis Sub-assy
5	Compressor and Fittings
6	Electronic Expansion Valve Assy
7	Right Side Plate
8	Valve Support
9	Cut-off valve
10	Cut-off valve
11	Valve Cover
12	Handle
13	Terminal Board

NO.	Description
14	4-Way Valve Assy
15	Condenser Assy
16	Clapboard Assy
17	Motor Support
18	Brushless DC Motor
19	Top Cover Assy
20	Left Side Plate
21	Condenser Left Border Plate
22	Electric Box Assy
23	Radiator
24	Electric Box
25	Main Board
26	Electric Box Cover

Some models may not contain some parts, please refer to the actual product.

11. Removal Procedure



11.1 Removal Procedure of Indoor Unit



09/12K


Note: Take A1 blue panel for example.







Caution: discharge the refrigerant completely before removal.

Step	Procedure
Before disassemble	Turn off the air conditioner and disconnect the power before disassemble the air conditioner. 
1. Remove filter	Hold the handle on the filter, pull it upwards to let the clasp at the top part of the filter loose, push it forwards and then the filter can be pulled out. 
2. Remove upper and lower guide louver	Push out the plug pin on upper and lower guide louver, Bend the guide louver with hand and then separate the guide louver from the crank shaft of step motor to remove it. 

Step	Procedure
3.Remove panel	Open the front panel; separate the panel rotation shaft from the groove fixing the front panel and then removes the front panel. Note: The display of some models is fixed on the panel; unscrew the screws fixing the display on the panel before removing the panel. 
4.Remove electric box cover 2	Remove the screws on the electric box cover 2 to remove the electric box cover 2. 
5.Remove front case sub-assy	a Remove the screws fixing front case. Note: (1) Open the screw caps before removing the screws around the air outlet. (2) The quantity of screws fixing the front case sub-assy is different for different models. b Loosen the clasps at left, middle and right sides of front case. Lift the front case sub-assy upwards to remove it. 



Step	Procedure
6.Remove electric box assy	
a Remove the screw fixing electric box assy.	 Screw
b	① Cut off the wire binder and pull out the indoor tube temperature sensor. ② Screw off one grounding screw. ③ Remove the wiring terminals of motor, cold plasma generator and stepping motor. ④ Remove the electric box assy. ⑤ Screw off the screws that are locking each.  Grounding screw Indoor tube temperature sensor Electric box assy Main board Wire binder Screws
c	Rotate the electric box assy. Twist off the screws that are locking the wire clip and loosen the power cord. Remove the wiring terminal of power cord. Lift up the main board and take it off.  Power cord Screw Wire clip Instruction:Some wiring terminal of this products is with lock catch and other devices.The pulling method is as below: 1.Remove the soft sheath for some terminals at first, hold the circlip and then pull out the terminals, 2.Pull out the holder for some terminals at first(holder is not available for some wiring terminal).hold the connector and then pull the terminal.  Circlip Soft sheath Holder Connector




Step	Procedure
5.Remove panel	
a	Remove 3 screws fixing evaporator assy. 
b	At the back of the unit, Loosen the clasp of the connection pipe clamp and then remove the connection pipe clamp. 
c	First remove the left side of evaporator from the groove of bottom shell and then remove the right side from the clasp on the bottom shell. 
d	Adjust the position of connection pipe on evaporator slightly and then lift the evaporator upwards to remove it. 


Step	Procedure
8. Remove motor and cross flow fan a Remove the screw fixing motor clamp and then remove the motor clamp. b Loosen the screws (2-3 circles) used for fixing the cross flow fan, pull right to pull out the motor.	 Screw  Screw
9. Remove swing motor.	Screw off the screws that are locking the swing motor and take the motor off.  Screws





Caution: discharge the refrigerant completely before removal.

Step	Procedure
Before disassemble: Turn off the air conditioner and disconnect the power before disassemble the air conditioner.	
1. Remove filter Hold the handle on the filter, pull it upwards to let the clasp at the top part of the filter loose, push it forwards and then the filter can be pulled out.	
2. Remove upper and lower guide louver Push out the plug pin on upper and lower guide louver, Bend the guide louver with hand and then separate the guide louver from the crank shaft of step motor to remove it.	

Step	Procedure
3.Remove panel	Open the front panel; separate the panel rotation shaft from the groove fixing the front panel and then removes the front panel. Note: The display of some models is fixed on the panel; unscrew the screws fixing the display on the panel before removing the panel. 
4.Remove electric box cover 2	Remove the screws on the electric box cover 2 to remove the electric box cover 2. 
5.Remove front case sub-assy	a Remove the screws fixing front case. Note: (1) Open the screw caps before removing the screws around the air outlet. (2) The quantity of screws fixing the front case sub-assy is different for different models. b Loosen the clasps at the top of front case. Lift the front case sub-assy upwards to remove it. 

Step	Procedure
6.Remove electric box assy	
a Remove the screw fixing electric box assy.	 Screw
b	① Cut off the wire binder and pull out the indoor tube temperature sensor. ② Screw off one grounding screw. ③ Remove the wiring terminals of motor, cold plasma generator and stepping motor. ④ Remove the electric box assy. ⑤ Screw off the screws that are locking each.  Grounding screw Indoor tube temperature sensor Electric box assy Main board Motor wire Cold plasma generator wire Stepping motor wire Wire binder Screws
c	Rotate the electric box assy. Twist off the screws that are locking the wire clip and loosen the power cord. Remove the wiring terminal of power cord. Lift up the main board and take it off. NOTE: This step is only available for the indoor power supply unit.  Power cord Screw Wire clip Instruction: Some wiring terminal of this products is with lock catch and other devices. The pulling method is as below: 1.Remove the soft sheath for some terminals at first, hold the circlip and then pull out the terminals. 2.Pull out the holder for some terminals at first(holder is not available for some wiring terminal),hold the connector and then pull the terminal.  Circlip Soft sheath Holder Connector

Step	Procedure
5.Remove panel	
a	Remove 3 screws fixing evaporator assy.  The diagram shows a top-down view of the evaporator assembly. Three screws are indicated by lines pointing to them, with the label 'Screw' at the top.
b	At the back of the unit, Loosen the clasp of the connection pipe clamp and then remove the connection pipe clamp.  The diagram shows the back of the unit with the connection pipe clamp removed. A line points to the clamp area with the label 'connection pipe clamp'.
c	First remove the left side of evaporator from the groove of bottom shell and then remove the right side from the clasp on the bottom shell.  The diagram shows the evaporator being lifted from the bottom shell. A line points to the clasp on the bottom shell with the label 'Clasp'.
d	Adjust the position of connection pipe on evaporator slightly and then lift the evaporator upwards to remove it.  The diagram shows the evaporator with the connection pipe adjusted. A line points to the connection pipe with the label 'Connection pipe'.

Step	Procedure
8. Remove motor and cross flow fan a Remove the screw fixing motor clamp and then remove the motor clamp. b Loosen the screws (2-3 circles) used for fixing the cross flow fan, pull right to pull out the motor.	 Screw  Screw
9. Remove swing motor.	Screw off the screws that are locking the swing motor and take the motor off.  Screws


11.2 Removal Procedure of Outdoor Unit


GWH09AUCXB-K6DNA1/VO






Caution: discharge the refrigerant completely before removal.

Step	Procedure
1. Before disassembly	
2. Remove big handle and valve cover	Remove the screws fixing big handle, valve cover and then remove them. 
3. Remove top cover	Remove the screws fixing top panel and then remove the top panel. 

Step	Procedure
4. Remove front panel assy Remove connection screws connecting the front panel assy with the chassis and the motor support, and then remove the front panel assy.	 Front panel assy
5. Remove right side plate assy Rescrew the ground-screws, remove the ground wires, loosen the screws fixing terminal board, remove the terminal board, rescrew the screws fixing the right plate, and remove the right side plate assy.	 Right side plate assy
6. Remove axial flow fan Remove the nut on the fan and then remove the axial flow fan.	 Nut Axial flow fan

Step	Procedure
7. Remove motor support and motor Remove the screws fixing the motor support and lift the motor support to remove it. Remove the screws fixing the motor and then remove the motor.	 Motor support Motor
8. Remove electric box assy Remove the terminals, lift up and rotate the electrical box assy to the right so that the snaps on the clapboard are removed and the electrical box assy are removed.	 Electric box assy
9. Remove clapboard assy Remove the screws fixing the clapboard assy and then remove the clapboard assy.	 Clapboard assy



Step	Procedure
10. Remove gas valve and liquid valve	Remove the valve support block, remove the screws fixing the gas valve and the liquid valve,unsolder the welding joint connecting the gas valve and the liquid valve, remove them. Note: Discharge the refrigerant completely before unsoldering; when unsoldering, wrap the gas valve with a wet cloth completely to avoid damage to the valve caused by high temperature. 
11. Remove 4-way valve and capillary	Unsolder the welding joints connecting capillary, and then remove it. Unsolder the welding joints connecting the 4-way valve assy with capillary sub-assy, compressor and condenser; remove the 4-way valve.Cooling only unit removes Discharge Tube and Inhalation Tube. Note: Before unsoldering the welding joint, wrap the 4-way valve with a wet cloth completely to avoid damage to the valve caused by high temperature. 
12. Remove compressor	Remove the 3 foot nuts on the compressor and then remove the compressor. 




Caution: discharge the refrigerant completely before removal.

Step	Procedure
1. Before disassembly	
2. Remove top cover	Remove the screws fixing top panel and then remove the top panel. 
3. Remove big handle and valve cover	Remove the screws fixing big handle, valve cover and then remove them. 


Step	Procedure
4. Remove front panel assy	Remove connection screws connecting the front panel assy with the chassis and the motor support, and then remove the front panel assy. 
5. Remove right side plate assy	Rescrew the ground screws, remove the ground wires, loosen the screws fixing terminal board, remove the terminal board, rescrew the screws fixing the right plate, and remove the right side plate assy. 
6. Remove valve support	Remove the valve support block, remove the screws fixing valve support, remove the screws fixing the liquid valve and gas valve, then remove the valve support. 

Step	Procedure
7. Remove gas valve and liquid valve	Unsolder the welding joint connecting the gas valve and the liquid valve, remove them. Note: Discharge the refrigerant completely before unsoldering; when unsoldering, wrap the gas valve with a wet cloth completely to avoid damage to the valve caused by high temperature.  liquid valve welding joint gas valve
8. Remove electronic expansion valve	Remove the terminals of the electronic expansion valve coil and rotate to remove the electronic expansion valve coil. Unsolder the welding joint connecting the electronic expansion valve and then remove the electronic expansion valve.  electric expand valve fitting electric expansion valve sub-assy welding joint
9. Remove electric box assy	Unplug the terminals, unscrew 1 screw that secures the electrical box assy, release the two snaps on the electrical box assy (in the clapboard and condenser angle), pull outwards, and remove the electrical box assy.  Electric Box Assy


Step	Procedure
10. Remove axial flow fan	Remove the nut on the fan and then remove the axial flow fan.  axial flow fan
11. Remove motor	Remove the screws fixing the motor and then remove the motor.  motor
12. Remove motor support	Remove the screws fixing the motor support and lift the motor support to remove it.  motor support


Step	Procedure
13. Remove 4-way valve assy Unsolder the welding joints connecting the 4-way valve assy, remove the 4-way valve. Note: Before unsoldering the welding joint, wrisp the 4-way valve with a wet cloth completely to avoid damage to the valve caused by high temperature.	
14. Remove clapboard assy Remove the screws fixing the clapboard assy and then remove the clapboard assy.	
15. Remove compressor Remove the 3 foot nuts on the compressor and then remove the compressor.	


Step	Procedure
1. Before disassembly	
2. Remove big handle and valve cover	Remove the screws fixing big handle, valve cover and then remove them. 
3. Remove top cover	Remove the screws fixing top panel and then remove the top panel. 


Step	Procedure
4. Remove front panel assy	Remove connection screws connecting the front panel assy with the chassis and the motor support, and then remove the front panel assy.  front panel
5. Remove right side plate assy	Rescrew the ground screws, remove the ground wires, loosen the screws fixing terminal board, remove the terminal board, rescrew the screws fixing the right plate, and remove the right side plate assy.  right side plate
6. Remove axial flow fan	Remove the nut on the fan and then remove the axial flow fan.  axial flow fan


Step	Procedure
7. Remove electric box assy Remove the terminals, lift up and rotate the electrical box assy to the right so that the snaps on the clapboard are removed and the electrical box assy are removed.	 Electric Box Assy
8. Remove motor. Remove the screws fixing the motor and then remove the motor.	 motor
9. Remove motor support Remove the screws fixing the motor support and lift the motor support to remove it.	 motor support


Step	Procedure
10. Remove gas valve and liquid valve	Remove the valve support block, remove the screws fixing the gas valve and the liquid valve,unsolder the welding joint connecting the gas valve and the liquid valve, remove them. Note: Discharge the refrigerant completely before unsoldering; when unsoldering, wrap the gas valve with a wet cloth completely to avoid damage to the valve caused by high temperature.  The diagram shows a side view of a refrigeration unit. Labels point to the 'welding joint' connecting the 'liquid valve' and 'gas valve'.
11. Remove valve support	Remove the screws fixing valve support, then remove the valve support.  The diagram shows a side view of a refrigeration unit. A label points to the 'valve support' block.
12. Remove 4-way valve assy	Unsolder the welding joints connecting the 4-way valve assy, remove the 4-way valve. Note: Before unsoldering the welding joint, wrap the 4-way valve with a wet cloth completely to avoid damage to the valve caused by high temperature.  The diagram shows a side view of a refrigeration unit. A label points to the '4-way valve assy'.


Step	Procedure
13. Remove electronic expansion valve	Remove the terminals of the electric expand valve fitting and rotate to remove the electric expand valve fitting. Unsolder the welding joint connecting the electronic expansion Valve and then remove the electronic expansion valve. 
14. Remove clapboard assy	Remove the screws fixing the clapboard assy and then remove the clapboard assy. 
15. Remove compressor	Remove the 3 foot nuts on the compressor and then remove the compressor. 


Step	Procedure
1. Before disassembly	
2. Remove valve cover	Remove the connection screw and then remove the valve cover. 
3. Remove big handle	Remove the connection screw and then remove the big handle. 

Step	Procedure
4. Remove top cover Remove connection screws connecting the top panel with the front panel and the right side plate, and then remove the top panel.	 top cover
5. Remove grille Remove connection screws between the front grille and the front panel. Then remove the grille.	 grille
6. Remove front panel Remove connection screws connecting the front panel with the chassis and the motor support and then remove the front panel.	 front panel

Step	Procedure
7. Remove right side plate Remove connection screws connecting the right side plate with the valve support and the electric box. Then remove the right side plate.	
8. Remove the nut and gasket on the blade and then remove the axial flow blade Remove the nut and gasket on the blade and then remove the axial flow blade.	
9. Remove motor and motor support Remove the tapping screws fixing the motor and disconnect the leading wire insert of the motor. Then remove the motor. Remove the tapping screws fixing the motor support and lift the motor support to remove it.	


Step	Procedure
10. Remove Electric Box Assy Remove screws fixing the electric box subassembly, loosen the wire bundle and unplug the wiring terminals. Then lift the electric box to remove it.	 Electric Box Assy
11. Remove isolation sheet Remove the screws fixing the isolation sheet and then remove the isolation sheet.	 isolation sheet
12. Remove cut-off valve Unsolder the welding joints connecting the liquid valve and gas valve, and then remove them. Note: Before unsoldering the welding joint, wrap the cut-off valve with a wet cloth completely to avoid damage to the valve caused by high temperature.	 liquid valve gas valve




Step	Procedure
13. Remove valve support Remove the screws fixing valve support, then remove the valve support.	 valve support
14. Remove 4-way valve assy Unsolder the welding joints connecting the 4-way valve assy, remove the 4-way valve. Note: Before unsoldering the welding joint, wrap the 4-way valve with a wet cloth completely to avoid damage to the valve caused by high temperature.	 4-way valve assy
15. Remove electronic expansion valve Remove the terminals of the electric expand valve fitting and rotate to remove the electric expand valve fitting. Unsolder the welding joint connecting the electronic expansion Valve and then remove the electronic expansion valve.	 electronic expansion valve

Step	Procedure
16. Remove left side plate	Remove the screws fixing the left side plate and then remove the left side plate. 
17. Remove condenser sub-assy	Remove the screws fixing the Remove condenser sub-assy and then remove the Remove condenser sub-assy. 
18. Remove compressor	Remove the 3 foot nuts on the compressor and then remove the compressor. 



Step	Procedure
1. Before disassembly	
2. Remove top cover	 Remove the screws fixing top panel and then remove the top panel.
3. Remove big handle and valve cover	 Remove the screws fixing big handle, valve cover and then remove them.

Step	Procedure
4. Remove front panel assy	Remove connection screws connecting the front panel assy with the chassis and the motor support, and then remove the front panel assy. 
5. Remove right side plate assy	Rescrew the ground screws, remove the ground wires, loosen the screws fixing terminal board, remove the terminal board, rescrew the screws fixing the right plate, and remove the right side plate assy. 
6. Remove gas valve and liquid valve	Remove the valve support block, remove the screws fixing the gas valve and the liquid valve, unsolder the welding joint connecting the gas valve and the liquid valve, remove them. Note: Discharge the refrigerant completely before unsoldering, when unsoldering, wrap the gas valve with a wet cloth completely to avoid damage to the valve caused by high temperature. 

Step	Procedure
7. Remove valve support	Remove the screws fixing valve support, then remove the valve support.  valve support
8. Remove electronic expansion valve	Remove the terminals of the electronic expansion valve coil and rotate to remove the electronic expansion valve coil. Unsolder the welding joint connecting the electronic expansion Valve and then remove the electronic expansion valve.  electric expansion valve sub-Assy welding joint
9. Remove electric box assy	Remove the terminals, lift up and rotate the electrical box assy to the right so that the snaps on the clashboard are removed and the electrical box assy are removed.  Electric Box Assy

Step	Procedure
10. Remove 4-way valve assy	Unsolder the welding joints connecting the 4-way valve assy, remove the 4-way valve. Note: Before unsoldering the welding joint, wrap the 4-way valve with a wet cloth completely to avoid damage to the valve caused by high temperature. 
11. Remove axial flow fan	Remove the nut on the fan and then remove the axial flow fan. 
12. Remove motor	Remove the screws fixing the motor and then remove the motor. 

Step	Procedure
12. Remove motor support Remove the screws fixing the motor support and lift the motor support to remove it.	 motor support
14. Remove clapboard assy Remove the screws fixing the clapboard assy and then remove the clapboard assy.	 clapboard assy
15. Remove compressor Remove the 3 foot nuts on the compressor and then remove the compressor.	 nut compressor

Appendix

Appendix 1: Reference Sheet of Celsius and Fahrenheit

Conversion formula for Fahrenheit degree and Celsius degree: $T_f = T_c \times 1.8 + 32$

Set temperature

Fahrenheit display temperature (°F)	Fahrenheit (°F)	Celsius (°C)	Fahrenheit display temperature (°F)	Fahrenheit (°F)	Celsius (°C)	Fahrenheit display temperature (°F)	Fahrenheit (°F)	Celsius (°C)
61	60.6	16	69/70	69.6	21	78/79	78.8	26
62/63	62.6	17	71/72	71.6	22	80/81	80.6	27
64/65	64.4	18	73/74	73.4	23	82/83	82.4	28
66/67	66.2	19	75/76	75.2	24	84/85	84.2	29
68	68	20	77	77	25	86	86	30

Ambient temperature

Fahrenheit display temperature (°F)	Fahrenheit (°F)	Celsius (°C)	Fahrenheit display temperature (°F)	Fahrenheit (°F)	Celsius (°C)	Fahrenheit display temperature (°F)	Fahrenheit (°F)	Celsius (°C)
32/33	32	0	55/56	55.4	13	79/80	78.8	26
34/35	33.8	1	57/58	57.2	14	81	80.6	27
36	35.6	2	59/60	59	15	82/83	82.4	28
37/38	37.4	3	61/62	60.8	16	84/85	84.2	29
39/40	39.2	4	63	62.6	17	86/87	86	30
41/42	41	5	64/65	64.4	18	88/89	87.8	31
43/44	42.8	6	66/67	66.2	19	90	89.6	32
45	44.6	7	68/69	68	20	91/92	91.4	33
46/47	46.4	8	70/71	69.8	21	93/94	93.2	34
48/49	48.2	9	72	71.6	22	95/96	95	35
50/51	50	10	73/74	73.4	23	97/98	96.8	36
52/53	51.8	11	75/76	75.2	24	99	98.6	37
54	53.6	12	77/78	77	25			

Appendix 2: Configuration of Connection Pipe

- Standard length of connection pipe (More details please refer to the specifications.)
- Min length of connection pipe for the unit with standard connection pipe of 5m, there is no limitation for them in length of connection pipe. For the unit with standard connection pipe of 7.5m and 8m, the min length of connection pipe is 3m.
- Max. length of connection pipe and max. high difference. (More details please refer to the specifications.)
- The additional refrigerant oil and refrigerant charging required after prolonging connection pipe
 - After the length of connection pipe is prolonged for 10m at the basis of standard length, you should add 5ml of refrigerant oil for each additional 5m of connection pipe.
 - The calculation method of additional refrigerant charging amount (on the basis of liquid pipe):
 - Basing on the length of standard pipe, add refrigerant according to the requirement as shown in the table. The additional refrigerant charging amount per meter is different according to the diameter of liquid pipe. See the following sheet.
 - Additional refrigerant charging amount = prolonged length of liquid pipe X additional refrigerant charging amount per meter

Additional refrigerant charging amount for R32				
Piping size		Indoor unit throttle	Outdoor unit throttle	
Liquid pipe	Gas pipe	Cooling only, cooling and heating (g/m)	Cooling only (g/m)	Cooling and heating (g/m)
1/4"	3/8" or 1/2"	14	12	16
1/4" or 3/8"	5/8" or 3/4"	40	12	40
1/2"	3/4" or 7/8"	60	24	96
5/8"	1" or 1 1/4"	136	48	96
3/4"	/	200	200	200
7/8"	/	280	280	280


Appendix 3: Pipe Expanding Method

Note:

Improper pipe expanding is the main cause of refrigerant leakage. Please expand the pipe according to the following steps:


A: Cut the pipe

- Confirm the pipe length according to the distance of indoor unit and outdoor unit.
- Cut the required pipe with pipe cutter.



B: Remove the burrs


- Remove the burrs with shaper and prevent the burrs from getting into the pipe.



C: Put on suitable insulating pipe.

D: Put on the union nut

- Remove the union nut on the indoor connection pipe and outdoor valve; install the union nut on the pipe.




E: Expand the port

- Expand the port with expander.

Note:


- "A" is different according to the diameter, please refer to the sheet below.

Outer diameter(mm)	A(mm)	
	Max	Min
Φ6 - 6.35 (1/4")	1.3	0.7
Φ9 - 9.52 (3/8")	1.6	1.0
Φ12 - 12.70 (1/2")	1.8	1.0
Φ16 - 15.88 (5/8")	2.4	2.2



F: Inspection

- Check the quality of expanding port. If there is any blemish, expand the port again according to the steps above.



Appendix 4: List of Resistance for Temperature Sensor

Resistance Table of Ambient Temperature Sensor for Indoor and Outdoor Units(15K)

Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)
-19	138.10	0	48.02	20	18.75	40	7.97
-18	128.60	2	44.31	22	17.14	42	7.35
-16	115.00	4	40.09	24	15.68	44	6.79
-14	102.90	6	36.32	26	14.36	46	6.28
-12	92.22	8	32.94	28	13.16	48	5.81
-10	82.75	10	29.90	30	12.07	50	5.38
-8	74.35	12	27.18	32	11.09	52	4.99
-6	66.88	14	24.73	34	10.20	54	4.63
-4	60.23	16	22.53	36	9.38	56	4.29
-2	54.31	18	20.54	38	8.64	58	3.99

Resistance Table of Tube Temperature Sensors for Indoor and Outdoor (20K)

Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)
-19	181.40	20	25.01	60	4.95	100	1.35
-15	145.00	25	20.00	65	4.14	105	1.16
-10	110.30	30	16.10	70	3.48	110	1.01
-5	84.61	35	13.04	75	2.94	115	0.88
0	65.37	40	10.62	80	2.50	120	0.77
5	50.87	45	8.71	85	2.13	125	0.67
10	39.87	50	7.17	90	1.82	130	0.59
15	31.47	55	5.94	95	1.56	135	0.52

Resistance Table of Discharge Temperature Sensor for Outdoor(50K)

Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)
-30	911.400	10	98	50	17.65	90	4.469
-25	860.8	15	77.35	55	14.62	95	3.841
-20	486.5	20	61.46	60	12.17	100	3.315
-15	362.9	25	49.19	65	10.18	105	2.872
-10	274	30	39.61	70	8.555	110	2.498
-5	209	35	32.08	75	7.224	115	2.182
0	161	40	26.15	80	6.129	120	1.912
5	125.1	45	21.43	85	5.222	125	1.682



JF00305011



GREE ELECTRIC APPLIANCES, INC. OF ZHUHAI

Add: West Jinji Rd, Qianshan, Zhuhai, Guangdong, China, 519070

Tel: (+86-756) 8522219

Fax: (+86-756) 8660428

E-mail: global@cn.gree.com

For product improvement, specifications and appearance in this manual are subject to change without prior notice.