SVEN PS-710/730/770/800 firmware update instructions

To update the firmware, do the following:

- 1) Copy the XXXXXX.MVA firmware file to USB flash drive. The flash drive must be in FAT32 format, only the file with the firmware should be in the USB flash drive;
- 2) Turn on the speaker (in any mode);
- 3) Insert the USB flash drive into the USB port of the speaker;
- 4) Wait about 30 seconds. Upon completion, the display will show "BLUE";
- 5) Turn off the speaker;
- 6) Remove the USB flash drive from speaker;
- 7) Turn speaker on;
- 8) The update is completed.

Инструкция по обновлению прошивки SVEN PS-710/730/770/800

Для обновления прошивки необходимо проделать следующее:

- 1) Записать на USB-flash накопитель файл с прошивкой XXXXXX.MVA. USB-flash должен быть отформатирован в FAT32, на USB-flash должен быть только файл с прошивкой;
- 2) Включить акустическую систему (в любом режиме);
- 3) Вставить USB-flash в USB порт акустической системы;
- 4) Подождать около 30 сек. По завершению на дисплее отобразится надпись «BLUE»;
- 5) Выключить акустическую систему;
- 6) Вытащить USB-flash накопитель;
- 7) Включить акустическую систему;
- 8) Обновление завершено.