




ASSEMBLY INSTRUCTION

ИНСТРУКЦИЯ

A3283LT-2BR



1



2