



Friends™

41441



 **WARNING: CHOKING HAZARD.**
Small parts. Not for children under 3 years.




AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.
Contient des petites pièces. Ne convient pas aux enfants de moins de 3 ans.






ADVERTENCIA: PELIGRO DE ASFIXIA.
No recomendado para niños menores de 3 años. Contiene piezas pequeñas.
















































































































































1x
6226644



1x
6301315



1x
6174193



1x
6253681



1x
6276993



1x
6344389



1x
6096109



1x
249626



6x
4568644



1x
300326



1x
6273226



1x
302126



1x
6199275



1x
6338416



1x
6102360



2x
6291040



1x
4211190



1x
6270119




1x
4621545



1x
6160819



2x
6097094



1x
6097710



3x
6286831



1x
4187743



1x
6133836



2x
6133225



2x
6152645



1x
6356469



1x
6139090



1x
6107188



1x
4651902



1x
4655173




5x
6269015



1x
6347555



1x
6343444



1x
6343443



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



00800 5346 5555 :



1-800-422-5346 :

