



# LUCIFER

User manual

1 Nut	4 pcs	2 Insulation Pillar	4 pcs	3 Screw Bolt	4 pcs	4 De-Vibration Buckle	4 pcs	5 Mounting Bracket(Intel)	2 pcs
6 Retention Plate	1 pc	7 Back Plate	1 pc	8 Mounting Bracket(AMD)	2 pcs	9 Insulating Washer	1pc	10 Double-screw Bolt(20X0)	4pcs
11 Thermal Grease	1 pc	12 Wire Clip	4 pcs	13 Metal Logo Sticker	1 pc	14 140mm Fan	1 pc	15 Heatsink Set	1 pc
16 Double-screw Bolt (AM4)	4pcs								

### INTEL

LGA1366  
LGA1156  
LGA1155  
LGA1150  
LGA775

Back plate installation (Intel)

### AMD

AM4  
AM3+  
AM3  
AM2+  
AM2  
FM2+  
FM2  
FM1

Back plate installation (AMD)

### INTEL

LGA20XX

Mounting Holes Illustration

www.gamersform.com

Beijing Deepcool Industries Co., Ltd.  
All rights reserved.  
Brands and designs are trademarks from Beijing Deepcool Industries Co., Ltd.



# 路西法

使用说明书

1 螺母	4个	2 绝缘柱	4个	3 螺柱	4个	4 减震扣	4个	5 Intel转接架	2个
6 扣具	1个	7 背板	1个	8 AMD转接架	2个	9 绝缘垫	1个	10 双头螺栓-20X0	4个
11 针管导热膏	1个	12 钢丝扣	4个	13 金属标贴	1个	14 140mm风扇	1个	15 散热器主体	1个
16 双头螺栓-AM4	4个								

### INTEL

LGA1366  
LGA1156  
LGA1155  
LGA1150  
LGA775

背板安装孔位说明

### AMD

AM4  
AM3+  
AM3  
AM2+  
AM2  
FM2+  
FM2  
FM1

背板安装孔位说明

### INTEL

LGA20XX

Intel转接架安装孔位说明

www.gamersform.com

Beijing Deepcool Industries Co., Ltd.  
All rights reserved.  
Brands and designs are trademarks from Beijing Deepcool Industries Co., Ltd.