



# CS-TKY-1000

## Тонер Cactus CS-TKY-1000

Бренд	Принтер	Картридж	Ресурс	Вес заправки	Примечание
Kyocera	Kyocera DP1400	TK-20	20000	870	
Kyocera	Kyocera DP1800	TK-20	20000	870	
Kyocera	Kyocera Ecosys M2030DN	TK-1130	3000	120	
Kyocera	Kyocera Ecosys M2030DN	TK-1140	7200	290	
Kyocera	Kyocera Ecosys M2040dn	TK-1170	7200	290	
Kyocera	Kyocera Ecosys M2135dn	TK-1150	3000	120	
Kyocera	Kyocera Ecosys M2235dn	TK-1200	3000	120	
Kyocera	Kyocera Ecosys M2235dn	TK-1200	3000	120	
Kyocera	Kyocera Ecosys M2530DN	TK-1140	7200	290	
Kyocera	Kyocera Ecosys M2530DN	TK-1130	3000	120	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Kyocera	Kyocera Ecosys M2540dn	TK-1170	7200	290	
Kyocera	Kyocera Ecosys M2540dw	TK-1170	7200	290	
Kyocera	Kyocera Ecosys M2635dn	TK-1150	3000	120	
Kyocera	Kyocera Ecosys M2635dw	TK-1150	3000	120	
Kyocera	Kyocera Ecosys M2640idv	TK-1170	7200	290	
Kyocera	Kyocera Ecosys M2735dn	TK-1150	3000	120	
Kyocera	Kyocera Ecosys M2735dn	TK-1200	3000	120	
Kyocera	Kyocera Ecosys M2735dw	TK-1200	3000	120	
Kyocera	Kyocera Ecosys M2835dw	TK-1200	3000	120	
Kyocera	Kyocera Ecosys M3040dn	TK-3100	12500	325	
Kyocera	Kyocera Ecosys M3040dn	TK-3100	12500	325	
Kyocera	Kyocera Ecosys M3040idn	TK-3150	14500	380	
Kyocera	Kyocera Ecosys M3145dn	TK-3160	12500	325	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Kyocera	Kyocera Ecosys M3145idn	TK-3060	14500	375	
Kyocera	Kyocera Ecosys M3540idn	TK-3150	14500	380	
Kyocera	Kyocera Ecosys M3550idn	TK-3130	25000	650	
Kyocera	Kyocera Ecosys M3560idn	TK-3130	25000	650	
Kyocera	Kyocera Ecosys M3645idn	TK-3060	14500	375	
Kyocera	Kyocera Ecosys M3655idn	TK-3190	25000	650	
Kyocera	Kyocera Ecosys M3660idn	TK-3190	25000	650	
Kyocera	Kyocera Ecosys M3860idn	TK-3200	40000	1150	
Kyocera	Kyocera Ecosys M3860idnf	TK-3200	40000	1150	
Kyocera	Kyocera Ecosys M4125idn	TK-6115	15000	510	
Kyocera	Kyocera Ecosys M4132idn	TK-6115	15000	510	
Kyocera	Kyocera Ecosys P2035d	TK-160	2500	100	
Kyocera	Kyocera Ecosys P2035dn	TK-160	2500	100	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Kyocera	Kyocera Ecosys P2040dn	TK-1160	7200	290	
Kyocera	Kyocera Ecosys P2040dw	TK-1160	7200	290	
Kyocera	Kyocera Ecosys P2135D	TK-170	7200	290	
Kyocera	Kyocera Ecosys P2135DN	TK-170	7200	290	
Kyocera	Kyocera Ecosys P2235dn	TK-1150	3000	120	
Kyocera	Kyocera Ecosys P2235dw	TK-1150	3000	120	
Kyocera	Kyocera Ecosys P2335d	TK-1200	3000	120	
Kyocera	Kyocera Ecosys P2335dn	TK-1200	3000	120	
Kyocera	Kyocera Ecosys P2335dw	TK-1200	3000	120	
Kyocera	Kyocera Ecosys P3045dn	TK-3160	12500	325	
Kyocera	Kyocera Ecosys P3050dn	TK-3160	12500	325	
Kyocera	Kyocera Ecosys P3050dn	TK-3170	15500	425	
Kyocera	Kyocera Ecosys P3055dn	TK-3190	25000	650	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Kyocera	Kyocera Ecosys P3055dn	TK-3170	15500	425	
Kyocera	Kyocera Ecosys P3055dn	TK-3160	12500	325	
Kyocera	Kyocera Ecosys P3060dn	TK-3160	12500	325	
Kyocera	Kyocera Ecosys P3060dn	TK-3190	25000	650	
Kyocera	Kyocera Ecosys P3060dn	TK-3170	15500	425	
Kyocera	Kyocera Ecosys P3150dn	TK-3170	15500	425	
Kyocera	Kyocera Ecosys P3150dn	TK-3160	12500	325	
Kyocera	Kyocera Ecosys P3260dn	TK-3200	40000	1150	
Kyocera	Kyocera Ecosys P4040dn	TK-7300	15000	520	
Kyocera	Kyocera FS-1000	TK-17	6000	290	
Kyocera	Kyocera FS-1010	TK-17	6000	290	
Kyocera	Kyocera FS-1016 MFP	TK-110	6000	290	
Kyocera	Kyocera FS-1018 MFP	TK-18	7200	290	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Kyocera	Kyocera FS-1020 MFP	TK-1110	2500	100	
Kyocera	Kyocera FS-1020D	TK-18	7200	290	
Kyocera	Kyocera FS-1024 MFP	TK-1100	2100	80	
Kyocera	Kyocera FS-1025 MFP	TK-1120	3000	120	
Kyocera	Kyocera FS-1028 MFP	TK-130	7200	290	
Kyocera	Kyocera FS-1030	TK-120	7200	290	
Kyocera	Kyocera FS-1030 MFP	TK-1140	7200	290	
Kyocera	Kyocera FS-1030 MFP	TK-1130	3000	120	
Kyocera	Kyocera FS-1040	TK-1110	2500	100	
Kyocera	Kyocera FS-1041	TK-1115	1600	65	
Kyocera	Kyocera FS-1050	TK-17	6000	290	
Kyocera	Kyocera FS-1060DN	TK-1120	3000	120	
Kyocera	Kyocera FS-1061DN	TK-1125	3000	120	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Kyocera	Kyocera FS-1100	TK-140	4000	180	
Kyocera	Kyocera FS-1100N	TK-140	4000	180	
Kyocera	Kyocera FS-1110	TK-1100	2100	80	
Kyocera	Kyocera FS-1116 MFP	TK-110	6000	290	
Kyocera	Kyocera FS-1118 MFP	TK-18	7200	290	
Kyocera	Kyocera FS-1120 MFP	TK-1110	2500	100	
Kyocera	Kyocera FS-1120d	TK-160	2500	100	
Kyocera	Kyocera FS-1120dn	TK-160	2500	100	
Kyocera	Kyocera FS-1124 MFP	TK-1100	2100	80	
Kyocera	Kyocera FS-1125 MFP	TK-1120	3000	120	
Kyocera	Kyocera FS-1128 MFP	TK-130	7200	290	
Kyocera	Kyocera FS-1130 MFP	TK-1130	3000	120	
Kyocera	Kyocera FS-1130 MFP	TK-1140	7200	290	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Kyocera	Kyocera FS-1300	TK-130	7200	290	
Kyocera	Kyocera FS-1320D	TK-170	7200	290	
Kyocera	Kyocera FS-1325 MFP	TK-1125	3000	120	
Kyocera	Kyocera FS-1350DN	TK-130	7200	290	
Kyocera	Kyocera FS-1370DN	TK-170	7200	290	
Kyocera	Kyocera FS-1370DN	TK-170	7200	290	
Kyocera	Kyocera FS-1500	TK-100	6000	290	
Kyocera	Kyocera FS-1700	TK-20	20000	870	
Kyocera	Kyocera FS-1750	TK-20	20000	870	
Kyocera	Kyocera FS-1920	TK-55	15000	520	
Kyocera	Kyocera FS-2000	TK-310	12000	480	
Kyocera	Kyocera FS-2020	TK-340	12000	325	
Kyocera	Kyocera FS-2020DN	TK-340	12000	325	



<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Kyocera	Kyocera FS-2100d	TK-3100	12500	325	
Kyocera	Kyocera FS-2100dn	TK-3100	12500	325	
Kyocera	Kyocera FS-3040	TK-475	15000	520	
Kyocera	Kyocera FS-3040 MFP	TK-350	15000	465	
Kyocera	Kyocera FS-3040dn	TK-3100	12500	325	
Kyocera	Kyocera FS-3140	TK-475	15000	520	
Kyocera	Kyocera FS-3140 MFP	TK-350	15000	465	
Kyocera	Kyocera FS-3540 MFP	TK-350	15000	465	
Kyocera	Kyocera FS-3640 MFP	TK-350	15000	465	
Kyocera	Kyocera FS-3700	TK-20	20000	870	
Kyocera	Kyocera FS-3900	TK-310	12000	480	
Kyocera	Kyocera FS-3900	TK-320	15000	465	
Kyocera	Kyocera FS-3900dn	TK-320	15000	465	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Kyocera	Kyocera FS-3900dn	TK-310	12000	480	
Kyocera	Kyocera FS-3920DN	TK-350	15000	465	
Kyocera	Kyocera FS-4000	TK-310	12000	480	
Kyocera	Kyocera FS-4000	TK-330	20000	870	
Kyocera	Kyocera FS-4000dn	TK-310	12000	480	
Kyocera	Kyocera FS-4020DN	TK-360	20000	620	
Kyocera	Kyocera FS-4100DN	TK-3110	15500	425	
Kyocera	Kyocera FS-4200dn	TK-3130	25000	650	
Kyocera	Kyocera FS-4300dn	TK-3130	25000	650	
Kyocera	Kyocera FS-6025 MFP	TK-475	15000	520	
Kyocera	Kyocera FS-6025 MFP	TK-475	15000	520	
Kyocera	Kyocera FS-6030 MFP	TK-475	15000	520	
Kyocera	Kyocera FS-6525 MFP	TK-475	15000	520	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Kyocera	Kyocera FS-6530 MFP	TK-475	15000	520	
Kyocera	Kyocera FS-6700	TK-20	20000	870	
Kyocera	Kyocera FS-6700	TK-20	20000	870	
Kyocera	Kyocera FS-6900	TK-20	20000	870	
Kyocera	Kyocera FS-6950DN	TK-440	15000	520	
Kyocera	Kyocera FS-6970DN	TK-450	15000	520	
Kyocera	Kyocera FS-720	TK-110	6000	290	
Kyocera	Kyocera FS-820	TK-110	6000	290	
Kyocera	Kyocera FS-9130DN	TK-710	40000	1700	
Kyocera	Kyocera FS-920	TK-110	6000	290	
Kyocera	Kyocera FS-9530DN	TK-710	40000	1700	
Kyocera	Kyocera KM-1620	TK-410	15000	520	
Kyocera	Kyocera KM-1635	TK-410	15000	520	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Kyocera	Kyocera KM-1650	TK-410	15000	520	
Kyocera	Kyocera KM-2020	TK-410	15000	520	
Kyocera	Kyocera KM-2035	TK-410	15000	520	
Kyocera	Kyocera KM-2050	TK-410	15000	520	
Kyocera	Kyocera KM-2250	TK-420	15000	520	
Kyocera	Kyocera KM-2540	TK-675	20000	870	
Kyocera	Kyocera KM-2560	TK-675	20000	870	
Kyocera	Kyocera KM-3040	TK-675	20000	870	
Kyocera	Kyocera KM-3050	TK-715	34000	1700	
Kyocera	Kyocera KM-3060	TK-675	20000	870	
Kyocera	Kyocera KM-4050	TK-715	34000	1700	
Kyocera	Kyocera KM-5050	TK-715	34000	1700	
Kyocera	Kyocera TASKalfa 180	TK-435	15000	520	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Kyocera	Kyocera TASKalfa 1800	TK-4105	15000	500	
Kyocera	Kyocera TASKalfa 1801	TK-4105	15000	500	
Kyocera	Kyocera TASKalfa 181	TK-435	15000	520	
Kyocera	Kyocera TASKalfa 220	TK-435	15000	520	
Kyocera	Kyocera TASKalfa 2200	TK-4105	15000	500	
Kyocera	Kyocera TASKalfa 2201	TK-4105	15000	500	
Kyocera	Kyocera TASKalfa 221	TK-435	15000	520	
Kyocera	Kyocera TASKalfa 300i	TK-685	20000	870	
Kyocera	Kyocera TASKalfa 3010i	TK-7105	20000	750	
Kyocera	Kyocera TASKalfa 3011i	TK-7105	20000	750	
Kyocera	Kyocera TASKalfa 3212i	TK-7125	20000	700	
Kyocera	Kyocera TASKalfa 3500i	TK-6305	35000	795	
Kyocera	Kyocera TASKalfa 3501i	TK-6305	35000	795	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Kyocera	Kyocera TASKalfa 3510i	TK-7205	35000	1250	
Kyocera	Kyocera TASKalfa 3511i	TK-7205	35000	1250	
Kyocera	Kyocera TASKalfa 4002i	TK-6325	35000	530	
Kyocera	Kyocera TASKalfa 4012i	TK-7225	35000	1250	
Kyocera	Kyocera TASKalfa 420i	TK-725	34000	1700	
Kyocera	Kyocera TASKalfa 4500i	TK-6305	35000	795	
Kyocera	Kyocera TASKalfa 4501i	TK-6305	35000	795	
Kyocera	Kyocera TASKalfa 5002i	TK-6325	35000	530	
Kyocera	Kyocera TASKalfa 520i	TK-725	34000	1700	
Kyocera	Kyocera TASKalfa 5500i	TK-6305	35000	795	
Kyocera	Kyocera TASKalfa 5501i	TK-6305	35000	795	
Kyocera	Kyocera TASKalfa 6002i	TK-6325	35000	530	
Kyocera	Kyocera TASKalfa 6500i	TK-6705	70000	1590	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Kyocera	Kyocera TASKalfa 6501i	TK-6705	70000	1590	
Kyocera	Kyocera TASKalfa 8000i	TK-6705	70000	1590	
Kyocera	Kyocera TASKalfa 8001i	TK-6705	70000	1590	