


Детализировка и лист запасных частей к гайковерту FROSP ПГ-12



No.	Part name	QTY	No.	Part name	QTY	No.	Part name	QTY	No.	Part name	QTY
1	Housing	1	12	Clamp nut	1	23	Cylinder	1	34	Ratchet pawl	1
2	Air inlet	1	13	Planet gear	3	24	Rotor	1	35	Pin	1
3	Trigger	1	14	Gear pin	3	25	Rotor blade	4	36	Revers knob	1
4	Trigger pin	1	15	Gear plate	1	26	Front end plate	1	37	C retainer ring	1
5	Valve stem	1	16	Crank shaft	1	27	Bearing	1	38	Spring	2
6	O-ring	1	17	Ratchet anvil	1	28	Rear end plate	1	39	Steel ball	2
7	Valve spring	1	18	Ratchet housing	1	29	Bearing	1	40	Washer	1
8	Valve plug	1	19	Bushing	1	30	Dowel pin	2	41	Steel ball	1
9	Washer	1	20	Needle bearing	1	31	Thrust washer	1	42	Spring	1
10	O-ring	1	21	Bushing	1	32	Spring	1			
11	Thread ring gear	1	22	Ratchet yoke	1	33	Lock pin	1			