

Squier Deluxe Active Jazz Bass V

Rosewood- m/n 0300575xxx



<u>Loc #</u>	<u>Description</u>	<u>Part Number</u>
1	Standard Tuners (set of 5)	007-3794-000
2	Bone Nut (blank) (2)	003-8487-000
3	String Guide	007-7500-000
4	Strap Buttons (2)	099-4915-000
5	Neck Pickup	006-2414-000
7	Bridge Pickup	006-2415-000
8	25K Volume Pot	007-2832-000
9	100K Middle Pot	007-2830-000
10	500K Blend Pot	007-2831-000
8-10a	Volume/Tone Knobs (ea) (chr)	007-2838-000
11	100K Stacked Tone Pot	007-2833-000
11a	Stacked pot knob (chrome)	007-3795-000
12	Toggle Switch	007-2834-000
13	Output Jack	007-2837-000
13a	Jack Plate	006-2416-000
14	Bridge Assembly	006-2436-000
	Battery box	007-4623-000

Deluxe Jazz Bass IV Active

Deluxe Jazz Bass V Active

6 5 4 3 2 1

D
C
B
A

D
C
B
A

