












Руководство по распаковке и установке  
Unpacking and Installation Guide  
Қаптамадан шығару және орнату нұсқаулығы  
Посібник з розпаковки та встановлення  
Qadoqdan chiqarish va oʻrnatish qoʻllanmasi

LS03C 32"




Не касайтесь экрана  
Do not touch the screen  
Не торкайтесь экрану  
Экранды тимеңіз  
Ekranga tegmang





	A	B	C	D	D1	D2	E	E1	E2	G	H	I
QE32LS03C	727,3 mm (727.3 mm)	426,8 mm (426.8 mm)	25,5 mm (25.5 mm)	451,9 mm (451.9 mm)	440,1 mm (440.1 mm)	739,9 mm (739.9 mm)	143,3 mm (143.3 mm)	150,4 mm (150.4 mm)	150,5 mm (150.5 mm)	80 cm (80 cm)	5,1 кг (5.1 kg)	5,2 кг (5.2 kg)



	A (mm) A (mm)	B (mm) B (mm)	C (mm) C (mm)	D (mm) D (mm)	E (mm) E (mm)
	277.5	277.5			
QE32LS03C			224.9	72.5	72.4

