





# Luka




- |      |                             |      |                         |
|------|-----------------------------|------|-------------------------|
| (D)  | Montageanleitung            | (GB) | Assembly instructions   |
| (FR) | Notice de montage           | (IT) | Istruzioni di montaggio |
| (NL) | Handleiding voor de montage | (PL) | Instrukcja montażu      |
| (CZ) | Montážní návod              | (SK) | Návod na montáž         |
| (HU) | Szerelési útműtató          | (RO) | Instrukțiuni de montaj  |
| (TR) | Montaj talimati             | (RU) | Инструкция по монтажу   |




110 kg-MAX

LKZ 41650


8




9




5



6



7





4

## Service • Assistenza • Dienstverlening • Serwis Servic • Szerviz • Сервисная служба


Name • Nom • Nome • Naam •  
Nazwa • Jméno • Názov • Név •  
Denimiro • Isim • Название

Nr. • No. • N° • Номер • Č. • Sz

Typ • Type • Tip •  
Típus • Tipo • Тип



<b>A</b>		<b>B</b>		<b>C</b>		<b>D</b>		<b>E</b>		<b>F</b>		<b>G</b>	
M6x60	8	D=6	8	M6x25	8	H=130	2	M6x20	26	D=20	8	20x40	4
<b>H</b>		<b>I</b>		<b>J</b>									
	2		1		1								



0

1

2

3

4

5

6

7

8

9

10

11

12


13

14


15

1

1




2




2

3



4



3