



Детализировка компрессорного блока КВД265/300

N070	I1014	3rd stage guide piston	1
N069	I1015	3rd stage floating piston	1
N068	A2013	3rd stage cylinder	1
N067	R1022	3rd stage cylinder head sealing ring	1
N066	I7023	3rd stage intake valve seat	1
N065	M4015	3rd stage intake valve spring	1
N064	I7022	3rd stage intake leaf valve	1
N063	I7021	3rd stage intake valve cover	1
N062	A6015	3rd stage cylinder head	1
N061	R1020	exhaust valve sealing ring	1
N060	I7020	3rd stage exhaust valve cover	1
N059	I7019	3rd stage exhaust leaf valve	1
N058	M4014	3rd stage exhaust valve spring	1
N057	I7018	3rd stage exhaust valve seat	1
N056	A6014	3rd stage cylinder cover	1
N055	I8032	dipstick	1
N054	M0001	sealing gasket	1
N053	M2011	oil-filling pipe	1
N052	R1019	sealing ring	1
N051	M1023	oil-filling pipe cover	1
N050	P4001	air filter assembly	1set
N049	A6013	1st stage cylinder head	1
N048	P3007	asbestos cushion	1
N047	I7017	1st stage height limiter	1
N046	I7016	1st stage exhaust leaf valve	1
N045	I7015	1st stage valve plate	1
N044	I7014	1st stage intake leaf valve	1
N043	I1013	1st stage piston	1
N042	M5011	1st stage piston pin	1
N041	I2010	1st stage piston ring	1
N040	A3009	connecting rod	3
N039	I8031	oil splash needle	3
N038	P3006	asbestos cushion	1
N037	A2012	1st stage cylinder	1
N036	R1021	1st stage cylinder sealing ring	1
N035	A6016	balance	1
N034	I7024	bearing spacer	2
N033	A5004	crankshaft	1
N032	M6008	6206 bearing	1
N031	A1006	crankcase back cover	1
N030	R2004	oil sealing	1
N029	Z4001	2nd stage safety valve assembly	1
N028	M1022	exhaust screw cap	2
N027	M2007	screw cap	1
N026	I7013	2nd stage exhaust valve seat	1
N025	I7012	2nd stage exhaust spring	1
N024	I7011	2nd stage exhaust leaf valve	1
N023	I7009	2nd stage exhaust valve cover	1
N022	A6012	2nd stage cylinder head	1
N021	I7008	2nd stage intake valve cover	1
N020	I7010	2nd stage intake leaf valve	1
N019	M4013	2nd stage intake valve spring	1
N018	I7007	2nd stage intake valve seat	1
N017	A2011	2nd stage cylinder	1
N016	R1018	2nd&3rd stage cylinder sealing ring	2
N015	I2009	2nd stage piston ring	1
N014	I1012	2nd stage piston	1
N013	M5010	piston pin	2
N012	M4012	piston pin snap ring	6
N011	M6010	M20/20single row roller bearing	3
N010	M6009	M4906 single row roller bearing	3
N009	A2010	2nd&3rd stage cylinder neck	2
N008	R1017	sealing ring	2
N007	M1021	oil drain screw	1
N006	A1005	crankcase	1
N005	R1016	crankcase cover sealing ring	2
N004	M3008	oil baffle plate	1
N003	M4011	bearing snap ring	2
N002	M6007	NU305 bearing	1
N001	A1004	crankcase front cover	1
No.	Serial No.	название	Кол-во