


Flexy-33 (WT)
Flexy-33 (BK)



I.




FLEXY


UAB „Rubineta“
Motoru st. 6, LT-02190 Vilnius, Lithuania
www.rubineta.com

COMPANY WITH
MANAGEMENT SYSTEM
CERTIFIED BY DNV
ISO 9001 • ISO 14001


V2307



II.





III.



IV.

**Flexy-25 (WT)
Flexy-25 (BK)**



I.

V.

EN

Low pressure kitchen faucet Flexy-25 has 3 connection hoses and is suitable for usage with pressureless water heaters (boiler, instant water heaters etc).

Warning!


After faucet ceramic cartridge is closed, it is normal for water to drip for about 1 minute. This phenomenon occurs due to the faucet design itself. This is the reason, why prolonging hoses or flow controller should not be connected to faucet's spout. After the closure, little more water may drip from the faucet, if expansion vessels with a plastic / rubber reservoir are being used. Aerator is made differently for the low pressure faucet and we must be very attentive on this.

SRB

Nisko pritisna kuhinjska jednoručna baterija Flexy-25 sa tri creva.
Koristi se kod niskopritisnih bojlera i protočnih bijlera za nisku montažu.


Upozorenje!

Nakon što se keramički mešač zatvori, normalna je pojava kapljivanja vode na izlivu oko 1 min. Ovo je normalna pojava ujednačavanja pritiska iz bojlera i stoga proizvođači i kontrolori protoka ne treba priključivati na izliv baterije. Vreme kapanja može biti i duže ako je ekspanzionalni sud bojlera od plastike ili gume. Aerator-perlator za baterije niskog pritiska zbog tehničkih zahteva sistema se razlikuje od običnih perlatora i prilagođeni su tehničkim specifičnostima i standardima zahteva za upotrebom na bojlerima niskog pritiska.



III.

IV.



V.