




Instrukcja montażu / Инструкция по сборке / Montáž instrukce / Montáž inštrukcie / Assembling instruction / Szerelési utasítás Montageanleitung / Сглобяване инструкция / Notice de montage / Kurulum Talimatları / Montaje de instrucción / Montagem de instrução / Sestavljanje navodila / Montage instructie / Склапање инструкцију / Asamblarea de instrucțiuni / Sastavljanje upute / Montering instruktion / Istruzioni di montaggio / Збіркаінструкція / Montāžas instrukcija / Montavimo instrukcija / Paigaldusjuhend



















Спинка Металика ВЗ


120, 140, 160, 180


PL - Przed rozpoczęciem zapoznać się z instrukcją montażu / RU- Перед началом обратитесь к инструкции по установке / CZ- Před zahájením naleznete v montážním návodu / SK- Pred začatím nájdete v montážnom návode / EN- Before starting, refer to the assembling advice in annex / HU- Megkezdése előtt olvassa el a telepítési utasításokat / DE- Vor die montage, bitte beiliegende anweisungen folgen / BG-Преди да започнете се отнасят към инструкциите за инсталиране / FR- Avant de commencer, se reporter aux conseils de montage en annexe / TR- Kuruluma baslamadan once, montaj talimatnamesini sirasiyla takip edin. / ES-Antes de comenzar referirse a las instrucciones de instalación / P- Antes de começar a consultar as instruções de instalação / SLO- Pred začetkom glejte navodila za namestitev / NL- Voordat u begint Zie de installatie-instructies / SRB- Пре почетка погледајте упутства за инсталацију / RO-Înainte de a începe să consultați instrucțiunile de instalare / HR- Prije početka pogledajte upute za instalaciju / S- Innan du börjar se Installationsanvisningen / I- Avanti di comminciare, riportate agli consigli di montaggio / UKR- Перед початком зверніться до інструкції з установки / LV- Pirms sākt montāžu, iepazīties ar instrukciju / LT- Prieš pradedant kreiptis į montavimo instrukcija / EST- Enne käivitamist vaadake pajgaldusjuhiseid












Α	1
В	1
С	1


D	1
Ε	2
F	14


	444					m_{1}	m_{1}		m
1	1	1	/	, -	1	7	0	0)
	2	3	4	5	6	/	8	9	- /

	G	2
	Н	28
	I	8
	J	2
Q	K	6

L	10
М	6
Ν	2
0	2
Р	2







Адрес: 610014, Россия, Кировская обл., г. Киров, ул. Потребкооперации, д.8Д/1, +7 (8332) 71-23-42. service-k@domaklevo.ru, www.domaklevo.ru.