



Disney

43224



4



WARNING: CHOKING HAZARD.
Toy contains small parts and a small ball.
Not for children under 3 years.




⚠️ AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.
Le jouet contient des petites pièces ainsi qu'une petite boule.
Il ne convient pas aux enfants de moins de 3 ans.

⚠️ ADVERTENCIA: PELIGRO DE ASFIXIA.
Juguete que contiene partes pequeñas y una pelota pequeña.
No recomendado para niños menores de 3 años.





1



2





2x

3







4





5







6







7



8






2x



1x

9







1x




1x

10





11






2x



2x


12





2x


13





2x

14






1x



1x

15






2x



2x


16







1x

17






18





19





2x

20





2x



1x

21

1



2





2x



1x

22

1



2






1x



1x

23





1x

24





1x

25





1x

26





1x



1x

27





1x



1x

28





1x

29






1x



1x

30





1x


31







2x

32






34






35





2x

36






1x



2x


37







1x

38





39



40







1x



1x

41



1x



1x

42





1x

43






1x




1x

44






45



46






1x



1x

47



1x




1x

48






49





50





2x




1x

51

1



2








52




53




54






55

1



2



3








1x




2x


56







57






58




59





1x


60






2x

61




1x

62




63





64









Disney
WISH

43224



43223

©Disney



43231



Rebuild
the
world™



