

FreeMotion B400

Wireless stereo headset



1. Functions

CLICK

1 Play-pause

2 Volume-

3 Volume+

4 Change the equalizer mode (normal, pop, rock, jazz, country, heavy bass)

Double click - on/off backlight

LONG PRESS


1 On/Off

2 Previous track

3 Next track

4 On/Off

TF card (sold separately)* - insert till it clicks




* up to 32GB, FAT32 file system

2. Phone call

1 Double click - dialing last call

2 Answer call


3 Long press - reject call



3. Removable microphone




4. Charging




NOTE

The charge level display for smartphones is approximate. Incorrect display of the charge level is not a breakdown.

5. Connection



6. AUX mode



IMPORTANT

In AUX mode FM/MP3/BT modes and microphone won't work.

