


Инструкция по эксплуатации

Русский язык

1 Краткий обзор


- 1 Клавиша настройки меню
- 2 mini HDMI
- 3 Type-C
- 4 складная подставка
- 5 противоскользящая поверхность



2 Подключение к ПК


Подключите свой ПК к интерактивному дисплею, как показано на рисунке ниже:

- 1 mini HDMI
- 2 Type-C
- 3 HDMI
- 4 USB




3 Установка драйвера


- Подготовка перед установкой драйвера: пожалуйста, удалите все драйверы планшетов с вашего компьютера и закройте все антивирусные программы.
- Загрузите драйвер по ссылке: <http://www.bostotablet.com/down.aspx>
- После успешной установки драйвера
 - Windows: найдите иконку "Digitalizer" на рабочем столе или панели задач в правом нижнем углу



- Мас: найдите иконку (Tablet) на панели запуска. После клика на нее вы увидите маленькую иконку на правой верхней навигационной панели (как показано на рисунке ниже). Кликните на нее, чтобы открыть панель настройки драйвера.




4 калибровка экрана



5 Настройки режима касания пальцем


(только для моделей с функцией касания пальцами)



Примечание: выбор функции "Отключить режим одноточечного прикосновения" может в значительной степени уменьшить возможность случайного касания


6 Установка кнопок

(только тип привязки)




Примечание: комбинации клавиш можно настроить



Настроить как клик левой или правой кнопкой мыши:




Настроить как нажатие клавиши:



Настроить как комбинацию клавиш:




7 Настройка уровня нажатия пера



Регулировка нажима: перемещайте ползунок вправо, если для рисования линий требуется больший нажим.

Регулировка чувствительности: перемещайте ползунок вправо, чтобы линия стала толще при том же давлении.

8 Извлечение пера




Спасибо за покупку! Мы будем рады, если Вы оставите хороший отзыв. Всего Вам доброго и отличного дня!

Quick Guide

English

1 OVERVIEW


- 1 Menu adjustment key
- 2 miniHDMI
- 3 Type-C
- 4 Foldable stand
- 5 Non-slip mat



2 CONNECTION

Connect your tablet with the computer as shown :

- 1 mini HDMI
- 2 Type-C
- 3 HDMI
- 4 USB



3 DRIVER INSTALLATION

1. Preparation before installation : Uninstall and remove other graphic tablet/monitor driver installed in your computer, quit all running programs, disable any anti-virus software and firewall temporarily, Installing the driver as administrator.


2. Download the driver from: <http://www.bostotablet.com/down.aspx>

3. After a successful installation


- ① Windows: You can find the "Digitizer" icon on the desktop or task bar bottom right corner of your computer.




- ② Mac: You can find "Tablet" icon in the "Launchpad", after click it, you will see the small icon on the top right navigation bar (as shown in the picture below), click to open the driver settings panel.



4 SCREEN CALIBRATION




5 FINGER-TOUCH SETTINGS (Only for 12HDT / 12HDKT / 13HD)




Note: select the "Disable single point touch" can greatly reduce false operation

6 SET THE KEYS (Only for 12HDK and 13HD series)



Note: Shortcut keys can be customized



Set to left and right mouse buttons:




Set as keyboard key:



Set as key combination:




7 SET UP THE PRESSURE SENSITIVE PEN



Pressure adjustment: drawing the Minimum pen pressure of lines Move the slider to the right, more pressure required for drawing the lines

Sensitivity adjustment: when drawing , the change ranges of the thickness for the corresponding lines, Move the slider to the right, the line is thicker for the same pressure.

8 REPLACE PEN NIB



Thank you for your purchase! We will be glad if you leave a good review, it is important for us. All the best to you and have a good day!